RemotesReplaced S6550-HD

RemotesReplaced Compatible Remote Control for SEDEA S6550-HD User Manual

Introduction

This manual provides instructions for the RemotesReplaced compatible remote control, designed as a direct replacement for the original SEDEA S6550-HD remote. It offers all the same functionalities as the original, ensuring seamless operation with your device.

Features

- Direct replacement for the original SEDEA S6550-HD remote control.
- No setup codes required; ready to use after battery insertion.
- Provides access to all original functions of your SEDEA S6550-HD device.
- Engineered to be electronically identical to the original remote.

Setup

1. Battery Installation

Locate the battery compartment on the back of the remote control. Slide open the battery cover. Insert two AAA batteries, ensuring correct polarity (+ and - terminals). Close the battery cover securely.



Image: Back of the remote control with the battery compartment.

2. Initial Use

This remote control is pre-programmed for the SEDEA S6550-HD. No additional setup or programming is required. Once batteries are installed, the remote is ready for immediate use with your device.

Operating Instructions

The remote control features a standard layout for easy navigation and control of your SEDEA S6550-HD device. Below is a general guide to common buttons and their functions.



Image: Front view of the remote control with all buttons labeled.

- **POWER:** Turns the device on or off.
- **MUTE:** Mutes or unmutes the audio.
- **TV/SAT/DVD/AUX:** Selects the input source.
- **MENU:** Accesses the main menu.
- **EXIT:** Exits the current menu or screen.
- **SHIFT:** Used for secondary functions of certain buttons.
- **Number Buttons (0-9):** For direct channel selection or inputting numbers.
- **SOURCE:** Cycles through available input sources.
- **-/--:** Toggles between single and double-digit channel entry.
- **GUIDE:** Displays the electronic program guide.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes the channel up or down.
- **SETUP:** Accesses setup options.
- **TEXT:** Activates teletext.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates through menus and confirms selections.
- **BACK:** Returns to the previous screen or menu.
- **SLEEP:** Sets a sleep timer.
- **TV/DTV:** Switches between TV and Digital TV modes.
- **INFO:** Displays program information.
- **EPG:** Electronic Program Guide.
- **FAV:** Accesses favorite channels.
- **NET TV / SMART:** Accesses internet-connected features or smart TV functions.
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within menus or applications, as indicated on screen.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback.

Maintenance

Battery Replacement

When the remote control's performance degrades or it stops responding, replace both AAA batteries. Always replace with new batteries of the same type. Do not mix old and new batteries, or different types of batteries.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the remote's surface or internal components.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the device's infrared receiver.

- Make sure you are within the effective range of the device.

- **Specific buttons not working:**
  - Ensure the remote is pointed directly at the device.
  - Clean the remote's surface, especially around the unresponsive buttons, to remove any debris.

Specifications

Attribute	Value
Brand	RemotesReplaced
Model Number	S6550-HD
Compatible Device	SEDEA S6550-HD
Battery Type	2 x AAA batteries (not included)
Item Weight	120 Grams
ASIN	B09SWWTB3F

Warranty and Support

This RemotesReplaced product comes with a **1-year warranty**. For any issues, questions, or support needs, please contact the seller directly through your purchase platform. Provide your order details for faster assistance.

© 2024 RemotesReplaced. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question