RemotesReplaced TS6820-T2-HEVC

RemotesReplaced Remote Control Instruction Manual for TELESYSTEM TS6820-T2-HEVC

Model: TS6820-T2-HEVC

Introduction

This manual provides instructions for the RemotesReplaced replacement remote control, specifically designed for the TELESYSTEM TS6820-T2-HEVC device. This remote offers identical functionality to the original remote control without requiring any complex setup or programming.

Setup

1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back of the remote control with the battery compartment visible. This image illustrates where to insert the AAA batteries.

2. Initial Use

No setup codes or programming are required. Once batteries are correctly installed, the remote control is ready for immediate use with your TELESYSTEM TS6820-T2-HEVC device.

Operating Instructions

This remote control provides full functionality for your TELESYSTEM TS6820-T2-HEVC. Below is a general guide to its buttons and their functions.



Image: Front view of the RemotesReplaced remote control. This image displays the layout of all buttons on the remote.

Key Button Functions:

- **POWER (●)**: Turns the device on or off.
- **MUTE**: Mutes or unmutes the audio.
- **TV/SAT/DVD/AUX**: Selects input sources.
- **MENU**: Accesses the main menu.
- **EXIT**: Exits the current menu or function.
- **SHIFT**: Used for secondary functions of certain buttons.
- **Number Buttons (0-9)**: Directly enters channel numbers or other numerical inputs.
- **SOURCE**: Changes the input source.
- **-/--**: Toggles between single and double-digit channel entry.
- **GUIDE**: Displays the electronic program guide (EPG).
- **Navigation Pad (Up, Down, Left, Right, OK)**: Navigates through menus and confirms selections.
- **VOL +/-**: Adjusts the volume level.
- **CH +/- (P +/-)**: Changes channels.
- **BACK**: Returns to the previous screen or menu.
- **SLEEP**: Sets a sleep timer.
- **TV/DTV**: Switches between TV and Digital TV modes.
- **INFO**: Displays information about the current program.
- **EPG**: Electronic Program Guide.
- **FAV**: Accesses favorite channels list.
- **NET TV / SMART**: Accesses internet-connected features or smart TV functions.
- **Color Buttons (Red, Green, Yellow, Blue)**: Used for specific functions within menus or applications, as indicated on screen.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward)**: Controls media playback.

Maintenance

Cleaning the Remote Control

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using abrasive cleaners, alcohol, or solvents, as these can damage the surface and markings.

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Storage

When not in use for extended periods, it is recommended to remove the batteries to prevent leakage, which could damage the remote control.

Troubleshooting

- **Remote control is not working:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the TELESYSTEM device.
  - Ensure you are within the effective range of the device.
- **Some buttons are not responding:**
  - Verify that the remote control is pointed directly at the TELESYSTEM device's infrared receiver.
  - Clean the remote control's surface and buttons to ensure no debris is interfering with button presses.
  - If only specific input buttons (e.g., TV, DVD) are not working, ensure your TELESYSTEM device supports that specific input or function.

Specifications

Feature	Detail
Brand	RemotesReplaced
Model Number	TS6820-T2-HEVC
Compatible Devices	TELESYSTEM TS6820-T2-HEVC (Television)
Connectivity Technology	Infrared (IR)
Number of Buttons	25
Batteries Required	2 x AAA (not included)
Item Weight	120 Grams
Manufacturer	Linkwebb

Warranty Information

This RemotesReplaced remote control comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote performs as intended. Please retain your proof of purchase for any warranty claims.

Support

For further assistance, troubleshooting, or warranty inquiries, please contact the seller or RemotesReplaced customer support. Provide your product model number (TS6820-T2-HEVC) and details of your issue for efficient support.
You can typically find contact information on the packaging or through the retailer where the product was purchased.

© 2023 RemotesReplaced. All rights reserved. TELESYSTEM is a registered trademark of its respective owner.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question