Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced RC1110

RemotesReplaced Compatible Remote Control for VESTEL RC110 TV User Manual

Model: RC1110

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your RemotesReplaced compatible remote control for VESTEL RC110 TV. This remote is designed to function identically to the original VESTEL RC110 remote, offering all the same features without requiring any complex setup codes.



Image: Front view of the remote control. This image displays the full layout of buttons on the remote, including power, channel, volume, navigation, and special function keys.

Setup

Battery Installation

The remote control requires two AAA batteries for operation. Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Back view of the remote control. This image highlights the battery compartment cover, indicating where to open it for battery insertion.



Image: Bottom view of the remote control. This perspective provides an additional view of the battery compartment's location and design.

Initial Use

No setup codes are required for this remote control. Once batteries are installed, it is ready for immediate use with compatible VESTEL RC110 TV models.

Operating Instructions

This section details the functions of the various buttons on your remote control.

General Functions

- **POWER** (**Red Button**): Turns the TV on or off.
- **MUTE**: Mutes or unmutes the TV sound.
- **TV** / **SAT** / **DVD** / **AUX**: Selects the input source (TV, Satellite, DVD player, Auxiliary device).
- **MENU**: Opens the TV's main menu.
- **EXIT**: Exits the current menu or on-screen display.
- **SHIFT**: Activates secondary functions of certain buttons (if applicable).

Navigation and Selection

- **Directional Arrows (Up, Down, Left, Right)**: Navigates through menus and options.
- **OK**: Confirms a selection or enters a menu.
- **BACK**: Returns to the previous screen or menu.

Channel and Volume Control

- **CH +/-**: Changes the TV channel up or down.
- **VOL +/-**: Adjusts the volume level up or down.
- **SOURCE**: Cycles through available input sources.
- **Number Pad (0-9)**: Directly enters channel numbers.
- **-/--**: Toggles between single and double-digit channel entry (for older TVs).
- **GUIDE**: Displays the electronic program guide (EPG).

Special Functions

- **SLEEP**: Sets a sleep timer for the TV.
- **TV/DTV**: Switches between analog and digital TV modes.
- **INFO**: Displays information about the current program or input.
- **EPG**: Electronic Program Guide.
- **FAV**: Accesses favorite channels list.
- **NET TV**: Direct access to network TV features or smart TV applications.
- **SMART**: Opens the Smart TV interface.
- **Colored Buttons (Red, Green, Yellow, Blue)**: These buttons typically correspond to specific functions within menus or smart TV applications, as indicated on-screen.
- **Play/Pause, Stop, Rewind, Fast Forward**: Media playback controls for compatible devices or TV functions.

MAINTENANCE

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Storage:** Store the remote in a dry place, away from direct sunlight and extreme temperatures.
- **Battery Replacement:** If the remote control becomes unresponsive or its range decreases, replace the batteries with new AAA alkaline batteries. Remove batteries if the remote will not be used for an extended period to prevent leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries.	Replace batteries with new AAA batteries, ensuring correct polarity.
Remote has short range or intermittent response.	Weak batteries; obstruction between remote and TV; remote sensor on TV is blocked.	Replace batteries. Ensure a clear line of sight to the TV's IR sensor. Remove any obstructions.
Specific functions (e.g., DVD controls) are not working.	Incorrect input source selected on the remote or TV.	Press the corresponding input button (e.g., **DVD**) on the remote to switch to the correct mode. Ensure the TV is also on the correct input.

Specifications

- **Model Number:** RC1110
- **Brand:** RemotesReplaced
- **Compatible With:** VESTEL RC110 TV
- **Power Source:** 2 x AAA Batteries (not included)
- **Weight:** Approximately 120 Grams
- **Manufacturer:** Linkwebb



Image: Side view of the remote control. This image shows the ergonomic profile and thickness of the device.



Image: Opposite side view of the remote control. This provides another angle of the remote's design.



Image: Top view of the remote control. This image shows the top edge of the remote, including the infrared emitter.

Warranty and Support

This RemotesReplaced compatible remote control comes with a **1-year warranty** from the date of purchase, covering manufacturing defects. For warranty claims or technical support, please contact your retailer or the manufacturer directly. Please retain your proof of purchase for warranty purposes.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09TBCRYR5

More documents and user manuals: **https://manuals.plus/**