## IKEA Filmis

# IKEA Filmis Clock/Thermometer/Alarm User Manual

Model: Filmis
Brand: IKEA

## Introduction

This manual provides essential information for the proper use, setup, and maintenance of your IKEA Filmis Clock/Thermometer/Alarm. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity.
The IKEA Filmis is a battery-powered device offering three primary functions: time display, alarm, and temperature measurement. It is designed for indoor use and features a clear digital display with LED backlight.

## Features

- **Multi-functional Display:** Shows time, alarm setting, and current temperature.
- **LED Backlight:** The display features an LED backlight that illuminates when a button is pressed, enhancing visibility in low-light conditions.
- **Alarm with Snooze:** Equipped with an alarm function that includes a snooze feature, repeating the alarm signal every five minutes.
- **Battery Operated:** Requires 2 LR6 AA 1.5V batteries (sold separately) for operation.
- **CE Marked:** This product complies with European safety, health, and environmental protection requirements.

## Package Contents

The IKEA Filmis Clock/Thermometer/Alarm package typically includes:

- 1 x IKEA Filmis Clock/Thermometer/Alarm unit
- 1 x User Manual (this document)

*Note: Batteries (2 x LR6 AA 1.5V) are not included and must be purchased separately.*

## Setup

1. **Battery Installation:**

   Locate the battery compartment on the back of the unit. Insert 2 LR6 AA 1.5V batteries, ensuring correct polarity (+/-) as indicated inside the compartment. Close the battery cover securely.

2. **Initial Power On:**

   Once batteries are installed, the display should activate, showing default time and temperature settings.

3. **Placement:**

   Place the clock on a stable, flat surface. Ensure it is not exposed to direct sunlight, extreme temperatures, or high humidity, which could affect its performance or display accuracy.



**Figure 1:** The IKEA Filmis Clock placed on a white nightstand, demonstrating its compact size and suitability for bedroom environments. A lamp and part of a bed are visible in the background.

## Operating Instructions

The IKEA Filmis clock features intuitive controls for setting time, alarm, and viewing temperature.

### Setting the Time

1. Locate the "SET" button (or similar time-setting button) on the back or side of the unit.
2. Press and hold the "SET" button until the hour digits begin to flash.
3. Use the "+" and "-" buttons (or "UP" and "DOWN" buttons) to adjust the hour.
4. Press "SET" again to move to the minute digits, then use "+" and "-" to adjust the minutes.
5. Press "SET" one more time to confirm the time setting.

### Setting the Alarm

1. Locate the "ALARM SET" button (or similar alarm-setting button).
2. Press and hold the "ALARM SET" button until the alarm hour digits begin to flash.
3. Use the "+" and "-" buttons to adjust the alarm hour.
4. Press "ALARM SET" again to move to the alarm minute digits, then use "+" and "-" to adjust the minutes.
5. Press "ALARM SET" one more time to confirm the alarm setting.

6. To activate or deactivate the alarm, locate the "ALARM ON/OFF" switch or button. Ensure it is in the "ON" position for the alarm to sound.

When the alarm sounds, press any button (often the large top button) to activate the snooze function. The alarm will sound again after approximately five minutes. To turn off the alarm completely, press the "ALARM ON/OFF" button or switch it to the "OFF" position.

## Viewing Temperature

The current temperature is continuously displayed on the screen, typically in Celsius (°C). No specific action is usually required to view the temperature.

## Using the Backlight

To activate the LED backlight, press the large button located on the top of the clock. The backlight will illuminate for a few seconds, making the display easier to read in dark environments.




**Figure 2:** Front view of the IKEA Filmis Clock, clearly showing the digital display with time (11:05), alarm setting (12:00), and temperature (30°C). The grey frame and silver base are visible.




**Figure 3:** A detailed close-up of the IKEA Filmis Clock's digital display, highlighting the alarm time (12:00) and temperature reading (28°C). This view emphasizes the clarity of the digits.

# Maintenance

- **Cleaning:** Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may

damage the surface or display.

- **Battery Replacement:** When the display dims or functions become erratic, it is time to replace the batteries. Always replace both batteries simultaneously with new LR6 AA 1.5V batteries. Dispose of old batteries according to local regulations.
- **Storage:** If the clock will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the unit. Store in a cool, dry place.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Display is blank or dim. | Low or dead batteries. Incorrect battery installation. | Replace batteries with new LR6 AA 1.5V batteries. Ensure correct polarity (+/-). |
| Alarm does not sound. | Alarm is not activated. Alarm volume is too low (if adjustable). Incorrect alarm time set. | Ensure the "ALARM ON/OFF" switch is in the "ON" position. Re-check alarm time settings. (Note: This model does not have adjustable volume). |
| Temperature reading seems inaccurate. | Clock is placed near a heat source or in direct sunlight. | Relocate the clock to a stable room temperature environment, away from direct heat or cold sources. Allow time for the sensor to adjust. |
| Buttons are unresponsive. | Low batteries. Internal malfunction. | Replace batteries. If the issue persists, the unit may require service or replacement. |

## Specifications

- **Brand:** IKEA
- **Model Name:** Filmis
- **Color:** Grey
- **Material:** Plastic, ABS Plastic
- **Display Type:** Digital
- **Special Feature:** Alarm, Temperature Display, LED Backlight
- **Power Source:** Battery Powered (2 x LR6 AA 1.5V, not included)
- **Room Type:** Living Room (suitable for various indoor spaces)
- **Shape:** Rectangular
- **Indoor/Outdoor Use:** Indoor
- **ASIN:** B09TFC3LHJ
- **CE Marking:** Yes

## Warranty and Support

Information regarding specific warranty terms and customer support contact details for the IKEA Filmis Clock/Thermometer/Alarm is not available in the provided product data. For warranty claims or technical assistance, please refer to your purchase receipt or contact IKEA customer service directly through their official website or local store.

You may also visit the official IKEA website for general product information and supportwww.ikea.com

© 2023 IKEA. All rights reserved. This manual is for informational purposes only.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question