Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JVC SI58UR

JVC 4K UHD Smart TV with Roku Technology User Manual

Model: SI58UR

Introduction

This user manual provides comprehensive instructions for the setup, operation, and maintenance of your JVC 4K UHD Smart TV with Roku Technology, Model SI58UR. This model features the latest Roku operating system, offering an intuitive home screen and access to thousands of movies and TV episodes through hundreds of free and paid channels. Please read this manual thoroughly before using your television to ensure proper and safe operation.

Product Overview



Image: Front view of the JVC 4K UHD Smart TV, Model SI58UR. The screen displays a vivid image of a city skyline with

illuminated skyscrapers and palm trees along a waterfront, under a blue and orange sky. The TV has a slim black bezel and is supported by two black V-shaped feet.

The JVC SI58UR is a 58-inch 4K UHD Smart TV designed to deliver an immersive viewing experience. Key features include:

- **4K UHD Resolution (3840 x 2160):** Provides stunning clarity and detail.
- **Roku Operating System:** Offers a user-friendly interface and access to a vast library of streaming content.
- **Multiple Connectivity Options:** Equipped with 2 HDMI ports, 1 USB port, and Ethernet for versatile connections.
- **Integrated Audio:** Features 2 internal speakers for clear sound.
- **Sleek Design:** Modern aesthetics with a tabletop stand for easy placement.

Setup

1. Unpacking the Television

Carefully remove the television and all accessories from the packaging. Ensure all components listed in the "Components Included" section are present. It is recommended to retain the original packaging for future transport or service needs.

2. Attaching the Stand (Tabletop Mounting)

1. Place the TV screen-down on a soft, clean surface to prevent scratches.
2. Align each stand leg with the corresponding screw holes on the bottom of the TV.
3. Secure each leg with the provided screws. Do not overtighten.

3. Connecting Peripherals

Connect your devices to the appropriate ports on the back or side of the TV.

- **HDMI Ports (x2):** For connecting Blu-ray players, game consoles, cable/satellite boxes, etc.
- **USB Port (x1):** For connecting USB drives to view photos, videos, or listen to music.
- **Ethernet Port (x1):** For a wired internet connection.
- **Antenna/Cable Input:** For connecting an antenna or cable TV.

4. Power Connection

Plug the power cord into the TV's power input, then plug the other end into a wall outlet. The TV will enter standby mode.

Operating Instructions

1. Initial Setup (Roku OS)

Upon first power-on, the TV will guide you through the Roku OS setup process:

1. **Language Selection:** Choose your preferred language.
2. **Network Connection:** Connect to your Wi-Fi network or use a wired Ethernet connection.
3. **Roku Account:** Create a new Roku account or sign in to an existing one. This is required to access streaming channels.
4. **Channel Installation:** The TV will automatically install essential channels. You can add more later.
5. **Antenna TV Setup (Optional):** If connecting an antenna, the TV will scan for available channels.

2. Using the Remote Control

The included infrared remote control allows you to navigate the Roku interface and control TV functions. Ensure batteries

are inserted correctly.

- **Home Button:** Returns to the Roku Home screen.
- **Directional Pad:** Navigates menus and selects items.
- **OK/Select Button:** Confirms selections.
- **Back Button:** Returns to the previous screen.
- **Volume Up/Down:** Adjusts audio volume.
- **Mute Button:** Mutes/unmutes audio.
- **Power Button:** Turns the TV on/off.

3. Accessing Streaming Channels

From the Roku Home screen, select any installed channel icon to launch it. You can browse and add new channels from the "Streaming Channels" menu.

4. Input Selection

To switch between connected devices (e.g., HDMI 1, USB), select the corresponding input tile on the Roku Home screen.

Maintenance

1. Cleaning the Screen

- Turn off the TV and unplug it from the power outlet.
- Gently wipe the screen with a soft, lint-free cloth (e.g., microfiber cloth).
- For stubborn marks, lightly dampen the cloth with water or a screen-cleaning solution specifically designed for electronics. Do not spray liquid directly onto the screen.
- Avoid using abrasive cleaners, alcohol, benzene, or thinners, as these can damage the screen.

2. Cleaning the Cabinet

Wipe the TV cabinet with a soft, dry cloth. If necessary, use a slightly damp cloth, then immediately wipe dry.

3. Ventilation

Ensure proper ventilation around the TV. Do not block ventilation openings. Maintain a minimum distance from walls or other objects to allow for airflow.

Troubleshooting

Problem	Possible Cause	Solution
No power	Power cord not connected; Power outlet not working	Ensure power cord is securely plugged in; Test outlet with another device.
No picture, but sound is present	Incorrect input selected; Device not powered on or connected properly	Verify correct input source; Check device power and cable connections.
No sound, but picture is present	Volume muted or too low; Audio cables loose; Incorrect audio output setting	Unmute or increase volume; Check audio cable connections; Adjust TV audio settings.
Remote control not working	Batteries dead or incorrectly inserted; Obstruction between remote and TV	Replace batteries; Ensure line of sight to TV's IR sensor.

Problem	Possible Cause	Solution
Cannot connect to Wi-Fi	Incorrect password; Router issues; TV too far from router	Double-check Wi-Fi password; Restart router; Move TV closer to router or use Ethernet.

Specifications

Feature	Detail
Brand	JVC
Model Name	SI58UR
Screen Size	58 inches
Display Technology	LED-LCD
Resolution	4K UHD (3840 x 2160 pixels)
Refresh Rate	120, 240 Hz
Operating System	Roku Operating System
Connectivity Technology	USB, Ethernet, HDMI
HDMI Ports	2
USB Ports	1
Audio Output Mode	Stereo (2.0 Channel)
Remote Control Technology	Infrared
Mounting Type	Tabletop Stand
Package Dimensions	143 x 87 x 15 cm
Package Weight	14 kg
Included Components	TV, Remote Control, User Manual, Warranty Card

Warranty and Support

Warranty Information

This JVC television comes with a manufacturer's warranty. Please refer to the included warranty card for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact JVC customer support. Contact information can typically be found on the warranty card, the official JVC website, or the product packaging. When contacting support, please have your TV's model number (SI58UR) and serial number ready. The serial number is usually located on a sticker on the back of the television.

© 2024 JVC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09TG5XJSV

More documents and user manuals: **https://manuals.plus/**