Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

saschedross AC/DC Adapter for EverStart Jump Starters

AC/DC Adapter User Manual

For EverStart Maxx J7CCE, J7CE, 800A, 800 Peak Amps Battery Jump Starters

1. Introduction

This manual provides essential information for the safe and effective use of your new AC/DC Adapter. This adapter is designed to provide power for charging compatible EverStart maxx J7CCE, J7CE, Ever Start max 800A, and 800 Peak Amps Battery Jump Starters, which may include a 120 PSI Air Compressor, 3.1A USB Power, and LED features. Please read this manual thoroughly before use and retain it for future reference.



Figure 1: The AC/DC Adapter with its power cord and barrel connector. This adapter is designed to convert standard wall outlet AC power to DC power suitable for your jump starter.

2. Safety Information

Always observe the following safety precautions to prevent injury or damage to the adapter or connected device:

- Use the adapter only with compatible devices as specified.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to severe impact.
- Do not disassemble or attempt to repair the adapter. Refer servicing to qualified personnel.
- Ensure the power outlet is easily accessible and unplug the adapter when not in use or during electrical storms.
- Keep out of reach of children.
- Do not use if the adapter or cord is damaged.

3. Setup

Follow these steps to set up your AC/DC adapter for use:

1. **Inspect the Adapter:** Before first use, carefully inspect the adapter and its cable for any signs of damage. Do not use if any damage is observed.
2. **Connect to Device:** Locate the charging port on your compatible EverStart jump starter. Insert the barrel connector of the AC/DC adapter firmly into the charging port. Ensure a secure connection.
3. **Connect to Power Outlet:** Plug the AC prongs of the adapter into a standard 100-240VAC 50/60Hz wall outlet.



Figure 2: The compact design of the adapter allows for easy portability and connection to a standard wall outlet. Ensure the adapter is fully inserted into the outlet.

4. Operating Instructions

Once connected, the adapter will begin supplying power to your jump starter. The charging indicator on your jump starter (if equipped) should illuminate, indicating that charging is in progress.

- **Charging Time:** Refer to your jump starter's specific user manual for recommended charging times and full charge indications.
- **Overcharge Protection:** This adapter features OVP (Over Voltage Protection), OCP (Over Current Protection), and SCP (Short Circuit Protection) to ensure safe charging. However, it is always best practice to disconnect the adapter once the jump starter is fully charged.
- **Usage Environment:** Use the adapter in a well-ventilated area, away from direct sunlight or heat sources.

5. Maintenance

Proper maintenance ensures the longevity of your AC/DC adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Wipe the adapter with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly winding the cable to prevent damage.
- **Cable Care:** Do not pull on the cable to disconnect the adapter from the outlet or device. Always grasp the plug or connector.

6. Troubleshooting

If you encounter issues with your AC/DC adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Adapter not supplying power / Jump starter not charging.	◦ Loose connection. ◦ Power outlet not active. ◦ Adapter or cable damage. ◦ Incompatibility with the jump starter. ◦ Jump starter battery issue.	◦ Ensure both ends of the adapter are securely plugged in. ◦ Test the power outlet with another device. ◦ Inspect the adapter and cable for cuts, bends, or breaks. If damaged, discontinue use. ◦ Verify that your jump starter model (e.g., EverStart maxx J7CCE, J7CE, 800A, 800 Peak Amps) is listed as compatible. ◦ If the adapter appears functional, the issue might be with the jump starter's battery or charging circuit. Consult the jump starter's manual or manufacturer.
Adapter feels warm during use.	Normal operation.	A slight warmth is normal during operation. If the adapter becomes excessively hot, disconnect it immediately and contact support. Ensure adequate ventilation.

If the problem persists after trying these solutions, please contact the product manufacturer or seller for further assistance.

7. Specifications

- **Input Voltage:** 100-240VAC, 50/60Hz
- **Output Protection:** OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
- **Compatibility:** Specifically designed for EverStart maxx J7CCE, J7CE, Ever Start max 800A, 800 Peak Amps Battery Jump Starters with 120 PSI Air Compressor and 3.1A USB Power.
- **Color:** Black
- **Plug Format:** Type A (US Standard)



Figure 3: Dimensions of the AC/DC Adapter, showing its compact size for easy handling and storage.



Figure 4: The power cord length of the AC/DC Adapter, measuring approximately 6.5 feet, providing ample reach.

8. Warranty and Support

Specific warranty details for this AC/DC adapter are typically provided by the manufacturer or seller at the time of purchase. Please refer to your purchase documentation or contact the seller directly for information regarding warranty coverage, returns, or technical support.
For general inquiries or support, you may also visit the brand's official website or contact their customer service department.

Brand: saschedross

Manufacturer: Shenzhen Waweis Technology Co., Ltd

ASIN: B09TLB5FWW

© 2024 saschedross. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09TLB5FWW

More documents and user manuals: **https://manuals.plus/**