Bell+Howell 7902

Bell+Howell Monster Double Zapper 18W User Manual

Model: 7902

Introduction | Safety Instructions | Setup | Operating Instructions | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

Thank you for purchasing the Bell+Howell Monster Double Zapper 18W. This electric bug killer is designed to effectively eliminate flying insects like mosquitoes, gnats, and flies, as well as crawling insects such as cockroaches and ants, both indoors and outdoors. Please read this manual thoroughly before use to ensure safe and optimal operation.



Figure 1: Bell+Howell Monster Double Zapper 18W in its retail packaging.

2. Safety Instructions

- Read all instructions before using this appliance.
- Keep out of reach of children and pets. The internal grid carries an electric charge.
- Do not insert foreign objects into the zapper.
- Do not use near flammable liquids or gases.
- Do not immerse the unit in water or other liquids.
- Ensure the unit is fully charged before first use for optimal performance.
- Unplug the unit before cleaning.
- This product is designed for household use only.
- Do not attempt to repair or modify the unit. Contact customer support if service is required.

3. Setup

1. **Unpack the Unit:** Carefully remove the Monster Double Zapper and all accessories from the packaging. Verify all components are present: main unit, charging cable, cleaning brush, and instruction manual.
2. **Initial Charge:** Before first use, fully charge the unit. Locate the charging port on the back of the unit. Open the protective cover and connect the provided USB charging cable. Connect the other end to a compatible USB power

adapter (not included). The charging indicator light will illuminate.

3. **Placement:**
    - For flying insects: Place the zapper on a flat surface or hang it using the integrated handle in an area where flying insects are prevalent.
    - For crawling insects (e.g., cockroaches, ants): Ensure the unit is placed on a flat surface. The heat and bait attraction feature is most effective when the unit is stable on the ground.



Figure 2: The Monster Double Zapper can be placed on a flat surface or hung, suitable for various indoor and outdoor environments.

4. Operating Instructions

The Monster Double Zapper features multiple operating modes to target different types of pests.

1. **Power On/Off:** Press the main power button (usually located in the center of the control panel) to turn the unit on or off.
2. **Mode Selection:** The unit has four distinct modes, indicated by LED lights on the control panel. Press the mode selection button to cycle through the options:

- **Mode 1 (Mosquitoes):** Activates the UV light for attracting and zapping flying insects.
- **Mode 2 (Roaches):** Activates the heat and bait attraction system in the base for crawling insects.
- **Mode 3 (Both):** Activates both UV light and the heat/bait system for comprehensive pest control.
- **Mode 4 (Heat Only):** Activates only the heat attraction in the base.

3. **Placement for Effectiveness:**
    - For flying insects, place the unit in a central location within the affected area, away from competing light sources.
    - For crawling insects, place the unit directly on the floor or counter where pests are observed.



Figure 3: The UV light effectively attracts flying insects to the zapping grid.

Your browser does not support the video tag.

Video 1: Official product demonstration of the Double Zapper's features and operation. This video illustrates how the device attracts and eliminates both flying and crawling insects using UV light and a heated bait compartment.

5. Maintenance

Regular cleaning ensures the longevity and effectiveness of your Monster Double Zapper.

1. **Power Off and Unplug:** Always turn off the unit and unplug it from the power source before performing any maintenance.
2. **Empty the Collection Tray:** The unit is designed with a removable tray at the base to collect dead insects. Gently slide out the tray, dispose of the contents, and clean the tray with water and mild soap if necessary. Ensure it is completely dry before reinserting.
3. **Clean the Zapping Grid:** Use the provided cleaning brush to carefully remove any insect debris from the electric grid. Do not use water or metal objects to clean the grid.
4. **Clean the Exterior:** Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.



Figure 4: The unit is designed for easy cleaning with a removable collection tray at the base.

6. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Unit does not turn on.	Battery is depleted or unit is not charged.	Charge the unit using the provided USB cable. Ensure the charging indicator light is on.
UV light is dim or not working.	Low battery or bulb lifespan reached.	Recharge the unit. If the problem persists, contact customer support for bulb replacement options.
Ineffective at zapping insects.	Grid is dirty or unit is improperly placed.	Clean the zapping grid with the brush. Relocate the unit to an area with higher insect activity and away from competing light sources. Ensure the correct mode is selected.
Heat attraction for crawling insects is not working.	Incorrect mode selected or unit malfunction.	Ensure Mode 2 (Roaches) or Mode 3 (Both) is selected. If the issue persists, contact customer support.

Your browser does not support the video tag.

Video 2: User-submitted video demonstrating a potential issue where the light stays on for a short duration. This video can be helpful for diagnosing similar power-related problems.

7. Specifications

- **Model:** 7902
- **Brand:** Bell+Howell
- **Power:** 18W
- **Coverage Area:** Up to 1200 sq. ft. (½ acre)
- **Insect Types:** Mosquitoes, Gnats, Flies, Moths, Cockroaches, Ants, Spiders
- **Features:** UV Light attraction, Heat/Bait attraction (for crawling insects), Rechargeable, Portable
- **Material:** Fireproof ABS Plastic
- **Dimensions (LxWxH):** Approximately 10 x 10 x 10 inches (based on item dimensions)
- **Item Weight:** 16 ounces
- **UPC:** 080313079023

8. Warranty & Support

For warranty information or product support, please refer to the warranty description provided with your purchase or contact Bell+Howell customer service. Keep your proof of purchase for any warranty claims.
Manufacturer: E Mishan & Sons
For further assistance, visit the official Bell+Howell store:Bell+Howell Store on Amazon

© 2024 Bell+Howell. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question