Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

saschedross dsf03020084

saschedross 2-Prong AC Charging Cord Instruction Manual

Model: dsf03020084 | **Brand:** saschedross

1. Introduction

This instruction manual provides essential information for the safe and effective use of your saschedross 2-Prong AC Charging Cord. This cable is designed to provide AC power input for charging compatible CEN-TECH portable power pack jump starters. Please read this manual thoroughly before use and retain it for future reference.

2. Product Overview

The saschedross 2-Prong AC Charging Cord is a replacement or spare power cable for specific portable jump starter models. It features a standard 2-prong AC plug for wall outlets and a compatible connector for your power pack's AC input port.



Image 1: The saschedross 2-Prong AC Charging Cord. This image displays the black power cord, coiled and secured, with both the 2-prong wall plug and the device-side connector visible.

2.1 Compatibility

This charging cord is compatible with the following CEN-TECH portable power pack jump starter models:

- Cen-Tech NP7UA170C1 CenTech 3-IN-1 Portable Power Pack Jump Starter
- Cen-Tech NP7UA182C1 CenTech 4-in-1 Portable Power Pack Jump Starter

Note: This is an AC power cord ONLY. It is designed to provide power to the jump starter's internal charging circuit.

3. Setup

Follow these steps to connect the charging cord to your CEN-TECH portable power pack:

1. **Locate the AC Input Port:** Identify the AC input port on your CEN-TECH portable power pack. Refer to your power

pack's manual if you are unsure of its location.

2. **Connect the Cord to the Power Pack:** Insert the device-side connector of the saschedross 2-Prong AC Charging Cord firmly into the AC input port of your power pack.
3. **Connect to a Power Outlet:** Plug the 2-prong end of the charging cord into a standard 120V AC wall outlet.

Ensure all connections are secure before proceeding.

4. Operating Instructions

Once the charging cord is connected as described in the 'Setup' section, your CEN-TECH portable power pack should begin charging. The charging indicator on your power pack (if equipped) will typically illuminate or change status to indicate that charging is in progress.

- Allow the power pack to charge for the duration recommended in its original instruction manual.
- Do not overcharge the power pack beyond the manufacturer's recommendations.
- Disconnect the charging cord from the wall outlet and the power pack once charging is complete.

5. Maintenance

Proper care of your charging cord will ensure its longevity and safe operation:

- **Storage:** Store the cord in a cool, dry place away from direct sunlight and moisture when not in use. Avoid tightly coiling or bending the cord sharply.
- **Cleaning:** Wipe the cord with a dry, soft cloth if it becomes dirty. Do not use liquid cleaners or immerse the cord in water.
- **Inspection:** Periodically inspect the cord for any signs of damage, such as cuts, frayed insulation, or bent prongs. If damage is found, discontinue use immediately and replace the cord.

6. Troubleshooting

If your CEN-TECH portable power pack is not charging when connected with this cord, consider the following:

- **Verify Cord Connection:** Ensure the charging cord is securely plugged into both the wall outlet and the power pack's AC input port.
- **Check Wall Outlet:** Test the wall outlet with another device to confirm it is supplying power.
- **Power Pack Battery Condition:** Rechargeable batteries have a limited lifespan, typically 1 to 3 years. If your power pack's battery is old or depleted beyond recovery, it may not accept a charge, regardless of the charging cord's functionality. If your jump starter has been in use for several years, it is advisable to verify its proper operation before assuming the charging cable is at fault.
- **Cord Damage:** Inspect the charging cord for any visible damage. A damaged cord should not be used.

Note: This cord is an AC input power cord only. If your power pack fails to charge, the issue is often related to the internal rechargeable battery aging rather than the charging cable itself.

7. Specifications

Feature	Detail

Feature	Detail
Brand	saschedross
Model Number	dsf03020084
Color	Black
Connector Gender	Male-to-Male
Voltage	12 Volts (for compatible device input)
Plug Format	Type B (US Standard)
Plug Type	Type B (US Standard)
Number Of Conductors	2
Power Cord Prong Count	2
Number of Outlets	1 (for device connection)
Special Features	Portable
Water Resistance Level	Not Water Resistant
UL Listed	No

8. Important Safety Information

- Use this cord only with compatible CEN-TECH portable power pack jump starters as specified.
- Do not use the cord if it is damaged, frayed, or has exposed wires.
- Do not modify the cord or its connectors.
- Keep the cord away from water, heat sources, and sharp objects.
- Always grasp the plug, not the cord, when disconnecting from an outlet or device.
- This cord is for indoor use only.

© 2023 saschedross. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09TRRZZCQ

More documents and user manuals: **https://manuals.plus/**