Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Generisch 11033896

Generisch Dishwasher Water Inlet Valve 11033896 Instruction Manual

Model: 11033896

Introduction

This manual provides essential information for the installation, operation, maintenance, and troubleshooting of the Generisch 11033896 dishwasher water inlet valve. This component is a compatible replacement part designed for various Bosch, Siemens, and Neff integrated dishwashers. Please read these instructions carefully before proceeding with installation or any maintenance to ensure safe and correct usage.

Safety Information

Warning: Always disconnect power to the dishwasher and turn off the water supply before attempting any installation or maintenance. Failure to do so can result in electric shock, water damage, or personal injury. If you are unsure about any step, consult a qualified technician.

- Ensure all connections are secure and watertight to prevent leaks.
- Use appropriate tools for installation.
- Keep children and pets away from the work area.

Installation Instructions

The water inlet valve controls the flow of water into your dishwasher. Replacing this part typically involves accessing the underside or back of the dishwasher.

1. **Preparation:**
    - Disconnect the dishwasher from the electrical power supply.
    - Turn off the main water supply valve to the dishwasher.
    - Place towels or a shallow pan under the dishwasher to catch any residual water.
2. **Access the Valve:**
    - Carefully pull the dishwasher out from its cabinet enclosure.
    - Depending on your dishwasher model, you may need to remove the lower access panel or tilt the dishwasher backward to access the valve located at the bottom.

3. **Disconnect Old Valve:**
    - Disconnect the electrical wiring harness from the old valve. Note the orientation if necessary.
    - Unscrew the water inlet hose from the valve.
    - Remove any mounting screws or clips securing the valve to the dishwasher frame.
    - Carefully detach the internal water hose(s) from the valve.
4. **Install New Valve:**
    - Attach the internal water hose(s) to the new Generisch 11033896 valve, ensuring a secure fit.
    - Mount the new valve to the dishwasher frame using the original screws or clips.
    - Connect the water inlet hose to the new valve. Hand-tighten first, then use a wrench for a snug fit, but do not overtighten.
    - Connect the electrical wiring harness to the new valve. Ensure it clicks into place.
5. **Final Steps:**
    - Carefully slide the dishwasher back into its enclosure.
    - Turn on the main water supply valve. Check for any leaks around the new valve and hose connections.
    - Reconnect the dishwasher to the electrical power supply.
    - Run a short test cycle to ensure proper operation and check for leaks again.



Figure 1: Front view of the Generisch 11033896 water inlet valve. This image shows the overall structure of the valve, including the red plunger and blue electrical connector.





Figure 2: Angled view of the Generisch 11033896 water inlet valve. This perspective highlights the side profile and the connection points.

Operation

The Generisch 11033896 water inlet valve operates automatically as part of your dishwasher's wash cycle. When the dishwasher requires water, the control board sends an electrical signal to the valve. This signal energizes a solenoid within the valve, which opens a plunger, allowing water to flow from your home's water supply into the dishwasher tub. Once the required water level is reached, the signal is removed, the solenoid de-energizes, and the plunger closes, stopping the water flow.



Figure 3: Top-down view of the Generisch 11033896 water inlet valve. This view emphasizes the red plunger mechanism.

Maintenance

The Generisch 11033896 water inlet valve is designed for durability and typically requires minimal maintenance. However, regular checks can help ensure its longevity and proper function:

- **Leak Inspection:** Periodically check the water inlet hose connection to the valve for any signs of leaks. Tighten connections if necessary, but avoid overtightening.
- **Filter Screen:** Some water inlet valves include a small filter screen at the water inlet connection to prevent debris from entering the valve. If your dishwasher experiences issues with filling, check this screen for clogs and clean it if needed. Ensure the water supply is off before checking.
- **General Cleanliness:** Keep the area around the valve free from dust and debris.

Troubleshooting

If your dishwasher is experiencing water-related issues after valve replacement, consider the following common troubleshooting steps:

Problem	Possible Cause	Solution
Dishwasher not filling with water	Water supply valve closed Kinked water inlet hose Clogged filter screen in valve Faulty electrical connection to valve	Ensure water supply is fully open. Straighten the water inlet hose. Turn off water, disconnect hose, clean filter screen. Check electrical harness for secure connection.
Dishwasher continuously fills with water (overflows)	Faulty water inlet valve (stuck open) Float switch issue (less common after valve replacement)	Disconnect power and water immediately. The valve may need replacement if it's new and faulty, or if the old one was stuck. Consult dishwasher's main manual for float switch troubleshooting.
Water leaks around valve connections	Loose hose connection Damaged O-ring or washer Cracked valve housing	Turn off water, tighten connections. Inspect and replace O-rings/washers if damaged. If valve housing is cracked, the valve needs replacement.






Figure 4: Bottom view of the Generisch 11033896 water inlet valve. This image shows the base and mounting points.




Figure 5: Detailed view of the electrical connector on the Generisch 11033896 water inlet valve. This shows the blue connector and metal pins.

Specifications

Feature	Detail
Brand	Generisch
Model Number	11033896
ASIN	B09TT6VR7M
Manufacturer	Onbekant

Feature	Detail
Material	Stainless Steel (internal components/housing)
Color	Stainless Steel (referring to the dishwasher, valve itself is white/blue/red)
Installation Type	Integrated
Recommended Uses	Dishwasher repair for dishes, glassware, pots, pans, and daily utensils.
Included Components	Dishwasher valve (unit count: 1)
Compatible Brands	Bosch, Constructa, Neff, Siemens

Warranty and Support

For warranty information or technical support regarding the Generisch 11033896 water inlet valve, please refer to the retailer or manufacturer's official website where the product was purchased. Keep your proof of purchase for any warranty claims.

© 2023 Generisch. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09TT6VR7M

More documents and user manuals: **https://manuals.plus/**