Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete Ariete 1500 Watt Food Processor

Ariete 1500 Watt Food Processor Instruction Manual

Model: Ariete 1500 Watt Food Processor

Product Overview

The Ariete 1500 Watt Food Processor is a versatile kitchen appliance designed for various food preparation tasks including chopping, blending, grating, slicing, juicing, and kneading. Its powerful 1500 Watt motor ensures efficient performance for all your culinary needs.



Image: The Ariete RoboMax Food Processor, showcasing the main motor unit, the large blender jug (1.75L max), and the food processor bowl (2.1L max chopper capacity). The control knob and Ariete branding are visible on the base unit.

Key Features:

- **Power:** 1500 Watt motor for robust performance.
- **Capacity:** 1.75L blender jug and 2.1L chopper bowl.
- **Versatility:** Includes attachments for grating, mixing, kneading, citrus juicing, slicing, and potato cutting.
- **Safety:** Equipped with a safety lock mechanism.
- **Material:** Durable plastic construction.

Setup and Assembly

1. Unpacking

1. Carefully remove all components from the packaging.
2. Check for any damage during transit. If any damage is found, do not use the appliance and contact customer support.
3. Retain the packaging for future storage or transport.

2. Component Identification

Familiarize yourself with the various parts of your Ariete Food Processor:

- Main Motor Unit (Base)
- Food Processor Bowl (approx. 2.1L chopper capacity)
- Blender Jug (1.75L max capacity)
- Lid for Food Processor Bowl
- Lid for Blender Jug
- Pusher/Feeder Tube
- S-blade for chopping and mincing
- Dough blade for kneading
- Grater attachment
- Slicing disc (with 3 blades for slicing)
- Citrus juicer attachment
- Potato cutter attachment

3. Initial Cleaning

Before first use, clean all detachable parts that will come into contact with food. Refer to the "Maintenance and Cleaning" section for detailed instructions. The main motor unit should only be wiped with a damp cloth.

4. Assembly

Ensure the appliance is unplugged before assembly.

- **For Food Processor Use:** Place the food processor bowl onto the motor unit, aligning the arrows and twisting clockwise until it locks into place. Insert the desired blade or disc onto the central shaft. Secure the lid onto the bowl, ensuring the safety lock mechanism engages.
- **For Blender Use:** Place the blender jug onto the motor unit, aligning the base of the jug with the motor unit and twisting clockwise until it locks. Secure the blender lid.
- Always ensure all parts are correctly assembled and locked before plugging in the appliance.

Operating Instructions

Always ensure the appliance is on a stable, flat surface and plugged into a suitable power outlet.

Control Dial:

- **"0" (Off):** The appliance is off.
- **"P" (Pulse):** Provides short bursts of maximum power. Ideal for quick chopping or blending. Release the dial to return to "0".
- **Speed Settings (dots):** Rotate the dial clockwise to select continuous speed settings from low to high, indicated by the dots.

Using the Food Processor:

1. Assemble the food processor bowl, desired blade (e.g., S-blade for chopping, dough blade for kneading) or disc (for slicing/grating), and lid as described in the "Setup and Assembly" section.
2. Add ingredients to the bowl. Do not exceed the maximum fill line (2.1L for chopping).
3. Plug in the appliance.
4. Select the desired speed or use the "P" (Pulse) function.
5. For slicing or grating, use the pusher to guide ingredients through the feeder tube.
6. Once finished, turn the dial to "0" and unplug the appliance before disassembling.

Using the Blender:

1. Assemble the blender jug and lid onto the motor unit.
2. Add ingredients to the blender jug. Do not exceed the maximum fill line (1.75L).
3. Plug in the appliance.
4. Select the desired speed or use the "P" (Pulse) function for short bursts.
5. Once finished, turn the dial to "0" and unplug the appliance before disassembling.

Specific Attachments Usage:

- **Grater Mill:** Attach the grater accessory to the food processor bowl. Use for grating hard cheeses, nuts, or spices.
- **Dough Attachment:** Use the specialized dough blade in the food processor bowl for kneading dough. Follow recipe guidelines for liquid to flour ratios.
- **Citrus Juicer:** Place the juicer attachment on the motor unit. Press halved citrus fruits onto the reamer to extract juice.
- **Sliced Cutter / Potato Cutter:** Use the appropriate slicing disc in the food processor bowl. Feed vegetables through the chute for uniform slices or potato sticks.

Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your appliance.

General Cleaning:

1. Always unplug the appliance from the power outlet before cleaning.

2. Disassemble all removable parts.
3. **Hand Wash Only:** All detachable parts (bowls, jugs, blades, discs, lids) should be washed by hand using warm, soapy water. Rinse thoroughly and dry immediately.
4. ***Do NOT wash any parts in a dishwasher.*** This appliance is not dishwasher safe.
5. Wipe the main motor unit with a damp cloth. Never immerse the motor unit in water or any other liquid.
6. Be extremely careful when handling sharp blades and discs.

Storage:

Store the appliance and its accessories in a clean, dry place, away from direct sunlight and out of reach of children.

Troubleshooting

If you encounter issues with your food processor, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; Safety lock not engaged; Power outage.	Ensure plug is securely in outlet; Check that bowl/jug and lid are correctly assembled and locked; Check household fuse/circuit breaker.
Motor stops during operation.	Overload protection activated; Ingredients too large/hard.	Unplug, remove some ingredients, let motor cool down for 15-20 minutes before restarting; Cut ingredients into smaller pieces.
Loud noise or vibration.	Improper assembly; Unstable surface.	Ensure all parts are correctly assembled and locked; Place appliance on a stable, flat surface.
Food not processed evenly.	Too much food; Incorrect speed; Dull blade.	Process in smaller batches; Adjust speed setting; Inspect blade for sharpness (replace if dull).

If the problem persists after trying these solutions, please contact customer support.

Specifications

- **Brand:** Ariete
- **Model Name:** Ariete 1500 Watt Food Processor
- **Power/Wattage:** 1500 watts
- **Material:** Plastic
- **Color:** Ice
- **Item Weight:** 2 Kilograms
- **Package Dimensions:** 10 x 8 x 7 cm
- **Special Features:** Safety Lock
- **Recommended Uses:** Grating, Slicing, Juicing
- **Product Care Instructions:** Hand Wash (Not dishwasher safe)
- **Included Components:** Main unit, Food Processor Bowl, Blender Jug, Lids, S-blade, Dough blade, Grater attachment, Slicing disc, Citrus juicer, Potato cutter.

- **ASIN:** B09TTQDJMG
- **Date First Available:** 17 February 2022

Warranty and Support

Warranty Information:

Specific warranty terms and conditions for the Ariete 1500 Watt Food Processor may vary by region and retailer. Please refer to the warranty card included with your product or consult the point of purchase for detailed warranty information. Keep your proof of purchase for warranty claims.

Customer Support:

For technical assistance, spare parts, or service inquiries, please contact Ariete customer support or your local authorized service center. Contact details can typically be found on the manufacturer's official website or on the product packaging.

Note: Do not attempt to repair the appliance yourself. Unauthorized repairs will void the warranty and may pose safety risks.

© 2024 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09TTQDJMG

More documents and user manuals: **https://manuals.plus/**