GYMAX GYHW67660

GYMAX 3-in-1 Kids Storage Bench Instruction Manual

Model: GYHW67660

1. Introduction

Thank you for choosing the GYMAX 3-in-1 Kids Storage Bench. This versatile furniture piece is designed to adapt to your child's needs, functioning as a comfortable seating bench, a practical toy storage box, and a functional table and chair set. This manual provides essential information for assembly, safe operation, and maintenance to ensure long-lasting use and enjoyment.

2. Product Features

The GYMAX 3-in-1 Kids Storage Bench offers multiple functionalities and thoughtful design elements:

- **3-in-1 Convertible Design:** Easily transforms from a bench to a table with a chair, and includes integrated storage.
- **Integrated Storage:** A spacious compartment under the seat provides convenient storage for toys, books, and other items.
- **Safety Hinge:** Equipped with a safety pneumatic rod to ensure the lid closes gently and prevents accidental slamming, protecting small fingers.
- **Durable Construction:** Made from high-quality MDF with a natural oak finish for stability and longevity.
- **Child-Friendly Design:** Features rounded corners and edges for enhanced safety.
- **Easy to Clean:** The smooth surface allows for simple wiping and maintenance.



Image 2.1: The GYMAX 3-in-1 Kids Storage Bench, showcasing its primary bench configuration and its convertible table and chair setup.



Image 2.2: A child utilizing the bench in its table and chair configuration for play or study.



Image 2.3: Visual representation of the product's three versatile functions.



Image 2.4: Detailed view of key features including safety mechanisms and design elements.

3. Safety Information

Please read and adhere to the following safety guidelines to ensure the well-being of your child and the longevity of the

product:

- Always supervise children when they are using the bench or table.
- Ensure all screws and fasteners are securely tightened during assembly and checked periodically.
- Do not exceed the recommended weight capacities: Tabletop Weight Capacity: 10 kg, Seat Weight Capacity: 30 kg.
- Keep small parts away from young children during assembly to prevent choking hazards.
- The safety hinge is designed to prevent sudden lid closure; however, always guide the lid when opening or closing.
- Avoid placing hot liquids or heavy objects on the tabletop.
- Do not allow children to climb on the product.

4. Package Contents

Upon opening the package, please verify that all components are present and undamaged. The package should contain:

- 1 x GYMAX 3-in-1 Kids Storage Bench (Table & Chair Set)
- 1 x Instruction Manual
- All necessary hardware for assembly (screws, dowels, etc.)

If any parts are missing or damaged, please contact customer support immediately.

5. Setup and Assembly Instructions

Assembly of the GYMAX 3-in-1 Kids Storage Bench is required. Please follow the detailed step-by-step instructions provided in the separate assembly guide included in your package. Ensure you have all tools listed in the assembly guide before beginning. It is recommended to assemble the product on a soft, clean surface to prevent scratches.
Key Assembly Tips:

- Identify all parts using the provided labels (letters/numbers).
- Do not overtighten screws during initial assembly; tighten fully once all components are in place.
- Pay close attention to the orientation of each piece as indicated in the diagrams.
- If you encounter any difficulties, refer to the troubleshooting section or contact customer support.

6. Operating Instructions: Converting the Bench

The GYMAX 3-in-1 Kids Storage Bench is designed for easy conversion between its different modes:

6.1. Converting to a Table and Chair Set:

1. Ensure the storage lid is fully closed.
2. Locate the adjustable mechanism (knob) on the side of the bench.
3. Rotate the knob to release the locking mechanism that holds the backrest in place.
4. Gently pivot the backrest forward and down. The backrest will become the tabletop, and the armrests will form the table legs.
5. Adjust the position until the tabletop is stable and level. The storage box then serves as the chair.
6. Ensure the adjustable mechanism is securely tightened to lock the table in position.

6.2. Converting to a Seating Bench:

1. If in table mode, loosen the adjustable knob.
2. Gently lift the tabletop (which was the backrest) upwards and backward until it forms the backrest of the bench.
3. Secure the adjustable mechanism by rotating the knob to lock the backrest in its upright position.

6.3. Accessing the Storage Box:

1. In bench mode, lift the seat panel upwards. The safety pneumatic rod will assist in holding the lid open.
2. To close, gently push the lid down. The safety hinge will ensure a slow, controlled descent.



Image 6.1: Visual guide for converting the bench between its different configurations.



Image 6.2: The storage compartment in use, demonstrating its capacity for various items.

7. Maintenance

Regular maintenance will help preserve the appearance and functionality of your GYMAX 3-in-1 Kids Storage Bench:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood finish.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Retighten as necessary.
- **Environmental Conditions:** Avoid exposing the furniture to extreme temperatures, direct sunlight, or high humidity, which can cause warping or fading.

8. Troubleshooting

If you encounter any issues with your GYMAX 3-in-1 Kids Storage Bench, consider the following common solutions:

- **Difficulty in Conversion:** Ensure all locking mechanisms (e.g., adjustable knob) are fully disengaged before attempting to convert. Check for any obstructions.
- **Wobbly Structure:** Verify that all assembly screws are securely tightened. If the issue persists, disassemble and reassemble, ensuring all parts are correctly aligned.
- **Lid Not Closing Smoothly:** Check the safety pneumatic rod for any damage or misalignment. Ensure no items are obstructing the closing path of the lid.
- **Missing or Damaged Parts:** Do not attempt to use the product with missing or damaged parts. Contact customer support for replacements.

9. Specifications

Attribute	Detail
Brand	GYMAX
Model Number	GYHW67660
Material	MDF
Color	Natural (Oak finish)
Chair Size (L x W x H)	60 x 43 x 57 cm
Table Size (L x W x H)	60 x 68 x 43 cm
Box Inner Size (L x W x H)	54 x 30 x 20 cm
Applicable Age	3-7 years old
Tabletop Weight Capacity	10 kg
Seat Weight Capacity	30 kg
Net Weight	9.5 kg



Image 9.1: Dimensional specifications for the product in its various forms.



Image 9.2: Summary of product specifications.

10. Warranty and Support

For warranty information, product support, or to report missing/damaged parts, please refer to the contact details provided with your purchase documentation or visit the official GYMAX website. Please retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question