Ufesa AF5100

Ufesa AF5100 Phantom 5L Smart Air Fryer Instruction Manual

Model: AF5100 | Brand: Ufesa

Introduction

This manual provides essential information for the safe and efficient operation of your Ufesa AF5100 Phantom 5L Smart Air Fryer. Please read it thoroughly before first use and keep it for future reference.

The Ufesa AF5100 Phantom is a 5-liter capacity air fryer designed for healthy cooking with minimal added oil. It features 1500W of power, 360° high-speed air circulation technology, a digital touch control panel, and Wi-Fi connectivity for smart control via the Ufesa Connect app. With 8 preset programs, it simplifies meal preparation for 3 to 6 servings.



Image: Ufesa AF5100 Phantom 5L Smart Air Fryer, white model.

Safety Instructions

- Always place the appliance on a stable, heat-resistant surface.
- Do not immerse the main unit in water or any other liquid.
- Ensure the voltage indicated on the appliance matches your local mains voltage before connecting.
- Keep children and pets away from the appliance during operation.
- Do not block the air inlet and outlet openings.
- Unplug the appliance when not in use and before cleaning.
- The basket and tray feature a cool-touch handle for safe handling.

Setup

1. Unpacking

Carefully remove all packaging materials, stickers, and labels from the air fryer. Ensure all components are present: main unit, cooking basket, and non-stick tray.

2. Initial Cleaning

Before first use, clean the cooking basket and non-stick tray with hot water, dish soap, and a non-abrasive sponge. Rinse thoroughly and dry completely. Wipe the exterior of the appliance with a damp cloth.

3. Placement

Place the air fryer on a stable, horizontal, and heat-resistant surface. Ensure there is at least 10 cm of free space on the back and sides, and 10 cm above the appliance to allow for proper air circulation.

4. App Connection (Ufesa Connect)

To utilize the smart features, download the Ufesa Connect app from your smartphone's app store. Follow the in-app instructions to connect your air fryer to your home Wi-Fi network. This allows for remote control of time, temperature, and access to a recipe book.



Image: Smartphone displaying the Ufesa Connect app interface for remote control.

Your browser does not support the video tag.

Video: Demonstration of controlling an air fryer via a mobile application, showcasing remote temperature and time adjustments. This video illustrates the Wi-Fi control feature of the Ufesa AF5100 Phantom.

Operating Instructions

1. Power On/Off

Plug the appliance into a grounded wall socket. Press the power button on the digital touch panel to turn the air fryer on or off.

2. Digital Touch Control

The large digital touch screen allows intuitive control:

- **Temperature Adjustment:** Use the temperature control buttons to set the desired cooking temperature from 80°C to 200°C.

- **Time Adjustment:** Use the timer control buttons to set the cooking time, up to 60 minutes.
- **8 Preset Programs:** Select from predefined programs for common dishes like fries, meat, fish, chicken, baking, pizza, vegetables, and shrimp. Each program has optimized time and temperature settings.



Image: Close-up of the digital touch control panel, showing temperature and time settings.



Image: Icons representing the 8 preset cooking programs available on the air fryer.

3. Cooking Process

1. **Prepare Food:** Place your ingredients in the cooking basket. For best results, do not overfill.
2. **Insert Basket:** Slide the cooking basket back into the air fryer until it clicks into place.
3. **Set Settings:** Select a preset program or manually set the desired temperature and time.
4. **Start Cooking:** Press the start button. The air fryer will begin the cooking cycle.
5. **Shake/Turn Food:** For even cooking, especially for items like fries or chicken, pull out the basket halfway through the cooking time and gently shake or turn the food. Then, reinsert the basket.
6. **Completion:** The air fryer will beep when the cooking time is complete. Carefully pull out the basket and remove the food.

Your browser does not support the video tag.

Video: A short preview demonstrating the general use and cooking capabilities of an air fryer, including placing food and operating the device. This video provides a visual overview of air frying.

Maintenance

1. Cleaning

- Always unplug the air fryer and allow it to cool completely before cleaning.
- The non-stick cooking basket and tray are removable and dishwasher safe for easy cleaning.
- Wipe the exterior of the appliance with a damp cloth. Do not use abrasive cleaning agents or scouring pads.
- Clean the interior of the appliance with a non-abrasive sponge and warm soapy water if necessary.

Image: Illustration of the easy-to-clean non-stick basket and tray.

2. Storage

Ensure the appliance is clean and dry before storing. Store it in a cool, dry place, preferably in its original packaging or a protective cover.

Troubleshooting

- **Appliance not turning on:** Check if the power cord is securely plugged into a working outlet.
- **Food not crispy:** Ensure the basket is not overloaded. Shake or turn food halfway through cooking. Increase cooking time or temperature slightly if needed.
- **White smoke from appliance:** This may indicate fat residue from previous use. Clean the basket and tray thoroughly.
- **App connectivity issues:** Ensure your Wi-Fi network is stable and the air fryer is within range. Refer to the Ufesa Connect app's troubleshooting guide.

Specifications

Feature	Specification
Model Name	Phantom
Model Number	AF5100
Capacity	5 Liters
Power	1500 Watts
Voltage	220 Volts
Temperature Range	80°C to 200°C
Control Method	Application, Touch
Dimensions (D x W x H)	34.5 x 26 x 33 cm
Weight	8 Kilograms
Material	Plastic
Non-stick Coating	Yes
Dishwasher Safe Parts	Yes (Basket and Tray)
Special Function	Programmable, Wi-Fi

Warranty and Support

Warranty Information

This Ufesa AF5100 Phantom Air Fryer comes with a**3-year warranty**. Please retain your proof of purchase for any

warranty claims. The warranty covers manufacturing defects under normal use conditions.

Customer Support

For further assistance, troubleshooting, or to inquire about spare parts, please visit the official Ufesa website or contact their customer service department. Contact details can typically be found in the packaging or on the manufacturer's website.

© 2024 Ufesa. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question