Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fly Bold WINB-000075

Fly Bold 32-Inch Sensory Bubble Tube Lamp

Model: WINB-000075

1. Introduction

Thank you for choosing the Fly Bold 32-Inch Sensory Bubble Tube Lamp. This product is designed to provide a calming and visually stimulating experience with its hypnotic movement of floating fish and vibrant color-changing LED lights. It is suitable for various environments, including children's rooms, sensory spaces, or any area where a tranquil ambiance is desired.

This manual contains important information regarding the safe setup, operation, and maintenance of your bubble tube lamp. Please read it thoroughly before use and retain it for future reference.



Image: The Fly Bold Bubble Tube Lamp features a sleek and minimalistic design, suitable for various room decors.

2. Safety Information

- Always place the lamp on a stable, flat surface to prevent tipping.
- Keep the lamp away from direct sunlight, heat sources, and extreme temperatures.
- Ensure the power cord is not pinched, twisted, or placed under heavy objects.
- Do not immerse the electrical components in water.
- Use only the provided power adapter.
- Keep out of reach of small children and pets to prevent accidental spills or damage.
- Unplug the lamp from the power outlet before cleaning or performing any maintenance.
- If the lamp is damaged or malfunctions, discontinue use immediately and contact customer support.

3. Package Contents

Verify that all items are present in the package:

- 1 x Fly Bold 32-Inch Bubble Tube Lamp
- 6 x Artificial Fish
- 1 x Remote Control
- 1 x Power Adapter (Charger)



Image: The package includes the bubble tube lamp, complementary artificial fish, a remote control for color and effect selection, and a power adapter.

4. Setup Instructions

Setting up your Fly Bold Bubble Tube Lamp is quick and easy, typically taking less than 5 minutes.

1. **Fill with Water:** Carefully fill the bubble tube with distilled water up to the 'MAX' line indicated on the tube. Avoid overfilling.
2. **Add Fish:** Gently place the artificial fish into the water.

3. **Connect Power:** Connect the power adapter to the lamp's power input and then plug it into a standard electrical outlet. The lamp should power on automatically.



Image: Visual guide for easy setup: 1. Pour water into the tube. 2. Fill to the MAX line. 3. Add artificial fish. 4. Ensure fish are submerged.

5. Operating Instructions

Your bubble tube lamp comes with a remote control to manage its lighting and bubble functions.

- **Power On/Off:** Use the power button on the remote to turn the lamp on or off.
- **Change Colors:** The remote allows you to select from 7 vibrant color options. Press the color buttons to cycle through or select a specific color.
- **Adjust Effects:** The remote may also offer different lighting effects (e.g., fade, flash, strobe). Refer to the remote's specific buttons for these functions.
- **Bubble Control:** The bubbles are typically activated when the lamp is on. Some remotes may have a dedicated button to adjust bubble intensity or turn them off.



Image: The remote control allows you to choose from various light colors and effects, creating a personalized sensory experience.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your bubble tube lamp.

- **Cleaning:** Wipe the exterior of the lamp with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Water Replacement:** It is recommended to replace the water every 3-6 months, or sooner if the water appears cloudy. Use distilled water to prevent mineral buildup.
- **Dusting:** Periodically dust the lamp and its base to maintain clarity and appearance.

7. Troubleshooting

If you encounter any issues, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Lamp does not turn on	No power, loose connection, faulty adapter	Check power outlet, ensure adapter is securely plugged in, try a different outlet.
No bubbles	Water level too low/high, air pump issue	Adjust water level to 'MAX' line. Ensure the lamp is on.
Remote control not working	Dead battery, obstruction, out of range	Replace remote battery. Ensure no objects block the signal. Point remote directly at the lamp.
Water appears cloudy	Mineral buildup, algae growth	Replace water with fresh distilled water. Clean the inside of the tube if accessible.

8. Specifications

Feature	Detail
Model Number	WINB-000075
Brand	Fly Bold
Height	32 inches
Material	Acrylonitrile Butadiene Styrene
Light Source	LED
Color Options	7 Colors (Remote Controlled)
Control Method	Remote Control
Power Source	Corded Electric
Item Weight	3.25 Pounds
Mounting Type	Freestanding
ASIN	B09V338WGJ

9. Warranty

This product is covered by a standard manufacturer's warranty against defects in materials and workmanship. Please retain your proof of purchase for any warranty claims. For specific warranty terms and conditions, refer to the product packaging or contact the retailer.

10. Support

If you require further assistance or have questions not covered in this manual, please contact your retailer or the manufacturer's customer support. Have your model number (WINB-000075) and purchase information ready when contacting support.

© 2023 Fly Bold. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

After changing the water and letting the fish sit overnight in the Fly Bold 32-Inch Sensory Bubble Tube Lamp, how long does it take for the fish to start moving when the lamp is turned on?

When you turn on the Fly Bold 32-Inch Sensory Bubble Tube Lamp, the fish should begin moving almost immediately as the air pump generates bubbles. The bubbles provide the lift and turbulence necessary to...

Read full answer

Open the live page

https://manuals.plus/asin/B09V338WGJ

More documents and user manuals: **https://manuals.plus/**