Powell 2a0ab961-5098-42e1-89f1-97dde8442aee

Powell Bina Rattan Cane Folding Dining Side Chair User Manual

Model: D1293D19 / 2a0ab961-5098-42e1-89f1-97dde8442aee

Product Overview

The Powell Bina Rattan Cane Folding Dining Side Chair is designed for versatile use in dining rooms, kitchens, guest bedrooms, or living rooms. It features a real woven rattan cane back and a padded beige linen fabric upholstered seat. The unique metal folding mechanism allows for compact storage when not in use.



Figure 1: Front view of the Powell Bina Rattan Cane Folding Dining Side Chair in its unfolded state.

Safety Information

Please read and understand all safety warnings before using this product. Failure to follow these instructions may result in injury or damage.

- **Maximum Weight Capacity:** Do not exceed the maximum weight capacity of the chair to ensure safe use.
- **Adult Handling:** This product requires adult handling.

- **Children Safety:** Keep children away from the folding chair when it is being unfolded or folded to prevent potential injuries from moving parts.
- **Stable Surface:** Always place the chair on a flat, stable, and level surface to prevent tipping.
- **Inspection:** Periodically inspect all parts for wear or damage. Do not use the chair if any components are compromised.

Setup

The Powell Bina Rattan Cane Folding Dining Side Chair comes pre-assembled and does not require additional assembly. To set up the chair for use, simply unfold it.

1. **Unfolding the Chair:**

   Hold the chair by the top of the backrest and the front edge of the seat. Gently pull the seat downwards and forwards until the metal folding mechanism locks into place, ensuring the chair legs are fully extended and stable.



Figure 2: The chair's metal folding mechanism, shown partially unfolded.

2. **Verifying Stability:**

   Before sitting, gently press down on the seat and rock the chair slightly to confirm it is fully open and stable on all four legs.

Operating Instructions

Using the Chair

Once unfolded and stable, the chair is ready for use as a dining chair, extra seating, or for other suitable purposes. Ensure the chair is placed on a hard, level surface for optimal stability.

Folding the Chair for Storage

1. **Initiate Folding:**

   Locate the metal folding mechanism beneath the seat. Gently lift the seat upwards while simultaneously pushing the back legs slightly inwards. The mechanism will disengage, allowing the chair to fold.



Figure 3: One chair in its unfolded state next to another in its folded state, demonstrating compact storage.

2. **Complete Folding:**

   Continue to fold the chair until it is flat and compact. Ensure all moving parts are securely nested to prevent accidental unfolding.

Maintenance and Care

Proper care will extend the life and appearance of your chair.

- **Cleaning Fabric:** The beige linen fabric is 100% polyester and easy to clean. For spills, blot immediately with a clean, dry cloth. For general cleaning, use a mild soap solution and a damp cloth, then wipe dry. Avoid harsh chemicals.
- **Cleaning Wood and Rattan:** Wipe the wood frame and rattan cane back with a soft, damp cloth. Avoid excessive moisture. Do not use abrasive cleaners.
- **Dusting:** Regularly dust the chair with a soft, dry cloth.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading of the fabric and wood finish.
- **Mechanism Care:** The metal folding mechanism is designed for smooth operation. If it becomes stiff, a small amount of silicone-based lubricant can be applied to the pivot points, avoiding contact with wood or fabric.



Figure 4: Detailed view of the woven rattan cane back, highlighting its texture and construction.

Troubleshooting

Problem	Possible Cause	Solution
Chair feels wobbly or unstable.	Not fully unfolded; uneven surface.	Ensure the folding mechanism is fully locked. Move the chair to a flat, level surface.

Problem	Possible Cause	Solution
Folding mechanism is stiff.	Accumulation of dust/debris; lack of lubrication.	Clean the mechanism. Apply a small amount of silicone-based lubricant to pivot points.
Fabric appears stained or dirty.	Spills or general use.	Blot spills immediately. Clean with mild soap solution and damp cloth, then dry.

Specifications

Feature	Detail
Brand	Powell
Model Number	D1293D19 / 2a0ab961-5098-42e1-89f1-97dde8442aee
UPC	081438581644
Product Dimensions (Unfolded)	20.5"W x 19.75"D x 34.5"H
Seat Dimensions	19.75"W x 15.75"D x 2.38"H
Seat Height from Floor	19"
Item Weight	14.11 pounds
Color	Natural (Wood), Beige (Fabric)
Materials	Cane, Rubberwood, Foam Cushion, Metal Hardware, 100% Polyester Fabric
Assembly Required	No (Pre-assembled)
Special Feature	Foldable
Indoor/Outdoor Usage	Indoor



Figure 5: Diagram illustrating the key dimensions of the chair.

Warranty and Support

For information regarding product warranty, please refer to the original purchase documentation or contact Powell customer support directly. Keep your proof of purchase for any warranty claims.

Customer Support: For technical assistance, replacement parts, or further inquiries, please visit the official Powell website or contact their customer service department. Contact details are typically available on the manufacturer's website or included with your purchase.

Note: This manual provides general instructions. Specific warranty terms and support options may vary.

© 2023 Powell. All rights reserved.
For more information, visit www.powellcompany.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question