Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Proscenic T20

Proscenic T20 3.5L Air Fryer Instruction Manual

Model: T20 | Brand: Proscenic

1. Important Safety Instructions

Please read all instructions carefully before using the Proscenic T20 Air Fryer. Retain this manual for future reference.

- Do not immerse the appliance, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Keep the appliance out of reach of children. Close supervision is necessary when the appliance is used near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Always unplug the appliance from the outlet when not in use and before cleaning. Allow it to cool before putting on or taking off parts.
- Do not place the appliance against a wall or against other appliances. Leave at least 10 cm (4 inches) free space on the back and sides and 10 cm (4 inches) free space above the appliance.
- Do not place anything on top of the appliance.
- During hot air frying, hot steam is released through the air outlet openings. Keep your hands and face at a safe distance from the steam and from the air outlet openings.
- The surfaces may become hot during use. Do not touch hot surfaces. Use handles or knobs.
- Do not use the appliance for any purpose other than described in this manual.

2. Product Overview

2.1 Components

The Proscenic T20 Air Fryer consists of the main unit, a removable frying basket, and a crisper plate.



Image: The Proscenic T20 Air Fryer with its basket containing food, illustrating the main unit and removable components.

2.2 Control Panel

The appliance features an LED touch screen with various icons for different functions and settings.



Image: The Proscenic T20 Air Fryer showcasing its LED touch screen and overall design, with a caption indicating its 10-in-1 functionality.

- **Temperature Display:** Shows current or set temperature.
- **Time Display:** Shows remaining or set cooking time.
- **Pre-set Program Icons:** 12 dedicated icons for common dishes (e.g., fries, chicken, fish).
- **Power Button:** To turn the appliance on/off and start/pause cooking.

- **Temperature/Time Adjustment:** Buttons to increase or decrease temperature and time.

3. Setup and First Use

3.1 Unpacking

1. Remove all packaging materials from the appliance.
2. Remove any stickers or labels from the appliance.
3. Thoroughly clean the basket and crisper plate with hot water, some dishwashing liquid, and a non-abrasive sponge.
4. Wipe the inside and outside of the appliance with a moist cloth.

3.2 Placement

- Place the appliance on a stable, horizontal, and level surface.
- Do not place the appliance on non-heat-resistant surfaces.
- Ensure adequate ventilation around the appliance (at least 10 cm clearance on all sides).

3.3 First Use

It is recommended to run the air fryer empty for about 10-15 minutes on a high temperature (e.g., 180°C) during its first use to eliminate any manufacturing odors. A slight smell or smoke may occur, which is normal.

4. Operating Instructions

4.1 Basic Operation

1. Plug the main plug into a grounded wall outlet.
2. Carefully pull the basket out of the air fryer.
3. Place the ingredients in the air fryer basket. Do not exceed the MAX indication.
4. Slide the basket back into the air fryer.
5. Press the power button to turn on the appliance.
6. Select a pre-set program or manually set the temperature and time.
7. Press the power button again to start the cooking process.
8. Some ingredients require shaking halfway through the preparation time. Pull the basket out by the handle and shake it. Then slide the basket back into the air fryer.
9. When you hear the timer bell, the set preparation time has elapsed. Pull the basket out of the appliance and place it on a heat-resistant surface.
10. Check if the ingredients are ready. If not, slide the basket back in and set the timer for a few extra minutes.
11. Empty the basket into a bowl or onto a plate.

4.2 Pre-set Programs

The Proscenic T20 offers 12 one-touch pre-set programs for popular dishes. Simply select the desired program icon on the touch screen.



Image: Visual representation of the 12 pre-set cooking programs available on the Proscenic T20 Air Fryer's interface.

4.3 Manual Settings

You can manually adjust the temperature and time using the dedicated buttons on the control panel. The temperature range is typically from 80°C to 200°C, and the timer can be set up to 60 minutes.

4.4 ProscenicHome App & Recipes

Utilize the ProscenicHome app for access to numerous recipes and cooking guidance. While the T20 model does not feature Wi-Fi connectivity for app control, the app serves as a valuable resource for recipe ideas and cooking instructions.



Image: A user interacting with the ProscenicHome app on a tablet, showcasing the variety of recipes available for the air fryer.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. Unplug the appliance and allow it to cool down completely before cleaning.
2. Clean the basket and crisper plate with hot water, dishwashing liquid, and a non-abrasive sponge. The non-stick Teflon coating makes them dishwasher safe.
3. Wipe the outside of the appliance with a moist cloth. Do not use harsh abrasive cleaners or scouring pads.
4. Clean the inside of the appliance with hot water and a non-abrasive sponge.
5. Clean the heating element with a cleaning brush to remove any food residues.



Image: Illustration of the easy cleaning process for the Proscenic T20's non-stick, dishwasher-safe basket and crisper plate.

5.1 Storage

Ensure the appliance is clean and dry before storing. Store it in a cool, dry place.

6. Troubleshooting

Problem	Possible Cause	Solution
The air fryer does not work.	The appliance is not plugged in.	Plug the main plug into a grounded wall socket.
	The timer has not been set.	Set the timer to the required preparation time.
Ingredients fried in the air fryer are not cooked evenly.	The amount of ingredients in the basket is too large.	Put smaller batches of ingredients in the basket. Smaller batches are fried more evenly.
	The temperature is set too low.	Increase the temperature.
White smoke comes out of the appliance.	Fat splashes from the basket into the heating element.	Clean the basket and crisper plate thoroughly after each use.
The appliance emits a burning smell.	Food residue on the heating element.	Unplug and allow to cool. Clean the heating element.

7. Specifications

Brand	Proscenic
Model Number	8813300212-DI (T20)
Color	Black
Product Dimensions (L x W x H)	15 x 15 x 30 cm (approx. 5.9 x 5.9 x 11.8 inches)
Capacity	3.5 Liters
Power	1500 Watts
Voltage	220 Volts (AC)
Material	Stainless Steel
Item Weight	4.67 Kilograms (approx. 10.3 lbs)
Control Method	Touch



Image: Dimensional drawing of the Proscenic T20 Air Fryer, indicating its compact size.

8. Warranty and Support

Proscenic offers comprehensive support for its products.

- **Warranty:** The product typically comes with a warranty of up to 24 months. Please refer to your purchase documentation for specific warranty terms and conditions.
- **Customer Service:** Multilingual online customer support is available.
- **Repair Service:** European repair warehouses are available for service needs.
- For further assistance, please visit the official Proscenic website or contact their customer support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09VNVKMGQ

More documents and user manuals: **https://manuals.plus/**