Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beurer HC35

Beurer HC35 Compact Hair Dryer User Manual

Model: HC35 | Brand: Beurer

Introduction

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Beurer HC35 Compact Hair Dryer. Please read all instructions carefully before first use and retain this manual for future reference.

The Beurer HC35 is a compact and powerful hair dryer designed for efficient drying and styling. It incorporates ionic technology to help reduce frizz and enhance hair shine.

Important Safety Instructions

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- Always unplug the appliance immediately after use.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- This appliance is for household use only.
- An appliance should never be left unattended when plugged in.
- Close supervision is necessary when this appliance is used by, on, or near children or individuals with disabilities.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.

- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- Do not direct hot air towards eyes or other heat-sensitive areas.
- Attachments may be hot during use. Allow them to cool before handling.
- Do not place appliance on any surface while it is operating.
- While the appliance is in use, keep your hair away from the air intake openings.

Product Components



The Beurer HC35 Compact Hair Dryer with its sleek black and rose gold design.



Included items: Ionic Hair Dryer, Instruction Manual, Storage Bag, and Narrow Concentrator Nozzle.

- **Hair Dryer Unit:** The main body of the appliance.
- **Styling Nozzle:** For precise airflow during styling.
- **Storage Bag:** For convenient storage and travel.
- **Hanging Loop:** Located at the base of the handle for easy storage.
- **Removable Filter:** Located at the rear of the dryer for easy cleaning.

Setup and First Use

1. **Unpack:** Carefully remove all packaging materials and check that all components listed in the 'Product Components' section are present and undamaged.
2. **Plug In:** Insert the power plug into a suitable electrical outlet. The hair dryer features a 5.6-foot long cord.
3. **ALCI Safety Device Test:** Before each use, test the Appliance Leakage Current Interrupter (ALCI) safety device. Press the 'TEST' button on the plug. The 'RESET' button should pop up. Press the 'RESET' button to resume operation. If the ALCI does not function as described, do not use the hair dryer.

Operating Your Hair Dryer

Powering On/Off

Locate the power switch on the handle. Slide it to the 'ON' position to start the dryer and to the 'OFF' position to turn it off.

Temperature Settings



The control panel showing the temperature and speed buttons.

The HC35 offers 4 temperature settings:

- **Cold:** For setting your style and adding shine.
- **Warm:** Gentle heat for delicate hair or initial drying.
- **Very Warm:** Standard heat for general drying.
- **Very Hot:** High heat for quick drying of thick hair.

Adjust the temperature using the dedicated temperature button on the handle.

Speed Settings



The three speed indicator lights on the hair dryer.

The HC35 features 3-speed settings:

- **Low:** Gentle airflow.
- **Medium:** Moderate airflow.
- **High:** Powerful airflow for faster drying.

Adjust the speed using the dedicated speed button on the handle.

Ionic Technology



Illustration of negative ions being emitted from the hair dryer.

The Beurer HC35 utilizes negative ion technology. This technology helps to seal the hair cuticle, reducing frizz and enhancing the natural shine of your hair during the drying process.

Using Attachments



The 360-degree swivel nozzle for directional airflow.

The included narrow concentrator nozzle can be attached to the front of the dryer. It features a 360-degree swivel design, allowing you to direct the airflow precisely for targeted drying and styling.

Hair Drying Tips



Approximate drying times for short, medium, and long hair.

- Begin with damp hair.

- Choose your preferred heat setting.
- Begin drying hair in sections, applying heat from the roots down.
- Use the cold air function between drying sections for added shine.
- Approximate drying times: Short hair (1-3 minutes), Medium length hair (3-5 minutes), Long hair (5-8 minutes).

Care and Maintenance

Cleaning the Filter



The removable filter at the rear of the hair dryer.

Regular cleaning of the air inlet filter is essential for optimal performance and longevity of your hair dryer. The filter is removable for easy cleaning.

- Ensure the hair dryer is unplugged and completely cool before cleaning.
- Gently twist or pull off the rear filter cover.
- Remove any accumulated lint, dust, or hair from the filter using a soft brush or cloth.
- Replace the filter cover securely.

Storage



The hair dryer stored in its included travel bag.



Close-up of the hanging loop at the base of the handle.

When not in use, store your hair dryer in a cool, dry place. The included storage bag provides protection, and the integrated hanging loop allows for convenient storage.

Troubleshooting Guide

If you experience issues with your Beurer HC35 Hair Dryer, please refer to the following common solutions:

Problem	Possible Cause / Solution
Hair dryer stops working or overheats.	The hair dryer may have an automatic overheat protection feature. Unplug the unit and allow it to cool down for several minutes. Ensure the air inlet guard and concentrator nozzle are clean and free of obstructions (refer to Section 5 of the instruction manual for cleaning).
Hair dryer does not turn on.	Check if the ALCI safety device on the plug has tripped. Press the 'RESET' button on the plug (refer to Section 1 of the instruction manual for testing the ALCI device). Ensure the power cord is securely plugged into a working outlet.
Reduced airflow or performance.	The air inlet filter may be clogged with lint or hair. Clean the removable filter as described in the 'Care and Maintenance' section.

Technical Specifications



Dimensions of the Beurer HC35 Compact Hair Dryer.

- **Model:** HC35
- **Power:** 1500 Watts
- **Voltage:** 125V
- **Material:** Ceramic
- **Color:** Black
- **Product Dimensions:** 11.3 x 5.1 x 3.3 inches
- **Weight:** Approximately 1.44 Pounds
- **Cord Length:** 5.6 feet

Warranty and Support

The Beurer HC35 Compact Hair Dryer comes with a limited lifetime warranty. For warranty claims or technical support, please contact our customer service team.

Our friendly customer service team is based in the U.S. and is available to answer any questions you may have regarding your product.

For the complete user manual in PDF format, please refer to the official document available atBeurer HC35 User Manual (PDF)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09VY6T637

More documents and user manuals: **https://manuals.plus/**