Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Oraimo OSV-102

Oraimo Cordless Vacuum Cleaner User Manual

Model: OSV-102 | Brand: Oraimo

1. Introduction and Product Overview

The Oraimo Cordless Vacuum Cleaner is a versatile 6-in-1 stick vacuum designed for efficient cleaning of various surfaces, including hard floors, carpets, and pet hair. It features two suction modes, a self-standing design for easy storage, and a detachable battery for convenient charging. This manual provides detailed instructions to help you get the most out of your vacuum cleaner.



Image: The Oraimo Cordless Vacuum Cleaner shown with its various attachments and configurations, highlighting its 6-in-1 versatility.

2. Setup and Assembly

Your Oraimo Cordless Vacuum Cleaner comes with several components that are easy to assemble. Follow these steps for initial setup:

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all included items are present: cordless stick vacuum, 4 washable HEPA filters, crevice tool, brush tool, power adapter, and accessorized storage bracket.
2. **Main Body Assembly:** Connect the extension tube to the main vacuum body until it clicks into place. Then, attach the floor brush head to the other end of the extension tube, ensuring a secure connection.

3. **Battery Installation and Initial Charge:** The 2200mAh*6 Lithium-Ion battery is detachable. Insert the battery into the main vacuum body until it clicks. For first use, fully charge the battery using the provided power adapter. The charging time is approximately 3-4 hours.
4. **Accessory Attachment:** Depending on your cleaning needs, attach the crevice tool or brush tool directly to the main vacuum body for handheld use, or to the extension tube for extended reach.



Image: The vacuum cleaner is shown in its full stick configuration, as a handheld unit with a crevice tool, and with a brush tool, demonstrating its modular assembly.



Image: A close-up view illustrating the detachable battery feature, showing how it can be removed for charging or replacement.

3. Operating Instructions

Operating your Oraimo Cordless Vacuum Cleaner is straightforward. Familiarize yourself with its features for optimal cleaning performance.

3.1 Powering On/Off and Suction Modes

- To turn on the vacuum, press the power button located on the handle. The vacuum will start in the standard suction mode.
- To switch between suction modes, press the mode button. There are two modes: **Standard** for general cleaning and extended battery life, and **Strong** for large particles and stubborn dirt.
- To turn off the vacuum, press the power button again.



Image: A user's hand operating the vacuum, with an inset showing the 'Switching Gears Button' for adjusting suction power between two speeds.

3.2 Usage Configurations

- **Stick Vacuum:** Use with the extension tube and floor brush for cleaning floors and carpets. The lightweight design makes it easy to maneuver.
- **Handheld Vacuum:** Detach the extension tube and attach the crevice or brush tool directly to the main body for cleaning furniture, car interiors, stairs, or hard-to-reach areas.



Image: A woman is shown using the Oraimo Cordless Vacuum Cleaner on a hard kitchen floor, demonstrating its ease of use for daily cleaning tasks.



Image: A woman effortlessly carries the lightweight Oraimo Cordless Vacuum Cleaner down a flight of stairs, emphasizing its portability and ease of transport between levels.

3.3 Self-Standing Feature

The vacuum cleaner is designed to be free-standing, allowing for convenient storage without the need for wall drilling or leaning against surfaces. This reduces the risk of accidental falls.



Image: The Oraimo Cordless Vacuum Cleaner stands upright on its own in a living room setting, demonstrating its self-standing capability for easy storage and accessibility.

4. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your Oraimo Cordless Vacuum Cleaner.

4.1 Emptying the Dust Cup

- The 800 mL dust cup should be emptied regularly, especially when the debris reaches the 'MAX' line.
- To empty, press the one-click release button on the dust cup and dispose of the contents into a trash bin.



Image: A hand is shown holding the vacuum's dustbin upside down, with collected debris falling out, illustrating the one-click emptying process.

4.2 Cleaning the HEPA Filters

- The vacuum includes washable and replaceable HEPA filters (4 included). It is recommended to clean the filters regularly to maintain suction power and filtration efficiency.
- Remove the filters from the dust cup. Tap off loose dirt.
- Rinse the filters under cold running water until the water runs clear. Do not use detergent.
- Allow the filters to air dry completely for at least 24 hours before reinserting them into the vacuum. Ensure they are completely dry to prevent damage and maintain performance.



Image: A hand holds a HEPA filter under a running faucet, demonstrating the process of washing the filter to remove accumulated dust and debris.

4.3 Battery Care

- Always fully charge the battery before first use.
- To extend battery life, the vacuum features a 3-second soft start.
- Store the vacuum and battery in a cool, dry place when not in use.

5. Troubleshooting

If you encounter issues with your Oraimo Cordless Vacuum Cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is not charged or not properly installed.	Ensure the battery is fully charged and securely inserted into the main body.
Low suction power	Dust cup is full; filters are clogged; blockage in the nozzle or tube.	Empty the dust cup. Clean or replace the HEPA filters. Check for and remove any blockages in the floor brush, extension tube, or main body inlet.
Short battery runtime	Battery not fully charged; using 'Strong' mode excessively; battery degradation.	Ensure battery is fully charged before use. Use 'Standard' mode for longer cleaning sessions. If battery life significantly decreases over time, consider replacing the battery.
Unusual noise during operation	Blockage in the brush roll or air pathways; damaged component.	Turn off the vacuum and check the brush roll for tangled hair or debris. Inspect all air pathways for blockages. If the noise persists, contact customer support.

6. Specifications

Below are the technical specifications for the Oraimo Cordless Vacuum Cleaner (Model OSV-102):

Feature	Specification
Brand	Oraimo
Model Name	Ultra Cleaner S (OSV-102)
Filter Type	Washable and Replaceable HEPA Filter
Cordless	Yes
Dust Cup Capacity	0.8 Liters
Wattage	160 watts
Runtime	Up to 30-35 minutes (depending on mode)
Charging Time	3-4 hours
Noise Level	70 dB
Item Weight	2.64 pounds
Product Dimensions	17.32"L x 13.39"W x 7.28"H

Feature	Specification
Battery Type	Lithium-Ion (2200mAh*6)

7. Warranty and Support

Oraimo is committed to providing professional after-sales service. For any questions, concerns, or warranty claims regarding your Oraimo Cordless Vacuum Cleaner, please contact our customer support team. Refer to the welcome guide included with your product for specific contact information or visit the official Oraimo website.
Please have your model number (OSV-102) and purchase details ready when contacting support to ensure prompt assistance.

© 2024 Oraimo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09VZKGKQ5

More documents and user manuals: **https://manuals.plus/**