Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SHIWAKOTO SHIWAKOTO HD

SHIWAKOTO HD All Region Free DVD Player User Manual

Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your SHIWAKOTO HD All Region Free DVD Player. Please read this manual thoroughly before using the product to ensure proper functionality and to maximize your viewing experience.

Package Contents

- 1 x SHIWAKOTO HD DVD Player
- 1 x Remote Control (batteries not included)
- 1 x HDMI Cable
- 1 x RCA Cable
- 1 x User Manual



Image: The SHIWAKOTO HD DVD Player, its remote, and a disc, positioned in front of a television screen.

Setup Instructions

1. Remote Control Battery Installation

Open the battery compartment on the back of the remote control. Insert two AAA batteries (not included), ensuring correct polarity (+/-). Close the compartment securely.

2. Connecting to Your TV or Display

The SHIWAKOTO HD DVD Player offers multiple connection options:

- **HDMI Connection (Recommended for 1080P Upscaling):** Connect one end of the included HDMI cable to the HDMI OUT port on the DVD player and the other end to an HDMI IN port on your TV, projector, or monitor. Select the corresponding HDMI input on your display device.
- **RCA Connection (Standard Definition):** Connect the included RCA cable (red, white, yellow) to the

corresponding color-coded ports on the DVD player (Video Out, Audio L, Audio R) and to the matching RCA IN ports on your TV or amplifier. Select the corresponding AV input on your display device.



Image: Rear view of the DVD player illustrating HDMI and RCA cable connections to various display and audio devices.

3. Power Connection

Connect the power cord to the AC IN port on the DVD player and then plug it into a standard electrical outlet.

4. Initial Power On

Press the Power button on the front panel of the DVD player or on the remote control. The power indicator light will illuminate.



Image: A SHIWAKOTO HD DVD Player integrated into a home theater system with a television and two speakers.

Operating Instructions

1. Disc Playback

- **Loading a Disc:** Gently press the OPEN/CLOSE button on the front panel or remote control to open the disc tray. Place a disc (label side up) onto the tray. Press OPEN/CLOSE again to close the tray.

- **Playing a Disc:** The player will typically begin playback automatically. If not, press the PLAY button on the remote control.
- **Stopping Playback:** Press the STOP button to halt playback. Press PLAY to resume from the last stopped point (Memory Playback feature).
- **Supported Disc Formats:** CD, DVD, DVD-R/+R, DVD-/RW, CD, CD-R/RW, VCD, SVCD. This player is region-free and supports discs from all regions (1-6). *Note: Blu-ray discs are not supported.*



Image: Visual representation of the DVD player's universal disc and region compatibility.

2. USB Input and Media Playback

Insert a USB flash drive or hard drive (up to 32GB) into the USB port on the front of the player. The player supports playback of videos, music, and photos. Supported file formats include MP3, JPEG, AVI, WMA, and more.

- **USB Copy Function:** The player supports copying CD/MP3 format files from a disc to a connected USB device. Refer to the remote control section for specific button functions.



Image: The DVD player's USB input and its capabilities for playing and copying media files.

3. 1080P Upscaling

When connected via HDMI, the player can up-convert standard definition DVD content to 1080P resolution,

enhancing picture quality for compatible displays. The resolution can be configured between 480p, 720p, and 1080p. Aspect ratios of 4:3 and 16:9 are supported.



Image: Demonstration of the DVD player's 1080P upscaling capability and adjustable picture quality settings.

4. Remote Control Functions

The included remote control provides comprehensive control over the DVD player's features:

- **Memory Playback:** Resumes playback from the last stopped point.
- **A-B Loop Playback:** Allows you to repeat a specific section of a disc.

- **Slow Playback:** Adjusts playback speed (e.g., 0.5x, 1x, 2x).
- **Subtitles:** Toggle subtitles on/off or select different subtitle tracks.
- **Angle:** Change camera angles on compatible discs.
- **Zoom:** Magnify a portion of the screen. *Note: Some users have reported the zoom icon remaining on screen; consult troubleshooting if this occurs.*
- **Setup:** Access the player's system settings menu.



Image: The remote control and its slow playback function, demonstrated with a video playing on a television.

Maintenance

1. Cleaning the Player

- Wipe the exterior of the player with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- Ensure ventilation openings are clear of dust and obstructions to prevent overheating.

2. Disc Care

- Handle discs by their edges to avoid fingerprints and scratches.
- Clean discs with a soft, lint-free cloth, wiping from the center outwards.
- Store discs in their cases away from direct sunlight and extreme temperatures.

3. General Handling

- Avoid placing heavy objects on top of the DVD player.
- Do not expose the player to moisture or excessive heat.
- The player features a sturdy metal casing for durability and heat dissipation.

Troubleshooting

Problem	Possible Cause	Solution
No power	Power cord not connected; power outlet faulty.	Ensure power cord is securely plugged into the player and a working outlet.
No picture/sound	Incorrect input selected on TV; loose HDMI/RCA cables.	Select the correct input source on your TV. Check all cable connections.
Disc not playing/freezing	Disc is dirty, scratched, or incompatible format; player malfunction.	Clean the disc. Try a different disc. Ensure the disc format is supported (not Blu-ray). If freezing persists, try unplugging and replugging the player.
Remote control not working	Batteries are dead or incorrectly inserted; obstruction between remote and player.	Replace batteries, ensuring correct polarity. Remove any obstructions. Ensure remote is pointed at the player's sensor.
Zoom icon remains on screen	Specific software behavior.	Try pressing the 'Zoom' button again or 'Display'/'Return' on the remote. If the issue persists, it may be a design characteristic.

Specifications

- **Model Name:** SHIWAKOTO HD
- **Brand:** SHIWAKOTO
- **Color:** Black
- **Product Dimensions:** 7.67 x 8.85 x 1.6 inches (19.5 x 22.5 x 4.1 cm)
- **Item Weight:** 2.2 pounds (1 kg)
- **Media Type:** CD, DVD, SVCD, VCD
- **Resolution:** 1920x1080 (1080P Upscaling)
- **Connector Type:** HDMI, RCA
- **Connectivity Technology:** HDMI, RCA, USB

- **Special Features:** Anti-Shock, Multi-Format Playback, Region Free, Surround Sound, Upscaling, Memory Playback
- **Audio Output Mode:** Surround



Image: Detailed dimensions and weight of the SHIWAKOTO HD DVD Player.

Warranty Information

The product package includes a warranty. For specific warranty terms, conditions, and duration, please refer to the

documentation provided with your purchase or contact SHIWAKOTO customer support directly. Keep your proof of purchase for warranty claims.

Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact SHIWAKOTO customer support. Refer to the contact information provided on the product packaging or the official SHIWAKOTO website for the most up-to-date support channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question