Fischer & Honsel 50422

Fischer & Honsel Eye Table Lamp Instruction Manual

Model: 50422 | Brand: Fischer & Honsel

1. Introduction

This manual provides essential information for the safe and efficient use of your Fischer & Honsel Eye Table Lamp, Model 50422. Please read these instructions carefully before assembly and operation, and retain them for future reference.

2. Safety Instructions

- Ensure the power supply is disconnected before installation, cleaning, or maintenance.
- This lamp is designed for indoor use only (IP20 rating). Do not expose to moisture or extreme temperatures.
- Use only E27 bulbs with a maximum wattage of 40W. Exceeding this limit may cause overheating and damage.
- Do not modify the lamp in any way. Any modifications will void the warranty and may pose a safety risk.
- Keep the lamp away from flammable materials.
- If the power cord is damaged, it must be replaced by a qualified electrician to avoid hazards.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. Package Contents

Verify that all components are present and undamaged before proceeding with assembly.

- Fischer & Honsel Eye Table Lamp Base (Model 50422)
- Fabric Lampshade
- Retaining Ring for Lampshade
- Power Cord with In-line Switch
- Instruction Manual



Image 1: Complete Fischer & Honsel Eye Table Lamp. The lamp features a matte silver, circular base with concentric grooves and a white cylindrical fabric lampshade.

4. Setup

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a clean, flat, and stable surface.
2. **Attach Lampshade:**
    - Unscrew the retaining ring from the lamp holder on the lamp base.
    - Place the fabric lampshade onto the lamp holder, ensuring it sits securely.
    - Screw the retaining ring back onto the lamp holder to secure the lampshade in place. Do not overtighten.
3. **Install Bulb:**
    - Ensure the lamp is unplugged from the power outlet.
    - Carefully screw an E27 bulb (max. 40W) into the lamp holder.
4. **Position Lamp:** Place the assembled lamp on a stable, level surface. Ensure the power cord is not pinched or obstructed.
5. **Connect to Power:** Plug the power cord into a suitable electrical outlet.



Image 2: Detail of the lamp base, illustrating the connection point for the power cord and the in-line switch.

5. Operating Instructions

The Fischer & Honsel Eye Table Lamp is operated using the in-line switch located on the power cord.

- **To Turn On:** Locate the in-line switch on the power cord and press the switch to the "ON" position.
- **To Turn Off:** Press the in-line switch to the "OFF" position.

6. Maintenance

- **Cleaning:**
  - Always unplug the lamp before cleaning.
  - Wipe the lamp base with a soft, dry cloth. Do not use abrasive cleaners or solvents.
  - The fabric lampshade can be gently dusted with a soft brush or a lint roller. Do not wash or immerse in water.
- **Bulb Replacement:**
  - Ensure the lamp is unplugged and the bulb has cooled down completely.
  - Carefully unscrew the old E27 bulb.
  - Screw in a new E27 bulb (max. 40W).

7. Troubleshooting

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in. Bulb is loose or faulty. Power outlet is not working. In-line switch is off.	Ensure the lamp is securely plugged into a working outlet. Check and tighten the bulb, or replace it with a new one. Test the outlet with another appliance. Ensure the in-line switch is in the "ON" position.
Flickering light.	Loose bulb connection. Faulty bulb.	Tighten the bulb. Replace the bulb.
Lampshade is unstable.	Retaining ring is loose.	Ensure the retaining ring is securely tightened onto the lamp holder.

8. Specifications

- **Model:** 50422
- **Brand:** Fischer & Honsel
- **Dimensions (L x W x H):** 34 cm x 17 cm x 53 cm (13.4 in x 6.7 in x 20.9 in)
- **Weight:** 2 Kilograms (4.4 lbs)
- **Bulb Type:** E27 (not included)
- **Max. Wattage:** 40W
- **Number of Bulbs:** 1
- **IP Rating:** IP20 (Indoor use only)
- **Finish:** Matte Silver base, White Fabric shade
- **Special Feature:** Energy efficient design
- **Power Source:** Corded Electric

9. Warranty and Support

For warranty information or technical support, please contact your retailer or visit the official Fischer &

Honsel website. Please have your model number (50422) and proof of purchase available when contacting support.
Note: Spare parts availability information is not provided by the manufacturer.

© 2024 Fischer & Honsel. All rights reserved.