OtterBox 78-80533

OtterBox 3-in-1 Wireless Charging Station User Manual

Model: 78-80533

Introduction

The OtterBox 3-in-1 Wireless Charging Station for MagSafe is designed to efficiently power your essential Apple devices in one compact and organized location. This station provides dedicated charging spots for your iPhone, Apple Watch, and AirPods (or other Qi-enabled devices), making it an ideal solution for home or office use. Its robust design ensures stability and reliable performance.

Product Features

- **Space-saving Design:** Consolidates charging for multiple devices, reducing clutter.
- **Strong Magnetic Alignment:** Features MagSafe technology for secure and precise attachment of compatible iPhones.
- **Optimized for Interaction:** Suspends iPhone securely in both portrait and landscape orientations, allowing for continued use while charging.
- **Fast Charging Capability:** Powered by an included 36W Wall Charger and 2M (6.6ft) USB-C to USB-C Cable for efficient power delivery.
- **Integrated Apple Watch Charging:** Designed to seamlessly integrate your existing Apple Watch charger (sold separately) for a complete charging solution.
- **Qi Wireless Charging Pad:** A dedicated pad for AirPods or other Qi-enabled devices.
- **Premium Finish:** Sleek, fingerprint-resistant finish for a clean aesthetic.

Setup Instructions

1. **Unpack Contents:** Carefully remove the charging station, 36W Wall Charger, and 2M USB-C to USB-C Cable from the packaging.
2. **Assemble Apple Watch Charger (if applicable):** The station is designed to integrate your own Apple Watch charger (not included). Route your Apple Watch charger cable through the designated channel on the back of the station and secure the charging puck into the holder.



Image: The OtterBox 3-in-1 Wireless Charging Station in white, shown with an iPhone, Apple Watch, and AirPods charging simultaneously. The Apple Watch charger is integrated into the side arm.

3. **Connect Power:** Plug the included 2M USB-C to USB-C Cable into the USB-C port located at the back of the charging station. Connect the other end of the cable to the 36W Wall Charger, and then plug the wall charger into a power outlet.
4. **Placement:** Place the charging station on a flat, stable surface. The non-slip weighted design helps keep it securely in place.

Operating Instructions

Charging Your iPhone:

Align your MagSafe-compatible iPhone with the magnetic charging puck on the main stand. The strong magnetic connection will securely hold your iPhone in place. You can charge your iPhone in both portrait and landscape orientations. When placed in landscape, your iPhone may enter StandBy mode (iOS 17 and later), displaying widgets like clocks, calendars, or photos.



Image: An iPhone is shown magnetically attaching to the MagSafe charging puck on the OtterBox 3-in-1 Wireless Charging Station, with blue magnetic rings indicating connection.

Charging Your Apple Watch:

Place your Apple Watch onto the integrated charging puck on the side arm of the station. Ensure it is properly seated for optimal charging. This module supports fast charging for compatible Apple Watch models.

Charging AirPods or Other Qi-Enabled Devices:

Place your AirPods charging case (or any other Qi-enabled device) onto the flat wireless charging pad located at the base of the station. Ensure the device is centered on the pad for efficient charging.



Image: A front view of the white OtterBox 3-in-1 Wireless Charging Station, highlighting the MagSafe phone charger, Apple Watch charger, and the base charging pad for AirPods.

Maintenance

To ensure the longevity and optimal performance of your OtterBox 3-in-1 Wireless Charging Station, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to wipe down the station. For stubborn marks, a slightly damp cloth with mild soap can be used, ensuring no moisture enters the charging ports or surfaces. The premium finish is fingerprint-resistant, making cleaning easy.
- **Cable Care:** Avoid sharp bends or kinks in the USB-C cable. Store excess cable neatly to prevent damage.
- **Placement:** Keep the charging station away from extreme temperatures, direct sunlight, and humid environments.

Troubleshooting

Issue	Possible Cause / Solution
Device not charging.	Ensure the charging station is properly plugged into a working power outlet. Verify the USB-C cable is securely connected to both the station and the wall charger. Ensure your device is correctly aligned on the charging pad/puck. Remove any thick cases from your device that might interfere with wireless charging.
iPhone not holding securely on MagSafe.	Ensure your iPhone case is MagSafe compatible. Non-MagSafe cases may weaken the magnetic connection. Verify there are no foreign objects between the iPhone and the charging puck.
Apple Watch not charging.	Confirm your Apple Watch charger is correctly integrated and connected within the station. The Apple Watch charger is not built-in and must be supplied by the user. Ensure the Apple Watch is properly seated on its charging puck.
Electronic ticking sound during charging.	Some users have reported a faint electronic ticking sound. If this is persistent or disruptive, contact OtterBox customer support.

Specifications

Attribute	Detail
Brand	OtterBox
Model Number	78-80533
Package Dimensions	6.06 x 5.16 x 5.12 inches
Item Weight	13.6 ounces
Connectivity Technology	Wireless, USB
Connector Type	USB Type C
Compatible Devices	Smartphones, Smartwatches
Compatible Phone Models	iPhone (MagSafe compatible)
Included Components	Charging Stand, 36W Wall Charger, 2M USB-C to USB-C Cable
Special Feature	Flexible (for phone orientation)
Color	White
Input Voltage	5 Volts
Mounting Type	Tabletop Mount
Date First Available	March 22, 2022

Warranty and Support

The OtterBox 3-in-1 Wireless Charging Station comes with a limited lifetime warranty, covering material and workmanship defects. This ensures quality and provides peace of mind for your investment.
For further assistance, troubleshooting, or to register your product, please visit the official OtterBox support page:

Visit OtterBox Store & Support

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question