Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Yewrich YR-R18

Yewrich AM/FM Radio Instruction Manual

Model: YR-R18

Product Overview

The Yewrich AM/FM Radio (Model YR-R18) is a portable transistor radio designed for clear reception and ease of use. It features both AM and FM bands, multiple power options, and a built-in speaker with a headphone jack for private listening.



Figure 1: Front view of the Yewrich AM/FM Radio, showing the speaker grille, tuning dial, and control knobs.

Package Contents

Please verify that all items are present in the package:

- Yewrich AM/FM Radio (Model YR-R18)
- AC Power Cable
- Owner's Manual (this document)

Note: 2 x D Cell batteries are required for battery operation and are not included.

Setup

Powering the Radio

The Yewrich AM/FM Radio offers two power options: AC power and battery power.

AC Power Operation

1. Locate the AC power input jack on the back of the radio.
2. Insert the included AC power cable into the jack.
3. Plug the other end of the AC power cable into a standard 120V AC wall outlet.
4. The radio is now ready for continuous operation.



Figure 2: The radio can be powered by AC (top) or D-cell batteries (bottom, not included).

Your browser does not support the video tag.

Video 1: Demonstrates the power options and key features of the Yewrich AM/FM Radio, including battery installation and AC power connection.

Battery Power Operation

1. Open the battery compartment located on the back of the radio.
2. Insert two (2) D Cell batteries (not included) into the compartment, ensuring correct polarity (+/-).
3. Close the battery compartment securely.
4. The radio is now ready for portable use.



Figure 3: Rear view of the radio, highlighting the battery compartment and AC power input.

Operating Instructions

Basic Controls



Figure 4: Labeled diagram of the radio's controls and features.

- **Power/Volume Knob:** Rotate this knob clockwise to turn the radio ON and increase the volume. Rotate counter-clockwise to decrease volume and turn OFF.
- **Tuning Knob:** Rotate this knob to scan through available radio frequencies.
- **AM/FM Band Switch:** Located on the side of the radio, slide this switch to select between AM and FM bands.
- **Headphone Jack:** Insert a 3.5mm headphone plug into this jack for private listening. The built-in speaker will automatically mute when headphones are connected.
- **Telescopic Antenna:** Extend the antenna for improved FM reception. For AM reception, the radio has a built-in ferrite bar antenna, and antenna extension is not typically required.

Tuning to a Station

1. Turn the Power/Volume knob clockwise to turn the radio ON.
2. Slide the AM/FM Band Switch to your desired band (AM or FM).
3. For FM reception, extend the telescopic antenna fully.
4. Slowly rotate the Tuning knob until you hear your desired station clearly. The tuning dial will indicate the approximate frequency.

5. Adjust the Volume knob to your preferred listening level.



Figure 5: The radio's extended antenna and DSP chip contribute to strong signal reception.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the radio. Do not use liquid cleaners or abrasive materials.
- **Battery Care:** If the radio will not be used for an extended period, remove the D Cell batteries to prevent leakage and damage.
- **Storage:** Store the radio in a cool, dry place away from direct sunlight and extreme temperatures.
- **Antenna:** Handle the telescopic antenna with care to prevent bending or breaking.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No power	Power/Volume knob is OFF. AC cable not properly connected. Batteries are dead or incorrectly inserted.	Turn Power/Volume knob clockwise. Ensure AC cable is securely plugged into radio and outlet. Replace batteries or check polarity.
Poor reception / Static	Antenna not extended (FM). Weak signal in your area. Interference from other electronic devices. Incorrect band selected.	Extend the telescopic antenna fully. Try repositioning the radio or antenna. Move radio away from other electronics. Ensure AM/FM band switch is set correctly.
No sound from speaker when headphones are removed	Headphones still partially inserted.	Ensure headphones are fully unplugged from the headphone jack.

Specifications

- **Model:** YR-R18
- **Dimensions:** 8.12 x 2.88 x 5.26 inches (L x W x H)
- **Weight:** 1.68 pounds
- **Radio Bands:** AM (520-1710 KHz), FM (87.5-108 MHz)
- **Power Source:** AC 120V / 2 x D Cell Batteries (DC 3V)
- **Speaker Output:** 2W (Premium built-in speaker)
- **Connectivity:** 3.5mm Headphone Jack
- **Antenna:** Retractable Telescopic Antenna (FM), Built-in Ferrite Bar Antenna (AM)



Figure 6: Product dimensions of the Yewrich AM/FM Radio.

Warranty and Support

Yewrich is committed to providing high-quality products. This product comes with a standard manufacturer's warranty. For detailed warranty information, product support, or assistance with troubleshooting, please refer to the contact information provided on the product packaging or visit the official Yewrich website.

You can also visit the Yewrich Store on Amazon for additional resources.

© 2024 Yewrich. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09WCVYWML

More documents and user manuals: **https://manuals.plus/**