MZK SG2007

MZK Cordless Grass Shear & Shrubbery Trimmer Instruction Manual

Model: SG2007

Introduction

The MZK 7.2V Cordless Grass Shear & Shrubbery Trimmer is a versatile 2-in-1 handheld electric tool designed for efficient garden and lawn maintenance. It allows for quick switching between grass shearing and hedge trimming tasks, offering cordless convenience and powerful performance for various pruning needs.

Safety Information

Always read and understand all safety warnings and instructions before operating this tool.

- **Double Safety Lock:** The trimmer features a double safety lock mechanism. To operate, both the switch and the safety lock must be pressed simultaneously. This design helps prevent accidental activation.
- **Wear Protective Gear:** Always wear heavy-duty yard work gloves and eye protection when operating the trimmer, especially when replacing blades.
- **Blade Handling:** Blades are sharp. Handle them with extreme care to avoid injury. Keep hands and body parts away from moving blades.
- **Keep Area Clear:** Ensure the work area is clear of debris, children, and pets before operation.
- **Proper Storage:** Store the trimmer and its components in a dry, secure place, out of reach of children.
- **Battery Safety:** Use only the provided charger and battery. Do not expose the battery to extreme temperatures or moisture.

Components

The MZK Cordless Grass Shear & Shrubbery Trimmer comes with the following components:

- Main Trimmer Unit
- Hedge Trimmer Blade (8-inch)
- Grass Shear Blade (2.4-inch)
- 7.2V Rechargeable Battery (integrated)
- Battery Charger
- Safety Key



Figure 1: Main components of the MZK Trimmer.

Setup

1. Attaching Blades

The trimmer includes two interchangeable blades: a hedge trimmer blade and a grass shear blade. To attach a blade:

1. Ensure the trimmer is off and the safety key is removed.
2. Align the desired blade with the motor shaft on the main unit.
3. Gently press the blade onto the shaft until it clicks securely into place. Ensure it is firmly seated and does not wobble.
4. To remove a blade, press the release button (if applicable) or pull the blade firmly away from the unit.



Figure 2: Blade attachment point on the trimmer.

2. Charging the Battery

The trimmer is equipped with a 7.2V rechargeable battery. Before first use, fully charge the battery.

1. Connect the charger to a standard electrical outlet.
2. Plug the charger's output into the charging port on the trimmer unit.

3. Allow 3-5 hours for a full charge. The indicator light on the trimmer or charger will typically change color or turn off when charging is complete.



Figure 3: Battery runtime information.

3. Inserting the Safety Key

The safety key is a crucial component for operation. It must be fully inserted into the designated slot on the handle for the trimmer to function.

1. Locate the safety key slot at the base of the handle.
2. Insert the safety key firmly into the slot until it is fully seated.

Operating Instructions

1. Powering On/Off

To turn the trimmer ON, you must engage both the safety switch and the main trigger simultaneously. Release both to turn the trimmer OFF.



Figure 4: Safety switch and lock locations.

2. Using the Hedge Trimmer

Attach the longer hedge trimmer blade for shaping shrubs and hedges. The 8-inch blade length is suitable for various shrubbery tasks.

- Hold the trimmer firmly with both hands, if an auxiliary handle is present, use it for better control.
- Start trimming from the top of the hedge, working downwards in smooth, even strokes.
- The lightweight design (approximately 2 pounds) ensures comfortable use, reducing fatigue during extended operation.



Figure 5: Demonstrating lightweight use for hedge trimming.



Figure 6: Blade dimensions for effective trimming.

3. Using the Grass Shear

Switch to the shorter grass shear blade for precise trimming of grass edges and small areas. The 2.4-inch blade length is ideal for detailed work.

- Hold the trimmer at an angle that allows the blade to cut grass cleanly.
- Move the trimmer along the edges of your lawn or around obstacles for a neat finish.

Maintenance

- **Blade Cleaning:** After each use, clean the blades to remove sap, dirt, and debris. Use a stiff brush and a damp cloth. For stubborn residue, a mild detergent can be used. Ensure blades are completely dry before storage to

prevent rust.

- **Blade Lubrication:** Periodically apply a light coat of machine oil or blade lubricant to the blades to ensure smooth operation and prevent corrosion.
- **Storage:** Store the trimmer in a cool, dry place, away from direct sunlight and moisture. Ensure the safety key is removed and stored separately to prevent unauthorized use.
- **Battery Care:** For long-term storage, it is recommended to charge the battery partially (around 50%) rather than fully charged or completely depleted. Recharge every few months if not in use.

Troubleshooting

Problem	Possible Cause	Solution
Trimmer does not turn on.	Safety key not inserted correctly or missing. Battery is depleted. Dual safety switch not engaged.	Ensure safety key is fully inserted. Charge the battery. Press both the safety switch and trigger simultaneously.
Blades are not cutting effectively.	Blades are dull or dirty. Too thick material being cut.	Clean blades thoroughly. Lubricate blades. Avoid cutting branches thicker than recommended.
Reduced runtime.	Battery not fully charged. Battery nearing end of life.	Ensure battery is fully charged before use. Consider battery replacement if performance continues to degrade.

Specifications

Feature	Detail
Brand	MZK
Model Number	SG2007
Power Source	Battery Powered (7.2V)
Hedge Trimmer Blade Length	8 Inches
Grass Shear Blade Length	2.4 Inches
Cutting Width	6 Inches
Item Weight	2.77 Pounds
Product Dimensions	12"L x 3.8"W x 1.9"H
Blade Material	Alloy Steel

Feature	Detail
Motor Speed	Up to 1100 RPM
Charging Time	3-5 hours
Runtime	50-100 minutes (depending on blade and usage)

Warranty and Support

MZK is committed to providing the best shopping experience. If you have any questions or problems with your MZK tool, please feel free to contact us. We are always here to help you solve any problems you may encounter.
For support, please visit the official MZK Store on Amazon:MZK Store

© 2025 MZK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question