Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PEXMOR G40000164

PEXMOR Adult Tricycle User Manual

Model: G40000164

Introduction

Thank you for choosing the PEXMOR Adult Tricycle. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new tricycle. Please read this manual thoroughly before using the product and retain it for future reference. This tricycle is designed for adults, featuring a 7-speed gear system, front and rear baskets, and a durable high-carbon steel frame for comfortable and practical use.



Image: The PEXMOR Adult Tricycle, showcasing its design and baskets.

Safety Information

Your safety is paramount. Always follow these guidelines:

- Always wear a helmet that meets safety standards when riding.
- Perform a pre-ride inspection: check brakes, tire pressure, and ensure all bolts are tight.
- Be aware of your surroundings and obey all traffic laws.
- Do not ride under the influence of alcohol or drugs.
- Ensure the tricycle's weight capacity (331 lbs) is not exceeded.
- Use caution when carrying heavy loads in the baskets, as it can affect stability.
- Avoid riding in adverse weather conditions or on slippery surfaces.

Package Contents

Upon unpacking, please verify that all components are present and undamaged:

- Tricycle Frame (main body)
- Front Wheel
- Rear Wheels (2)
- Handlebar Assembly
- Seat and Seat Post
- Front Basket
- Rear Basket
- Pedals (2)
- Fenders (front and rear)
- Hardware Kit (bolts, nuts, washers, tools)
- User Manual

Setup and Assembly

Assembly is required for this tricycle. Please follow the instructions carefully. It is recommended to have a second person assist during certain steps.

Assembly Video Guide

Your browser does not support the video tag.

Video: Detailed instruction video for assembling the PEXMOR Adult Tricycle. This video covers step-by-step assembly procedures.

Key Assembly Steps:

1. **Install the Front Wheel:** Secure the front wheel into the fork, ensuring the quick-release or axle nuts are tightened properly.
2. **Attach the Handlebar:** Insert the handlebar stem into the fork tube and tighten the bolt. Adjust the handlebar to a comfortable height and angle.
3. **Mount the Seat:** Insert the seat post into the frame's seat tube. Adjust the seat height for comfortable pedaling and secure it with the quick-release lever or bolt.



Image: The adjustable seat post, allowing riders to customize seat height for comfort.

4. **Install Pedals:** Note that pedals are typically marked 'L' for left and 'R' for right. Thread them into the crank arms carefully. The left pedal tightens counter-clockwise, and the right pedal tightens clockwise.
5. **Attach Fenders:** Secure the front and rear fenders over the wheels using the provided hardware.



Image: Close-up of a rear wheel with a full wrap fender, providing protection from splashes.

6. **Install Baskets:** Attach the front and rear baskets to their designated mounting points on the tricycle frame. The front basket is foldable for convenience.



Image: The foldable front basket in its expanded position, ready for use.

7. **Adjust Brakes and Gears:** Ensure both front V-brake and rear brakes are properly aligned and functional. Test the 7-speed derailleur for smooth shifting. Refer to the video for detailed adjustments.

Operating Instructions

Riding Your Tricycle:

- **Starting:** Mount the tricycle, place your feet on the pedals, and push off gently while beginning to pedal.
- **Steering:** Tricycles steer differently from two-wheel bicycles. Practice in an open, safe area to get accustomed to the wider turning radius and stability.
- **Braking:** The tricycle features front V-brakes and rear brakes. Apply both brakes smoothly and evenly to slow down or stop. Avoid sudden braking, especially with the front brake only, to prevent instability.
- **Gear Shifting:** Use the 7-speed shifter to select appropriate gears for different terrains and speeds. Shift to a lower gear for uphill climbs and a higher gear for flat or downhill riding. Shift gears smoothly while pedaling.
- **Using Baskets:** The front and rear baskets are designed for carrying items. Distribute weight evenly, with heavier

items in the rear basket for better stability. Do not overload the baskets.



Image: A person riding the PEXMOR tricycle, demonstrating its use for carrying groceries.

Maintenance

Regular maintenance ensures the longevity and safe operation of your PEXMOR Adult Tricycle.

- **Tire Pressure:** Check tire pressure before each ride. Maintain the recommended PSI (usually printed on the tire sidewall).
- **Chain Lubrication:** Lubricate the chain every few weeks or after riding in wet conditions to ensure smooth operation and prevent rust.
- **Brake Inspection:** Regularly check brake pads for wear and brake cables for tension. Adjust or replace as needed.
- **Bolt Tightness:** Periodically check all bolts and nuts, especially on the wheels, handlebars, seat post, and baskets, to ensure they are securely tightened.
- **Cleaning:** Clean the tricycle with a damp cloth and mild soap. Avoid high-pressure washing, which can damage bearings and other components.

- **Storage:** Store the tricycle in a dry, covered area to protect it from the elements.

Troubleshooting

Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
Brakes feel weak	Worn brake pads, loose cable, misaligned calipers	Inspect brake pads and replace if worn. Adjust cable tension. Realign calipers.
Gears not shifting smoothly	Derailleur out of adjustment, dirty/dry chain, bent hanger	Adjust derailleur limits and cable tension. Clean and lubricate chain. Check for bent components.
Tricycle pulls to one side	Uneven tire pressure, loose wheel nuts, bent frame/fork	Check and equalize tire pressure. Tighten wheel nuts. Inspect frame for damage.
Squeaking or grinding noise	Dry chain, loose components, worn bearings	Lubricate chain. Check and tighten all bolts. Inspect bearings for wear.

Specifications

Brand: PEXMOR

Model Number: G40000164

Bike Type: Tricycle

Age Range: Adult

Number of Speeds: 7

Wheel Size: 24 Inches

Frame Material: High Carbon Steel

Suspension Type: Front, Rear

Special Features: Basket, Foldable

Brake Style: Linear Pull

Maximum Weight Recommendation: 331 Pounds

Assembly Required: Yes



Image: Dimensional overview of the PEXMOR Adult Tricycle, showing key measurements.

Warranty and Support

PEXMOR stands behind the quality of its products. For specific warranty details, please refer to the warranty card included with your purchase or visit the official PEXMOR website.
If you encounter any issues or have questions regarding your PEXMOR Adult Tricycle, please contact our customer support team:

Website: PEXMOR Official Store

Email: [Insert Customer Support Email Here]

Phone: [Insert Customer Support Phone Number Here]

Please have your model number (G40000164) and purchase date ready when contacting support.

© 2023 PEXMOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09WH56RXP

More documents and user manuals: **https://manuals.plus/**