YOTON YD075

YOTON Portable DVD Player User Manual

Model: YD075

Introduction

Thank you for purchasing the YOTON Portable DVD Player, Model YD075. This device is designed to provide a versatile and portable entertainment experience, featuring a 7.5-inch HD swivel screen, long-lasting built-in battery, and broad compatibility with various media formats. This manual will guide you through the setup, operation, and maintenance of your new DVD player to ensure optimal performance and longevity.

Product Overview and Package Contents

Familiarize yourself with the components of your YOTON Portable DVD Player and verify all items are included in the package.



Image: The YOTON Portable DVD Player shown with its included remote control. The player features a swivel screen and integrated speakers.

Package Contents:

- YOTON Portable DVD Player (Model YD075)
- Remote Control
- AC Power Adapter
- Car Charger
- 3-in-1 AV Cable
- User Manual



Image: A flat lay showing all included accessories: the YD075 DVD player, user manual, AC charger, 3-in-1 AV cable, car charger, and remote control.

Setup

1. Charging the Battery:

Before first use, fully charge the built-in lithium-ion battery. Connect the AC power adapter to the DC IN port on the player and plug it into a wall outlet. The charging indicator light will typically show the charging status. A full charge provides approximately 4-6 hours of playback time.
For car use, connect the certified car charger to the DC IN port and your vehicle's cigarette lighter socket.



Image: An illustration demonstrating the various power options for the YOTON Portable DVD Player, including AC adapters, car charger, and the built-in battery, indicating approximately 5 hours of use.

2. Initial Power On:

Press the Power button to turn on the device. The screen will light up, and the main menu will appear.

3. Connecting to External Displays (TV/Projector):

To view content on a larger screen, use the included 3-in-1 AV cable. Connect one end to the AV OUT port on the DVD player and the other end to the corresponding AV IN (RCA) ports on your TV or projector (Yellow for Video, White for Left Audio, Red for Right Audio). Select the correct AV input source on your external display.



Image: The YOTON Portable DVD Player connected via AV cables to a large television screen, demonstrating the synchronized display feature.

4. Car Installation:

For in-car entertainment, the player can be mounted to the back of a car seat using a compatible headrest mount (not included). Ensure the player is securely fastened and cables are routed safely to avoid obstruction.



Image: A child in the back seat of a car pointing at the YOTON Portable DVD Player, which is mounted on the back of the front seat headrest.

Operating Instructions

1. Inserting a Disc:

Gently open the disc cover. Place a DVD or CD onto the spindle with the label side facing up. Press down gently on the center of the disc until it clicks into place. Close the disc cover firmly. The player will automatically detect the disc and begin playback or display the disc menu.



Image: The YOTON Portable DVD Player with an open disc tray, surrounded by various discs, illustrating its region-free playback and compatibility with formats like SVCD, VCR, DVD-RW, CD, HDCD, EVD, DVD, CD-R, and DVD-R, along with USB and SD card support.

2. Using USB and SD Card:

Insert a USB flash drive into the USB port or an SD card into the SD card slot. The player supports various media formats including JPEG, WMA, MPG, MP3, DIVX, VOB, AVI. Use the remote control or on-device buttons to navigate and select files for playback.

3. Swivel Screen Functionality:

The 7.5-inch HD screen can be rotated 270° horizontally and 180° vertically. This allows for flexible viewing angles, making it suitable for various environments and sharing with others. Adjust the screen gently to your desired position.



Image: Two views of the YOTON Portable DVD Player demonstrating its rotatable and adjustable screen angle, showing 270° horizontal rotation and 180° vertical rotation capabilities.

4. Last Memory Function:

The player features a smart memory function. If the device is powered off during playback, it will automatically resume from the last viewing position when powered on again.



Image: An illustration of the YOTON Portable DVD Player's break point memory function, showing that a film will be replayed from where it was stopped.

5. Audio Output:

The player has built-in dual speakers for direct audio playback. For private listening, connect headphones to the headphone jack. The player also supports AV-OUT for external audio systems via the 3-in-1 AV cable.

Maintenance

Cleaning:

Wipe the player's exterior with a soft, dry cloth. For the screen, use a screen-specific cleaning solution and a microfiber cloth. Do not use abrasive cleaners or solvents. Keep the disc tray and ports free of dust and debris.

Battery Care:

To prolong battery life, avoid fully discharging the battery frequently. If storing the player for an extended period, charge the battery to about 50% and store in a cool, dry place. Recharge every few months to prevent deep discharge.

Troubleshooting

- **"No Disc" Error:**

  Ensure the disc is clean and free of scratches. Verify the disc format is compatible with the player (MINI DVD, DVD-5, DVD-9, DVD-10, DVD-18, DVD±R, DVD±RW). This player does **not** support Blu-ray discs. If the issue persists, try a different disc.

- **No Power:**

  Check if the AC adapter or car charger is securely connected. Ensure the battery is charged. If using battery power, the battery might be fully depleted and requires charging.

- **No Picture on TV:**

  Verify the AV cable connections are correct (Yellow to Yellow, White to White, Red to Red). Ensure your TV's input source is set to the correct AV input.

- **No Sound:**

  Check the volume level on the player and any connected external speakers/headphones. Ensure headphones are fully plugged in if used. If connected to a TV, check the TV's volume and mute settings.

- **Remote Control Not Working:**

  Ensure there are fresh batteries in the remote. Point the remote directly at the player's IR sensor. Remove any obstructions between the remote and the player.

If you encounter problems not listed here or cannot resolve an issue, please contact YOTON customer support.

Specifications

Model Number	YD075
Screen Size	7.5 inches (HD Swivel Screen)
Display Type	LCD
Product Dimensions	1.65 x 6.3 x 8.15 inches
Item Weight	1.5 pounds
Battery Type	Lithium Ion (2 required, included)
Working Time	Approx. 4-6 hours (on full charge)
Compatible Disc Formats	MINI DVD, DVD-5, DVD-9, DVD-10, DVD-18, DVD±R, DVD±RW (Region Free)
Supported Media (USB/SD)	JPEG, WMA, MPG, MP3, DIVX, VOB, AVI, etc.
Connectivity	Headphone, AV-IN, AV-OUT, USB, SD Card

Warranty and Support

YOTON offers comprehensive after-sales support for your portable DVD player.

- **Warranty:** All products purchased from YOTON are covered by a 1-year warranty from the date of purchase.
- **After-Sales Service:** YOTON customers enjoy dedicated after-sales service, including repair, replacement, or refund services.
- **Free New Parts:** You can contact our after-sales team directly for free new parts for any broken or missing components.
- **Technical Support:** Our professional team provides 100% technology support within 24 hours for any concerns regarding usage.

For support, please reach out to the YOTON after-sales service email:support.vp@yoton.co.



Image: Icons representing YOTON's customer service commitments: One-year Free Coverage, 12-Hour Prompt Response, Lifetime Professional Support, and 30-Day No-reason Return.

© 2024 YOTON. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question