ORFELD H01

ORFELD Cordless Vacuum Cleaner User Manual

Model: H01 | Brand: ORFELD

1. Introduction

Thank you for choosing the ORFELD Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new vacuum cleaner. Please read it thoroughly before first use and keep it for future reference.

2. Product Overview

The ORFELD Cordless Vacuum Cleaner is a powerful and versatile 4-in-1 cleaning solution designed for various floor types, including hardwood, carpet, tile, wood, and marble. It features 24000Pa suction, a 40-minute runtime, and advanced filtration for efficient cleaning.



Figure 2.1: Main components of the ORFELD Cordless Vacuum Cleaner, including the main unit, extension wand, motorized brush head, crevice tool, and brush attachment.



Figure 2.2: The vacuum cleaner effectively handles various debris like dust, crumbs, dog food, and pet hair on both carpeted and hard floor surfaces.

Your browser does not support the video tag.

Video 2.1: Demonstration of the ORFELD Cordless Vacuum Cleaner's performance on carpet and hardwood floors, showcasing its suction capabilities.



Figure 2.3: An internal view highlighting the advanced multi-stage filtration system, designed to capture fine dust and allergens.

3. Setup

3.1 Assembly

1. Insert the extension wand into the main motor unit until it clicks securely.
2. Attach the motorized brush head to the other end of the extension wand, ensuring it locks into place.

3. For handheld use, detach the extension wand and attach desired accessories (crevice tool, brush attachment) directly to the main motor unit.

3.2 Initial Charging

Before first use, fully charge the battery. The detachable battery can be charged while attached to the vacuum or separately.



Figure 3.1: The vacuum can be conveniently stored and charged on its wall-mounted dock, or the battery can be removed for separate charging.

- Connect the power adapter to the charging port on the battery or the wall mount.
- Plug the adapter into a power outlet. The battery indicator lights will show charging status.
- A full charge typically takes 4-5 hours, providing up to 40 minutes of runtime depending on the mode used.

4. Operating Instructions

4.1 Power On/Off and Mode Selection

- Press the power button to turn the vacuum on.
- The vacuum operates in two modes: Standard and Turbo. Press the mode selection button to switch between them.
- Use Standard mode for daily cleaning and lighter debris.
- Switch to Turbo mode for deeper cleaning, stubborn dirt, or high-pile carpets.



Figure 4.1: Visual comparison of the vacuum's performance in Standard mode (for light debris) and Turbo mode (for heavier debris like pet food).

4.2 Versatile Cleaning

The 4-in-1 design allows for flexible cleaning:

- **Stick Vacuum:** Ideal for floors and carpets. The LED lights on the brush head illuminate hidden dust.
- **Handheld Vacuum:** Perfect for cleaning car interiors, upholstery, stairs, and tight spaces using the appropriate attachments.
- The flexible brush head allows easy maneuverability under furniture and around obstacles.



Figure 4.2: The vacuum's adaptability is shown through its use as a stick vacuum for floors, a handheld for car seats, and for high-reach cleaning.

5. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

5.1 Emptying and Cleaning the Dust Cup

- Press the release button to detach the dust cup from the main unit.
- Open the dust cup lid and empty contents into a trash bin.
- Wipe the inside of the dust cup with a damp cloth or tissue.

Your browser does not support the video tag.

Video 5.1: Step-by-step guide on how to disassemble and empty the dust cup for cleaning.

5.2 Cleaning the HEPA Filter

- Twist and pull to remove the HEPA filter from the dust cup.
- Tap the filter gently to remove loose dust.
- Rinse the HEPA filter under running water until clean. Do not use detergent.
- Allow the filter to air dry completely for at least 24 hours before reinserting. Ensure it is completely dry to prevent damage and maintain suction.

Your browser does not support the video tag.

Video 5.2: Detailed instructions on how to clean the HEPA filter using running water and proper drying techniques.

5.3 Cleaning the Roller Brush

- Locate the release tab on the side of the motorized brush head.
- Slide the tab to unlock and remove the roller brush.
- Use scissors to cut away any tangled hair or fibers from the brush.
- Clean the brush with a damp cloth if necessary. Ensure it is dry before reinserting.

Your browser does not support the video tag.

Video 5.3: Guide on how to remove and clean the roller brush from the vacuum head, including removing tangled hair.

6. Troubleshooting

Problem	Possible Cause	Solution
Vacuum not turning on	Battery is not charged or not properly installed.	Ensure battery is fully charged and securely clicked into place.
Low suction power	Dust cup is full, filter is clogged, or roller brush is tangled.	Empty dust cup, clean HEPA filter, and remove any obstructions from the roller brush.
Brush head not spinning	Obstruction in the brush head or brush head not properly attached.	Check for and remove any blockages. Ensure the brush head is securely attached to the wand.

Problem	Possible Cause	Solution
Short runtime	Battery not fully charged or operating in Turbo mode constantly.	Fully charge the battery. Use Standard mode for longer cleaning sessions.

7. Specifications

Brand: ORFELD

Model Name: H01

Special Feature: Lightweight, HEPA

Filter Type: HEPA Filter

Is Cordless?: Yes

Runtime: 40 minutes

Recommended Uses For Product: Carpet, Hard Floor, Tile, Wood, Marble Floor

Form Factor: Stick

Product Dimensions: 42"L x 4"W x 8"H

Battery Description: Lithium-Ion

Noise Level: 65 dB

Item Weight: 8.23 pounds

8. Warranty and Support

ORFELD offers a 3-year warranty for this product, ensuring peace of mind. For technical support, warranty claims, or any inquiries, please refer to the contact information provided in your product packaging or visit the official ORFELD website. Additional safety information can be found in theSafety Information PDF.

© 2023 ORFELD. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question