SOARFLY 121

SOARFLY Electric Rechargeable Pedicure Foot File Model 121 User Manual

Comprehensive instructions for safe and effective use.

Introduction

Thank you for choosing the SOARFLY Electric Rechargeable Pedicure Foot File. This device is designed to effectively remove dry, hard, and calloused skin from your feet, promoting smoother and healthier skin. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.
The SOARFLY Pedicure Foot File features a rechargeable design, three interchangeable quartz sand roller heads, and two adjustable speed settings for customized foot care. It is also equipped with an LED display for battery level and an integrated LED light for enhanced visibility during use.

Important Safety Warnings

Warning: The product packaging may contain information different from what is shown on our website. Always read the label, warnings, and instructions provided on the product before using or consuming it.

- Do not use on broken, irritated, or infected skin. Consult a medical professional if you have diabetes or poor circulation before use.
- Keep out of reach of children.
- Avoid excessive pressure. The device features a "Pressure Lock" safety technology that automatically stops the grinder if too much force is applied, protecting your feet from injury.
- Ensure the device is fully dry before charging.
- Do not immerse the main body of the device in water for extended periods, despite its IPX7 waterproof rating.

Package Contents

Your SOARFLY Electric Rechargeable Pedicure Foot File package includes the following items:

- 1 x Electric Rechargeable Callus Remover
- 3 x Quartz Sand Roller Heads (Coarse, Regular, Fine)

- 1 x USB Charging Cable
- 1 x Pedicure Tool Set (may include callus shaver, cuticle remover, foot file, nail clippers, etc.)
- 1 x Cleaning Brush



The image displays the electric foot file along with a comprehensive 16-in-1 pedicure kit, including tools like a callus shaver, nail file, V-shaped push stick, foot file, corn knife, nail brush, silicone sheet, blade replaceable tool, and cuticle remover.

Setup

1. Charging the Device

Before first use, fully charge the device. The integrated 1200 mAh lithium-ion battery requires approximately 3 hours for a full charge, providing about 160 minutes of operation.

1. Connect the USB charging cable to the USB fast charging port on the device.
2. Plug the other end of the USB cable into a compatible USB power source (e.g., laptop, computer, power bank, wall

adapter).

3. The LED display will show the charging progress. Once fully charged, the display will indicate 100%.



The image illustrates the USB fast charging capability, showing the device connected to a wall adapter, with other compatible charging sources like a laptop and power bank also depicted. The LED display shows battery percentage.

2. Attaching a Roller Head

The device comes with three different quartz sand roller heads: Coarse, Regular, and Fine. Choose the appropriate roller head based on your skin's condition.

- **Coarse Roller:** For stubborn calluses and very hard skin.
- **Regular Roller:** For new dead skin and moderate calluses.
- **Fine Roller:** For daily foot care and polishing delicate skin.

1. Ensure the device is turned off.
2. Press the roller release button located on the side of the device.
3. Gently insert the desired roller head into the slot until it clicks into place.



This image illustrates the three types of grinding rollers: Coarse for stubborn calluses, Regular for new dead skin, and Fine for daily foot care. It also shows the device in use on a foot.

Operating Instructions

1. Preparation for Use

For best results, it is recommended to prepare your feet before using the electric foot file.

1. Soak your feet in warm water for approximately 10 minutes to soften the skin.
2. Thoroughly dry your feet before use. The device is suitable for both wet and dry use, but dry feet often yield better results for initial callus removal.



This image demonstrates the three-step process for achieving smooth feet: 1. Soaking feet in warm water for 10 minutes, 2. Using the electric callus remover, and 3. Applying cream to nourish the feet.

2. Using the Electric Foot File

The device features two speed settings for different skin types and needs.

- **Low Speed (1700x/min):** Ideal for delicate skin or light exfoliation.
- **High Speed (2000x/min):** Suitable for hard skin and stubborn calluses.

1. Press the power button once to turn on the device at low speed. The integrated LED light will illuminate, and the LED display will show the battery level.
2. Press the power button a second time to switch to high speed.
3. Gently glide the rotating roller head over the hard skin or calluses on your feet. Do not apply excessive pressure. The device will automatically stop if too much pressure is detected.
4. Move the device continuously over the area, avoiding staying in one spot for too long to prevent irritation.
5. After achieving the desired smoothness, press the power button again to turn off the device.



This image highlights the two speed modes: Low Speed (1700x/min) and High Speed (2000x/min), indicating how to select them via the power button.

3. Post-Treatment

After using the foot file:

1. Rinse your feet with water to remove any remaining dead skin particles.
2. Apply a moisturizing foot cream or lotion to nourish and hydrate your newly smoothed skin.

Maintenance

1. Cleaning the Roller Heads

Regular cleaning of the roller heads is essential for hygiene and optimal performance.

1. Ensure the device is turned off.
2. Press the roller release button and remove the used roller head.
3. Rinse the roller head under running water to remove dead skin particles. You may use the provided cleaning brush for thorough cleaning.
4. Allow the roller head to air dry completely before reattaching or storing.



This image illustrates the four steps to remove and clean the rollers: 1. Brushing off debris, 2. Pressing the release button to remove the roller, 3. Rinsing the roller under water, and 4. Reattaching the clean roller.

2. Cleaning the Device Body

The device has an IPX7 waterproof design, allowing for safe rinsing.

1. After removing the roller head, you can rinse the device body under running water.
2. Wipe the device body with a clean, dry cloth.
3. Ensure the device is completely dry before storing or recharging.



This image visually confirms the IPX7 waterproof rating, showing the device partially submerged in water, indicating it is safe for wet usage and easy cleaning.

3. Storage

Store the device and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully (approx. 3 hours).
Roller head stops during use.	Excessive pressure applied (safety lock activated).	Reduce pressure on the skin. Glide gently.
Roller head is not effective.	Roller head is worn out or incorrect type for skin condition.	Replace the roller head or try a coarser roller head. Ensure feet are dry for optimal initial removal.
Device not charging.	USB cable or power source issue.	Check USB cable connection. Try a different USB port or power adapter. Ensure the device is dry.

Specifications

Brand	SOARFLY
Model Number	121
ASIN	B09WRD3BY5
Dimensions	19.5 x 14 x 5.4 cm
Weight	350 grams
Battery Type	1200 mAh Lithium-ion (non-standard)
Charging Time	Approximately 3 hours
Operating Time	Approximately 160 minutes
Speed Settings	Low: 1700x/min, High: 2000x/min
Waterproof Rating	IPX7
Material	ABS
Color	Black

Warranty Information

Specific warranty details are typically provided with your purchase documentation or on the product packaging. Please refer to those materials for information regarding warranty coverage and duration.
For return policy information, please refer to the retailer's policy where the product was purchased. For example, Amazon's return policy typically allows for returns or replacements within 14 days of purchase.

Customer Support

If you encounter any issues or have questions not covered in this manual, please contact SOARFLY customer support through the retailer's platform or the contact information provided with your product.
For purchases made on Amazon, you can typically find seller contact information through your order history.

SOARFLY Electric Rechargeable Pedicure Foot File Model 121 User Manual. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question