ADESSO CYBERTABLETK10

Adesso Cybertablet K10 Graphics Drawing Tablet User Manual

Model: CYBERTABLETK10

Introduction

The Adesso Cybertablet K10 is an advanced graphics tablet designed to provide superior cursor control, enhanced productivity, and higher efficiency for both PC and Mac users. It is an ideal tool for various applications including art, business presentations, and creative projects. This manual provides essential information for setting up, operating, and maintaining your Cybertablet K10.



Image: The Adesso Cybertablet K10 graphics tablet, showcasing its sleek black design and the accompanying battery-free pen. The tablet features a large drawing area and shortcut buttons along the top edge.

What's in the Box

Upon unboxing your Adesso Cybertablet K10, please ensure all the following components are present:

- Digital Pen
- Pen Holder
- Cybertablet K10 Graphics Tablet
- USB Cable (integrated or separate, for connection)

Setup

Follow these steps to set up your Cybertablet K10 for first-time use:

1. **Connect the Tablet:** Plug the USB cable from the Cybertablet K10 into an available USB port on your computer (PC or Mac).
2. **Driver Installation:** For optimal performance and full functionality, it is recommended to install the latest drivers for your Cybertablet K10. Drivers are typically available on the Adesso official website. Follow the on-screen instructions during installation.

3. **Operating System Compatibility:** The tablet is compatible with Windows 10 Home and other operating systems. Ensure your system meets the minimum requirements for driver installation.
4. **Pen Setup:** The included digital pen is battery-free, requiring no charging. It is ready for use once the tablet is connected and drivers are installed.

Operating the Cybertablet K10

The Cybertablet K10 offers a responsive and intuitive drawing experience. Here's how to utilize its key features:

Active Drawing Area

The tablet features a generous 10" x 6" active drawing area, providing ample space for detailed work and broad strokes. This large area allows for increased precision and detail in your creations.



Image: A top-down view of the Adesso Cybertablet K10, clearly indicating its 10-inch width and 6-inch height active drawing area with measurement lines.

Pressure Sensitivity

The Cybertablet K10 boasts 8192 levels of pressure sensitivity. This feature allows the digital pen to imitate the subtleties of a traditional brush stroke, pencil line, or other writing tools, providing a natural and expressive drawing experience. Varying pressure on the pen will result in different line thickness or opacity, depending on the software used.



Image: The Adesso Cybertablet K10 with a glowing blue line illustrating the concept of pressure sensitivity, emphasizing the 8192 levels of pressure detection.

Battery-Free Pen with Tilt Support

The included digital pen operates without a battery, eliminating the need for charging and ensuring uninterrupted workflow. It also supports a tilt range, allowing for more natural shading and varied brush effects, similar to traditional art tools.



Image: The Adesso Cybertablet K10 with its battery-free stylus, showing an arrow indicating the tilt functionality of the pen.

Customizable Keys and Scroll Wheel

The Cybertablet K10 features 6 customizable shortcut keys and a scroll wheel located at the top of the tablet. These keys can be programmed through the tablet's driver software to provide quick access to commonly used functions, tools, or shortcuts in your preferred applications, enhancing your workflow efficiency.



Image: A close-up view of the top section of the Adesso Cybertablet K10, highlighting the 6 customizable shortcut keys and the central scroll wheel, with a hand demonstrating interaction.

Maintenance

To ensure the longevity and optimal performance of your Cybertablet K10, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to gently wipe the surface of the tablet and the digital pen. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the device.
- **Storage:** When not in use, store the tablet and pen in a clean, dry place away from direct sunlight, extreme temperatures, and dust.
- **Pen Nibs:** Periodically check the pen nib for wear. Replacement nibs may be available from the manufacturer if needed.

Troubleshooting

If you encounter issues with your Cybertablet K10, try the following troubleshooting steps:

- **No Response from Tablet/Pen:**
  - Ensure the USB cable is securely connected to both the tablet and your computer.
  - Try connecting the tablet to a different USB port on your computer.
  - Restart your computer.
  - Verify that the tablet drivers are correctly installed and up to date. Reinstall them if necessary.
- **Inaccurate Cursor Movement:**
  - Recalibrate the tablet if your driver software provides this option.
  - Ensure there are no obstructions or debris on the tablet's active area.
- **Pen Pressure Not Working:**
  - Check your drawing software settings to ensure pressure sensitivity is enabled.
  - Verify that the tablet drivers are installed correctly, as pressure sensitivity often relies on proper driver function.

If these steps do not resolve the issue, please refer to the support section for further assistance.

Specifications

Feature	Detail
Product Dimensions	9 x 1.7 x 12.1 inches
Item Weight	1 pounds
Model Number	CYBERTABLETK10
Brand	ADESSO
Connectivity Technology	USB
Pressure Sensitivity	8192 Levels
Operating System	Windows 10 Home (and other compatible OS)
Special Feature	Portable
Active Drawing Area	10" x 6"

Warranty and Support

For detailed warranty information regarding your Adesso Cybertablet K10, please refer to the documentation included with your purchase or visit the official Adesso website. Adesso provides customer support for product inquiries, technical assistance, and warranty claims.

You can find more information and support resources by visiting theADESSO Store on Amazon or the official Adesso corporate website.

© 2024 ADESSO. All rights reserved.

This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question