Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BEEM GRIND-PERFECT Elektrische Kaffeemühle

BEEM Grind-PERFECT Electric Coffee Grinder

Model: GRIND-PERFECT Elektrische Kaffeemühle

1. Introduction

Thank you for choosing the BEEM Grind-PERFECT Electric Coffee Grinder. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new appliance. Please read these instructions thoroughly before first use and keep them for future reference.
The BEEM Grind-PERFECT is designed to deliver freshly ground coffee with precision, featuring a high-quality conical burr grinder, 35 adjustable grind settings, and a customizable quantity selection for 2 to 12 cups.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.

3. Package Contents

Please check the contents of your package to ensure all items are present and undamaged:

- BEEM Grind-PERFECT Electric Coffee Grinder Unit
- Removable Bean Hopper (250g capacity)
- Ground Coffee Container (130g capacity)
- Portafilter Holder/Adapter (for 52-58mm portafilters)
- Dosing Spoon
- Cleaning Brush

4. Product Overview

Familiarize yourself with the components of your BEEM Grind-PERFECT coffee grinder:



Image 1: Labeled diagram of the BEEM Grind-PERFECT coffee grinder. Key components include the 250g removable bean hopper, 35-level grind setting dial, high-quality stainless steel conical burr grinder, 130g ground coffee container, portafilter holder, and controls for 2-12 cup selection. Accessories like the dosing spoon and cleaning brush are also shown.

1. **Bean Hopper:** Transparent container for whole coffee beans (250g capacity).
2. **Grind Setting Dial:** Adjusts the fineness of the grind (35 levels).

3. **Conical Burr Grinder:** High-quality stainless steel burrs for precise grinding.
4. **Quantity Selection Knob:** Rotary knob to select the desired amount of coffee (2-12 cups).
5. **Start/Stop Button:** Initiates and stops the grinding process.
6. **Ground Coffee Container:** Removable container for collecting ground coffee (130g capacity).
7. **Portafilter Holder:** Attachment for grinding directly into a portafilter (52-58mm diameter).
8. **Drip Tray:** Collects any spilled coffee grounds.

5. Setup

Follow these steps to set up your coffee grinder for first use:

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future transport or storage.
2. **Clean:** Before first use, clean all removable parts (bean hopper, ground coffee container, portafilter holder, dosing spoon, cleaning brush) with warm soapy water, rinse thoroughly, and dry completely. Wipe the main unit with a damp cloth.
3. **Placement:** Place the grinder on a stable, flat, and dry surface. Ensure there is sufficient space around the unit for ventilation.
4. **Assemble Bean Hopper:** Place the clean and dry bean hopper onto the top of the grinder unit. Rotate it until it locks securely into place.
5. **Connect Power:** Plug the power cord into a suitable electrical outlet.

6. Operating Instructions



Image 2: Operational steps for the BEEM Grind-PERFECT coffee grinder. This image illustrates adding whole coffee beans to the hopper, adjusting the grind fineness using the dial, grinding coffee directly into a portafilter, and the grinder's compatibility with pour-over brewing methods.

6.1. Filling the Bean Hopper

Open the lid of the bean hopper and pour whole roasted coffee beans into it. Do not overfill; the maximum capacity is 250g. Close the lid securely after filling.

6.2. Adjusting Grind Size



Image 3: A visual comparison of different coffee grind sizes, including fine (suitable for espresso), medium (for drip coffee), and coarse (for French press). This demonstrates the versatility of the grinder's 35 grind settings.

The BEEM Grind-PERFECT offers 35 grind settings, from very fine to coarse. Rotate the grind setting dial located below the bean hopper to select your desired fineness. The dial is marked with indicators for common brewing methods:

- **1-10 (Espresso):** Very fine grind for espresso machines.
- **11-25 (Drip / Pour Over):** Medium grind for drip coffee makers and pour-over methods.
- **26-35 (French Press):** Coarse grind for French press and cold brew.

Experiment with different settings to find the ideal grind for your coffee beans and brewing method.

6.3. Adjusting Quantity

Use the rotary knob on the front of the grinder to select the desired number of cups (2-12). The grinder will automatically stop once the selected quantity has been ground.

6.4. Grinding into the Ground Coffee Container

1. Ensure the ground coffee container is clean and empty.
2. Slide the ground coffee container into its designated slot under the grinding chute.
3. Select the desired grind size and quantity.
4. Press the Start/Stop button to begin grinding. The grinder will stop automatically.
5. Remove the container and use the freshly ground coffee.

6.5. Grinding Directly into a Portafilter



Image 4: This image demonstrates the versatility of the grinder, showing coffee being ground into the included ground coffee container, directly into an espresso machine's portafilter, and its use with a pour-over coffee cone.

1. Remove the ground coffee container.
2. Attach the portafilter holder/adapter to the grinder.
3. Place your espresso machine's portafilter (52-58mm diameter) securely into the holder.
4. Select the desired grind size (typically fine for espresso) and quantity.
5. Press the Start/Stop button to begin grinding. The grinder will stop automatically.
6. Remove the portafilter and proceed with brewing your espresso.

7. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your grinder. Always unplug the appliance from the power outlet before cleaning.

7.1. Daily Cleaning

- **Ground Coffee Container & Portafilter Holder:** Empty and wash with warm soapy water, rinse, and dry thoroughly.
- **Drip Tray:** Remove and empty any spilled grounds. Wipe clean with a damp cloth.
- **Exterior:** Wipe the exterior of the grinder with a soft, damp cloth. Do not use abrasive cleaners or immerse the main unit in water.

7.2. Cleaning the Burr Grinder

For best results, clean the burr grinder regularly, especially when changing coffee bean types or if you notice inconsistent grinding.

1. Ensure the grinder is unplugged.
2. Remove the bean hopper by rotating it counter-clockwise and lifting it off.
3. Carefully remove the upper burr. Refer to the product diagram for guidance.
4. Use the provided cleaning brush to remove any accumulated coffee grounds from both the upper and lower burrs.
5. Clean the inside of the grinding chamber with the brush.
6. Reassemble the upper burr and bean hopper, ensuring they are securely locked in place.

8. Troubleshooting

If you encounter issues with your BEEM Grind-PERFECT, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Grinder does not start.	Not plugged in; bean hopper not correctly installed; power outage.	Check power connection; ensure bean hopper is locked in place; check household circuit breaker.
Inconsistent grind.	Burrs are dirty or clogged; grind setting too coarse/fine for desired result.	Clean the burr grinder as per Section 7.2; adjust grind setting.
Grinder jams or stops during operation.	Foreign object in beans; burrs clogged with oily beans.	Unplug the grinder, remove beans, and carefully inspect for foreign objects. Clean burrs thoroughly.
Coffee grounds spill.	Ground coffee container or portafilter not correctly positioned.	Ensure the container or portafilter is fully inserted and aligned with the grinding chute.

If the problem persists after attempting these solutions, please contact BEEM customer support or your retailer for assistance.

9. Specifications



Image 5: Dimensional diagram of the BEEM Grind-PERFECT coffee grinder. The image indicates a height of 29.5 cm, a width of 13.8 cm, and a depth of 20.0 cm, providing a clear understanding of the product's physical footprint.

Feature	Specification
Brand	BEEM
Model Number	GRIND-PERFECT Elektrische Kaffeemühle
Color	Black
Dimensions (L x W x H)	13.8 x 20 x 29.5 cm
Bean Hopper Capacity	250 Grams
Power	150 Watts
Voltage	230 Volts

Feature	Specification
Material	Stainless Steel
Item Weight	2.04 Kilograms
Grind Settings	35 levels (fine to coarse)
Cup Selection	2-12 cups

10. Warranty and Support

For warranty information, please refer to the documentation provided with your purchase or contact your retailer. BEEM provides quality products, and any claims under warranty should be directed to the point of purchase or the official BEEM customer service channels.
Spare parts availability information is currently unavailable through this manual. Please consult the manufacturer's website or contact customer support for details on spare parts.

© 2024 BEEM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09WYZ11YB

More documents and user manuals: **https://manuals.plus/**