Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hikvision 8191907

HIKVISION 24-inch LED Monitor User Manual

Model: 8191907

Introduction

This user manual provides comprehensive instructions for the installation, operation, and maintenance of your HIKVISION 24-inch LED Monitor. Please read this manual thoroughly before using the product and retain it for future reference.

Safety Information

- Ensure the monitor is placed on a stable, flat surface to prevent accidental falls.
- Do not expose the monitor to rain or moisture to avoid electric shock or fire.
- Keep ventilation openings clear to prevent overheating.
- Use only the power adapter supplied with the monitor.
- Unplug the monitor from the power outlet before cleaning.

Package Contents

Verify that all items are present in the package:

- HIKVISION 24-inch LED Monitor
- Monitor Stand (Base and Neck)
- Power Adapter
- Power Cable
- HDMI Cable (may vary by region)
- VGA Cable (may vary by region)
- User Manual (this document)

Product Overview

Familiarize yourself with the components of your monitor.



This image shows the Hikvision 24-inch LED monitor from a side angle, highlighting its slim bezel and the stand. The screen displays a vibrant image of a coastal town, demonstrating its visual capabilities.

Front Panel

- **Power Button:** Turns the monitor on or off.
- **OSD Control Buttons:** Navigate and adjust settings in the On-Screen Display menu.

Rear Panel

- **Power Input:** Connects to the power adapter.
- **HDMI Port:** Connects to devices with HDMI output.
- **VGA Port:** Connects to devices with VGA output.
- **Audio Input/Output:** For external audio devices (if applicable).
- **VESA Mount Holes:** For wall mounting or alternative stands (M4 100mm x 100mm).

Setup

1. Assembling the Stand

1. Carefully place the monitor face down on a soft, clean cloth to prevent scratches.
2. Attach the stand neck to the monitor's rear panel, ensuring it clicks into place or is secured with screws (if provided).
3. Attach the stand base to the neck, securing it with the thumb screw or screws at the bottom.
4. Alternatively, for VESA mounting, remove the stand and attach a compatible VESA mount (100x100mm) to the monitor.

2. Connecting Cables

1. **Power Connection:** Connect the power adapter to the monitor's power input, then plug the power cable into a wall outlet.
2. **Video Connection:**
    - **HDMI:** Connect one end of the HDMI cable to the monitor's HDMI port and the other end to the HDMI output port of your computer or device.
    - **VGA:** Connect one end of the VGA cable to the monitor's VGA port and the other end to the VGA output port of your computer or device.
3. **Audio Connection (if applicable):** If using external speakers or headphones, connect them to the monitor's audio output port. The built-in speakers provide audio directly via HDMI.

3. Initial Power On

Press the power button on the monitor. The power indicator light will illuminate, and the monitor will display the input source. If no signal is detected, ensure your connected device is powered on and configured correctly.

Operating the Monitor

Power On/Off

Press the power button located on the front or bottom of the monitor to turn it on or off.

OSD (On-Screen Display) Menu

The OSD menu allows you to adjust various display settings. Use the control buttons (usually located on the bottom or rear of the monitor) to navigate the menu.

- **Menu Button:** Opens the OSD menu.
- **Up/Down Buttons:** Navigate through menu options.
- **Enter/Select Button:** Confirms a selection or enters a sub-menu.
- **Exit Button:** Exits the current menu or sub-menu.

Common OSD Settings:

- **Input Source:** Select between HDMI and VGA inputs.
- **Brightness/Contrast:** Adjust the display's luminance and contrast levels.
- **Color Settings:** Adjust color temperature, RGB levels, or select preset color modes.
- **Picture Mode:** Select preset display modes (e.g., Standard, Game, Movie).
- **Audio:** Adjust volume for built-in speakers.
- **OSD Settings:** Adjust OSD language, transparency, and timeout.
- **Reset:** Restore all settings to factory defaults.

Maintenance

Cleaning the Monitor

- Always unplug the monitor before cleaning.
- **Screen:** Use a soft, lint-free cloth lightly dampened with water or a non-abrasive screen cleaner. Do not spray liquid directly onto the screen.
- **Casing:** Wipe the plastic casing with a soft, dry cloth. Avoid using strong detergents or abrasive cleaners.

Storage

If storing the monitor for an extended period, disconnect all cables, pack it in its original packaging (if available), and store it in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
No image on screen	• Monitor not powered on. • Video cable loose or disconnected. • Incorrect input source selected. • Computer/device not powered on or in sleep mode.	• Press the power button. • Check and re-secure video cables (HDMI/VGA). • Use OSD menu to select correct input source. • Ensure computer/device is on and awake.
"No Signal" message	• Incorrect input source selected. • Video cable not connected properly. • Computer/device not outputting signal.	• Select the correct input source via OSD. • Verify video cable connection at both ends. • Restart your computer/device.
Image is blurry or distorted	• Incorrect resolution setting. • Loose VGA cable (for analog connection).	• Set display resolution to the monitor's native resolution (e.g., 1920x1080 for Full HD). • Ensure VGA cable is securely fastened.
No sound from built-in speakers	• Volume too low or muted. • Audio source not selected (if using HDMI). • External speakers/headphones connected.	• Adjust volume via OSD menu or computer settings. • Ensure HDMI is selected as audio output on your device. • Disconnect external audio devices.

Specifications

Feature	Detail
Brand	Hikvision

Feature	Detail
Model Number	8191907
Screen Size	24 Inches
Display Type	LED
Connectivity Technology	VGA, HDMI
Maximum Display Resolution	640 x 480
Aspect Ratio	16:9
Screen Surface Description	Glossy
Response Time	1 millisecond
Refresh Rate	60 Hz
Viewing Angle (H/V)	178° / 178°
Built-in Speakers	Yes (two x two watts)
Casing Material	Plastic
VESA Compatibility	M4 100mm x 100mm

Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Hikvision website. Keep your purchase receipt as proof of purchase for warranty claims.
Online Support: www.hikvision.com/en/support/

© 2024 Hikvision. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09X6ZHWRM

More documents and user manuals: **https://manuals.plus/**