Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sensea 3276000699972

SENSEA Easy 3L Bathroom Bin User Manual

Brand: Sensea | Model: 3276000699972

1. Introduction

Welcome to the user manual for your SENSEA Easy 3L Bathroom Bin. This manual provides essential information on the product's features, setup, operation, maintenance, and troubleshooting. Please read it carefully to ensure proper use and longevity of your bin.

The SENSEA Easy 3L Bathroom Bin is designed for discreet waste disposal in bathrooms, offering a compact and hygienic solution. Its 3-liter capacity and removable inner bucket make it convenient for daily use and easy cleaning. The pedal-operated opening system ensures hands-free operation, promoting better hygiene.

2. Product Overview

The SENSEA Easy 3L Bathroom Bin features a sleek, dark grey matte metal design that blends seamlessly into various bathroom decors. Its compact size makes it ideal for small spaces.



Figure 2.1: SENSEA Easy 3L Bathroom Bin (closed view).

Key Features:

- **Compact Design:** Dark grey finish with a discreet design, perfect for small bathroom spaces. The lid conceals the interior for maximum discretion.
- **Soft-Close Lid:** The lid features a soft-closing mechanism to prevent clattering noises.
- **Easy Cleaning:** Equipped with a removable inner bucket (3L capacity) and a handle for convenient emptying and cleaning.
- **Hygienic Operation:** Pedal-operated opening system allows for hands-free use, enhancing hygiene and eliminating the need to bend down.
- **Portability:** Features a handle at the back for easy relocation.



Figure 2.2: Rear handle for easy transport.

3. Setup

Your SENSEA Easy 3L Bathroom Bin comes pre-assembled. Follow these simple steps for initial setup:

1. **Unpack:** Carefully remove the bin from its packaging.
2. **Inner Bucket Placement:** Ensure the removable inner bucket is correctly seated inside the main bin body. It should fit snugly.
3. **Positioning:** Place the bin in your desired location in the bathroom. Ensure there is enough space for the lid to open fully and for the pedal to be operated comfortably.



Figure 3.1: SENSEA Easy 3L Bathroom Bin with inner bucket.

4. Operating Instructions

Opening the Bin:

- To open the bin, gently press down on the foot pedal located at the base of the bin.
- The lid will lift open, allowing you to dispose of waste.
- Release the pedal, and the lid will slowly close due to its soft-closing mechanism.

Emptying the Bin:

1. Open the lid manually or by pressing the pedal.
2. Grasp the handle of the removable inner bucket and lift it out of the main bin body.
3. Dispose of the waste from the inner bucket into a larger waste receptacle.
4. Place the empty inner bucket back into the main bin body, ensuring it is properly seated.

5. Close the lid.

5. Maintenance and Care

Regular cleaning and proper care will ensure your SENSEA Easy 3L Bathroom Bin remains hygienic and functional for a long time.

Cleaning Instructions:

- **Inner Bucket:** The removable inner bucket can be washed with warm soapy water. Rinse thoroughly and dry completely before placing it back into the bin.
- **Exterior:** Wipe the exterior of the bin with a soft, damp cloth. For stubborn marks, a mild, non-abrasive cleaner can be used. Avoid harsh chemicals or abrasive materials, as they may damage the finish.
- **Lid and Pedal Mechanism:** Periodically check the lid and pedal mechanism for any debris or obstructions. Wipe clean as needed.
- **Drying:** Always ensure all parts are completely dry before reassembling to prevent rust or mildew.

General Care:

- Do not overload the bin beyond its 3-liter capacity.
- Avoid placing heavy objects on the lid.
- Use appropriate bin liners to keep the inner bucket clean and extend its lifespan.

6. Troubleshooting

If you encounter any issues with your SENSEA Easy 3L Bathroom Bin, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lid does not open or close smoothly.	Obstruction in the mechanism; debris around the hinge; inner bucket not seated correctly.	Check for any foreign objects obstructing the lid or pedal. Ensure the inner bucket is properly aligned. Clean around the hinge area.
Pedal feels stiff or unresponsive.	Accumulation of dirt or debris in the pedal mechanism.	Clean the pedal mechanism thoroughly. Ensure no objects are preventing its full range of motion.
Bin emits unpleasant odors.	Waste residue inside the inner bucket or main bin.	Empty and thoroughly clean both the inner bucket and the main bin. Use a deodorizer if necessary. Ensure bin liners are used and changed regularly.

7. Specifications

Detailed specifications for the SENSEA Easy 3L Bathroom Bin:

Feature	Detail
Product Dimensions (L x W x H)	28 x 17 x 23 cm (approximately 11 x 6.7 x 9 inches)
Manufacturer	ADEO

Feature	Detail
ASIN	B09X9N2K6D
Manufacturer Reference	3276000699972
Brand	Sensea
Capacity	3 Liters
Color	Dark Grey Matte
Opening Mechanism	Pedal
Material	Metal
Recommended Use	Bathroom
Room Type	Bathroom
Special Feature	Lid
Shape	Cylindrical
Finish Type	Painted



Figure 7.1: Product Dimensions Diagram.

8. Warranty and Support

SENSEA products are designed for durability and reliability. For specific warranty information, please refer to the documentation provided with your purchase or visit the official SENSEA website.

For any questions, technical assistance, or support regarding your SENSEA Easy 3L Bathroom Bin, please contact SENSEA customer service or the retailer from whom you purchased the product. Keep your proof of purchase handy for any warranty claims.

You can find more information about SENSEA products and their commitment to quality on their official brand store: SENSEA Brand Store.

© 2024 Sensea. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09X9N2K6D

More documents and user manuals: **https://manuals.plus/**