Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jimmyjane JJ10524

JIMMYJANE Form 2 Gripp Vibrator Instruction Manual

Introduction

The JIMMYJANE Form 2 Gripp is a personal massager designed for targeted stimulation. It features an ergonomic design with a finger holder for precise control and multiple vibration settings for varied experiences. This manual provides essential information for the safe and effective use, care, and maintenance of your device.

Safety Information

- This device is made from body-safe, phthalate-free, and latex-free silicone.
- The Form 2 Gripp has an IPX7 waterproof rating, meaning it is fully submersible for cleaning and use in water.
- Do not use the device if it appears damaged or compromised.
- Keep out of reach of children.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

Package Contents

- JIMMYJANE Form 2 Gripp device
- Magnetic USB charging cable
- Storage bag

Product Overview

The Form 2 Gripp features a unique twin-ear design and a patented Comfort Gripp finger holder for enhanced maneuverability. The device includes control buttons for power, mode selection, and speed adjustment.





Image: Main view of the JIMMYJANE Form 2 Gripp vibrator, showcasing its ergonomic shape and smooth silicone finish.



Image: A hand holding the Form 2 Gripp, illustrating how the patented Comfort Gripp finger holder allows for precise and natural control during use.

Charging Instructions

1. Locate the magnetic charging port on the device.
2. Connect the magnetic USB charging cable to the device's charging port, ensuring a secure connection.
3. Plug the USB end of the cable into a compatible USB power source (e.g., computer, wall adapter).
4. The device will indicate charging status (e.g., an LED light).
5. A full charge provides up to 60 minutes of runtime. Disconnect the charger once fully charged.

Operating Instructions

1. **Power On/Off:** Press and hold the power button for a few seconds to turn the device on or off.
2. **Mode Selection:** Once powered on, press the mode button to cycle through the 5 distinct vibration patterns.
3. **Speed Adjustment:** For each mode, press the speed button to adjust the intensity through 5 different speeds. This allows for a total of 25 unique vibration functions.
4. **Ergonomic Use:** Position your fingers through the Comfort Gripp holder to guide the device and target stimulation effectively.

Cleaning and Maintenance

- Clean the device thoroughly before and after each use.
- Wash with warm water and a mild, toy-safe soap, or use a dedicated toy cleaner.
- Rinse thoroughly and pat dry with a lint-free cloth.
- As the device is fully submersible (IPX7), it can be cleaned under running water.
- Avoid using harsh chemicals, alcohol-based cleaners, or petroleum-based lubricants, as these can damage the silicone material.

Storage

Store the JIMMYJANE Form 2 Gripp in its provided storage bag in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the device is clean and fully dry before storing.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on	Battery is depleted	Charge the device fully using the magnetic USB cable.
Device is not charging	Magnetic connection is not secure or USB power source is faulty.	Ensure the magnetic cable is firmly attached to the device. Try a different USB port or power adapter.
Vibrations feel weak	Low battery level.	Recharge the device.

Specifications

- **Model Name:** Form 2 Gripp
- **Item Model Number:** JJ10524
- **Brand:** Jimmyjane
- **Material:** Silicone
- **Batteries:** 1 Nonstandard Battery (included)
- **Package Dimensions:** 7.52 x 6.3 x 2.72 inches
- **Weight:** 15.84 ounces
- **Waterproof Rating:** IPX7 (fully submersible)
- **Runtime:** Up to 60 minutes per charge

Disposal Information

This product contains a rechargeable battery and electronic components. Do not dispose of it with general household waste. Please follow local regulations for the disposal of electronic waste and batteries to protect the environment.

Warranty and Support

For warranty information or technical support, please contact JIMMYJANE customer service. Refer to the product packaging or the official JIMMYJANE website for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09XBYYJ9J

More documents and user manuals: **https://manuals.plus/**