realme RMX3474

realme 9 5G Smartphone User Manual

Model: RMX3474

Introduction

This user manual provides essential information for the realme 9 (5G) Smartphone, model RMX3474. It covers setup, operation, maintenance, and troubleshooting to help you maximize your device's functionality. The realme 9 (5G) is equipped with a 2.4 GHz Octa-core processor, 4GB RAM, and 128GB internal storage, expandable via microSDXC. It runs on Android 11 and features a 5000mAh non-removable battery.

Setup

1. Unboxing and Initial Inspection

Carefully remove all components from the packaging. Verify that the smartphone, charging cable, and any other included accessories are present and undamaged.



Figure 1: Front view of the realme 9 5G smartphone, showcasing its display and front camera.

2. SIM Card and microSD Card Installation

The realme 9 (5G) supports Dual SIM functionality and a dedicated microSDXC slot for storage expansion. Locate the

SIM tray on the side of the device. Use the provided SIM ejector tool to open the tray. Insert your Nano-SIM cards and/or microSD card into the designated slots, ensuring correct orientation. Gently push the tray back into the device until it clicks into place.



Figure 2: Side view of the realme 9 5G smartphone, illustrating the location of the SIM tray and volume buttons.

3. Initial Charging

Before first use, it is recommended to fully charge the device. Connect the charging cable to the phone's charging port and the other end to a compatible power adapter. The device features a 5000mAh non-removable battery. A full charge ensures optimal performance and battery calibration.



Figure 3: Bottom view of the realme 9 5G smartphone, showing the charging port and speaker grille.

4. Powering On and Initial Setup Wizard

Press and hold the power button located on the side of the device until the realme logo appears. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, Google account sign-in, and security settings. The device runs on Android 11.0.

Operating Instructions

1. Basic Navigation

- **Touchscreen:** Interact with the device using touch gestures such as tap, swipe, pinch-to-zoom, and long press. The display technology is LCD with a resolution of 1080 x 2400.
- **Buttons:** The device features physical buttons for power and volume control.
- **Home Screen:** Access your applications, widgets, and notifications from the customizable home screen.

2. Connectivity

- **Wi-Fi:** Connect to wireless networks for internet access. Go to Settings > Network & internet > Wi-Fi.
- **Cellular Data:** Utilize 2G, 3G, 4G, and 5G cellular technologies for mobile internet. Ensure your SIM card is active and has a data plan. The device is unlocked for all carriers.
- **Bluetooth:** Pair with Bluetooth devices like headphones or speakers.
- **GPS:** The device supports GPS for location services and navigation.

3. Camera Usage

The realme 9 (5G) features a rear camera system. Open the Camera application to capture photos and videos. Explore various modes and settings available within the app.



Figure 4: Back view of the realme 9 5G smartphone, highlighting the multi-lens camera module.

4. Audio Features

The device does not include a traditional 3.5mm headphone jack. Audio output is primarily through the built-in speaker or

via Bluetooth headphones/adapters.

Maintenance

1. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of the phone. Avoid using harsh chemicals or abrasive materials, which can damage the finish. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner designed for electronics.

2. Battery Care

To prolong the life of your 5000mAh Lithium Polymer battery, avoid extreme temperatures. Do not expose the device to direct sunlight for extended periods or to very cold environments. Use only realme-approved chargers and cables. While the battery is non-removable, proper charging habits can maintain its health.

3. Software Updates

Regularly check for and install software updates. These updates often include performance improvements, security patches, and new features. You can usually find this option in Settings > System > System update.

4. Storage Management

Periodically review your stored files and applications. Delete unnecessary data to free up the 128GB internal storage. Utilize the dedicated microSDXC slot for additional storage if needed.

Troubleshooting

Common Issues and Solutions

- **Device Not Powering On:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, try a forced restart (usually by holding the power button and volume down button simultaneously for several seconds).
- **Poor Network Signal:** Check your SIM card insertion. Ensure you are within network coverage. If issues persist, contact your wireless carrier. The device supports various global frequencies (GSM, WCDMA, FDD-LTE, TDD-LTE, NR).
- **Battery Draining Quickly:** Reduce screen brightness, close unused apps running in the background, disable unnecessary connectivity features (Bluetooth, GPS) when not in use.
- **Apps Crashing/Freezing:** Clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache). If the issue continues, try reinstalling the app or performing a factory reset (back up your data first).
- **Storage Full:** Delete old photos/videos, uninstall unused apps, or move files to the microSD card.

For more complex issues or problems not listed here, please refer to the official realme support website or contact their customer service.

Specifications

Feature	Detail

Feature	Detail
Model Name	9
Item Model Number	RMX3474
Brand	realme
Operating System	Android 11.0
CPU Speed	2.4 GHz Octa-core
RAM	4 GB
Memory Storage Capacity	128 GB (expandable via microSDXC)
Battery Capacity	5000 Milliamp Hours (non-removable Lithium Polymer)
Screen Size	6.6 Inches
Display Technology	LCD
Resolution	1080 x 2400
Product Dimensions	6.47 x 2.98 x 0.33 inches
Item Weight	6.7 ounces (0.19 Kilograms)
Color	Black (Meteor Black)
Wireless Carrier	Unlocked for All Carriers
Cellular Technology	2G, 3G, 4G, 5G (GSM, WCDMA, FDD-LTE, TDD-LTE, NR)
Connectivity Technologies	Wi-Fi, Cellular
GPS	True
Human Interface Input	Touchscreen, Buttons
Audio Jack	No headphone jack
Other Camera Features	Rear
Phone Talk Time	41.36 Hours
Language Support	German, English, French, Italian, Spanish
Date First Available	January 25, 2023

Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product or visit the official realme website. Warranty terms and conditions may vary by region and retailer.

For technical support, service, or further inquiries, please contact realme customer service or visit their official support channels. You can find more information and resources on the realme Store on Amazon.

© 2024 realme. All rights reserved.