ghd 99350066565

ghd Unplugged Styler Instruction Manual

Model: 99350066565

Brand: ghd

Introduction

The ghd Unplugged Styler is a cordless, portable, and powerful flat iron designed for touch-ups and styling on the go. Its innovative technology maintains a consistent temperature of 365°F, which is scientifically proven to be the optimal temperature for styling hair with minimal damage. The styler features snag-free plates for versatile styling and comes with a heat-resistant case for convenient portability.



Image: The ghd Unplugged Styler, showcasing its sleek black design and compact form factor.

Safety Information

- Always ensure the styler is fully charged before use to avoid interruptions during styling.
- The styler operates at a preset temperature of 365°F (185°C). Do not attempt to alter this temperature.
- Avoid direct contact of the heated plates with skin or other surfaces to prevent burns or damage.
- The device features an automatic shut-off function after 3 minutes of non-usage to conserve battery and enhance safety.
- Allow the styler to cool completely before storing it in its heat-resistant case.
- Keep out of reach of children.



Image: A visual representation of the optimal styling temperature of 365°F, highlighting temperatures that are too hot or too cool for effective and safe styling.

What's in the Box

Your ghd Unplugged Styler package includes:

- ghd Unplugged Styler (1" Cordless Flat Iron)
- Heat-Resistant Case
- USB-C Cable
- Power Adapter



Image: The ghd Unplugged Styler shown alongside its protective heat-resistant case, designed for safe storage and travel.

Setup

Before first use, fully charge your ghd Unplugged Styler.

1. Connect the provided USB-C cable to the charging port on the styler.
2. Plug the other end of the USB-C cable into the power adapter.
3. Plug the power adapter into a suitable electrical outlet.
4. The battery indicator lights will illuminate to show charging progress. A full charge is indicated by five solid lights.
5. Allow approximately 2 hours for a full charge. A full charge provides up to 20 minutes of continuous styling time.



Image: A detailed view of the USB-C charging port on the ghd Unplugged Styler, indicating its modern charging capability.

Operating Instructions

1. **Power On:** Slide the power switch to the 'On' position. The styler will begin to heat up, indicated by flashing lights.
2. **Ready for Use:** The styler will reach its optimal styling temperature of 365°F in approximately 45 seconds. The indicator lights will become solid when ready.
3. **Styling:** Take a small section of dry hair and place it between the ceramic plates. Gently glide the styler from root to tip. The snag-free plates ensure smooth movement through the hair.
4. **Power Off:** Slide the power switch to the 'Off' position. The indicator lights will turn off.
5. **Cool Down:** Allow the styler to cool down for approximately 3 minutes before handling or storing.



Image: A close-up of the ghd Unplugged Styler's power switch and LED battery indicator, showing the user interface.



Image: A detailed view of the smooth ceramic plates of the ghd Unplugged Styler, designed for effortless gliding through hair.

Maintenance

- Ensure the styler is turned off and completely cool before cleaning.
- Wipe the ceramic plates and the body of the styler with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
- Do not immerse the styler in water or any other liquid.
- Store the styler in its heat-resistant case in a dry, safe place when not in use.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Styler not turning on or heating up.	Low battery or not charged.	Fully charge the styler using the provided USB-C cable and power adapter. Ensure the power switch is in the 'On' position.
Styler turns off unexpectedly during use.	Automatic shut-off activated due to inactivity.	The styler is designed to shut off after 3 minutes of non-usage. Turn the styler off and then back on to resume styling. Ensure it is fully charged for continuous use.
Hair is not straightening effectively.	Hair is not dry, or sections are too large.	Ensure hair is completely dry before styling. Work with smaller sections of hair for better results.

Specifications

- **Model Number:** 99350066565
- **Dimensions:** 8.6 x 2 x 1.6 inches
- **Weight:** 2 Pounds
- **Battery:** 1 Lithium Ion battery (included)
- **Charging:** USB-C
- **Optimal Styling Temperature:** 365°F (185°C)
- **Heat-up Time:** Approximately 45 seconds
- **Run Time:** Up to 20 minutes (fully charged)
- **Automatic Shut-off:** After 3 minutes of inactivity
- **Plate Material:** Ceramic
- **Manufacturer:** FLEX
- **GTIN/UPC:** 850011636060

Warranty and Support

For detailed warranty information and customer support, please refer to the official ghd website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

© 2024 ghd. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question