Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Broonel Fine Point Digital Active Stylus Pen

Broonel Fine Point Digital Active Stylus Pen User Manual

INTRODUCTION

Welcome to the user manual for your Broonel Fine Point Digital Active Stylus Pen. This stylus is designed to provide a precise and natural writing and drawing experience on compatible touch-screen devices.

A sleek black digital active stylus pen, featuring a fine point tip and a metallic clip, designed for precise interaction with touchscreens.

Setup

Inserting the Battery

The Broonel Fine Point Digital Active Stylus Pen requires one AAA battery for operation. Follow these steps to insert the battery:

1. Gently twist and pull the top cap of the stylus to open the battery compartment.
2. Insert one AAA battery, ensuring the polarity (+/-) matches the indicators inside the compartment.
3. Securely replace the top cap by twisting it back into place.

First Use

Once the battery is inserted, the stylus is ready for use. No Bluetooth pairing is required.

A detailed view of the stylus pen, highlighting the LED On/Off switch and the adjustable 2.3mm fine point nib, indicating key functional areas.

Operating Instructions

Powering On/Off

To power on the stylus, press the LED On/Off switch located on the barrel of the pen. The LED indicator will illuminate. To power off, press the switch again.

Using the Stylus

The stylus is designed for use with both iOS and Android tablet PCs and smartphones. Simply touch the fine point nib to your device's screen to interact.

The 2.3mm nib provides an accurate writing and sketching experience.

Adjusting Nib Sensitivity

The stylus features an adjustable nib, allowing for variating sensor depth. This can be adjusted to achieve more accurate depth of field and responsiveness depending on your device and application.

An overhead shot of the stylus pen resting on a tablet displaying a digital sketch, with a smartphone and a cup of coffee nearby, illustrating its use in a creative context.

A hand holding the stylus pen, actively drawing a detailed car design on a tablet screen, demonstrating its precision for digital art and

design.

A hand using the stylus on a tablet, which displays a split screen with different digital artworks, showcasing the stylus's versatility for various creative tasks.

Maintenance

Cleaning

To clean the stylus, gently wipe the body with a soft, dry cloth. Do not use abrasive cleaners or immerse the stylus in water.

Battery Replacement

When the stylus performance degrades or the LED indicator does not light up, it is time to replace the AAA battery. Follow the battery insertion steps outlined in the "Setup" section.

Storage

Store the stylus in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, remove the battery to prevent leakage.

Troubleshooting

Stylus Not Responding

- Ensure the stylus is powered on (LED indicator should be lit).
- Check the battery. Replace with a fresh AAA battery if necessary.
- Ensure your device's screen is clean and free of debris.
- Verify that your device is compatible with active stylus pens.

Inaccurate or Lagging Performance

- Adjust the nib sensitivity as described in the "Operating Instructions" section.
- Ensure your device's screen is clean.

- Close any unnecessary applications running in the background on your device to free up resources.
- Restart your tablet or smartphone.

Specifications

Feature	Detail
Model	Fine Point Digital Active Stylus Pen
Brand	Broonel
Color	Black
Material	Brass
Nib Size	2.3mm (Adjustable)
Power Source	1 x AAA Battery (Included)
Connectivity	No Bluetooth Required
Compatibility	IOS & Android Tablet PC & Smartphones (e.g., AWOW 10.1" Tablet)

Warranty and Support

Warranty Information

This Broonel product comes with a standard manufacturer's warranty. Please refer to the product packaging or the official Broonel website for specific warranty terms and conditions.

Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact Broonel customer support. Contact details can typically be found on the official Broonel website or your purchase documentation.

For more information, visit the official product page.

© 2024 Broonel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09YHKM99M

More documents and user manuals: **https://manuals.plus/**