KREAFUNK 18888

KREAFUNK aGO Mini Portable Bluetooth Speaker

User Manual

Introduction

Thank you for choosing the KREAFUNK aGO Mini Portable Bluetooth Speaker. This compact and water-resistant speaker is designed to deliver fine-tuned stereo sound for both indoor and outdoor use. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance.

What's in the Box

- aGO Mini Portable Bluetooth Speaker
- Charging Cable (USB-A to USB-C)
- User Manual (this document)

Product Overview

The aGO Mini is a compact and durable speaker, perfect for on-the-go audio. Its water-resistant design (IPX5) allows for versatile use in various environments.



Image: Front view of the KREAFUNK aGO Mini Portable Bluetooth Speaker in beige, showcasing its compact, spherical design and top speaker grille.

Key Features:

- **Fine-tuned Stereo Sound:** Despite its small size, the aGO Mini delivers clear and balanced audio.
- **Water Resistant (IPX5):** Designed to withstand splashes and light rain, making it suitable for outdoor use.
- **Long Playtime:** Up to 12 hours of wireless play on a single charge.
- **Quick Charging:** Fully charges within 1 hour.
- **Bluetooth Connectivity:** Seamlessly stream audio from any Bluetooth-enabled device within a 10-meter range.
- **Portable Design:** Lightweight (2.4 ounces) and compact (2"D x 2"W x 1.3"H), easily fits into a pocket or bag.

Setup

1. Charging the Speaker:

Before first use, fully charge your aGO Mini speaker.

1. Connect the included charging cable to the charging port on the speaker.
2. Connect the other end of the charging cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The charging indicator light will illuminate. It takes approximately 1 hour for a full charge.
4. Once fully charged, the indicator light will change or turn off (refer to specific light behavior in the operating section if available, otherwise assume standard).

2. Pairing with a Bluetooth Device:

To connect your speaker to a smartphone, tablet, or other Bluetooth-enabled device:

1. Ensure the aGO Mini speaker is powered on.
2. Activate Bluetooth on your device (e.g., phone settings).
3. The speaker will automatically enter pairing mode (or press and hold the power button if it has a dedicated pairing function, which is not specified but common). Look for a blinking indicator light.
4. On your device, search for available Bluetooth devices. Select "aGO Mini" (or similar name) from the list.
5. Once connected, the speaker will typically emit an audible confirmation tone, and the indicator light will become solid.

Your speaker is now ready for use.

Operating the Speaker

Power On/Off:

- To power on, press and hold the power button (location not specified, assume standard).
- To power off, press and hold the power button again.

Audio Playback:

Once paired, audio from your connected device will play through the aGO Mini speaker. Control playback (play/pause, skip tracks) directly from your connected device.

Volume Control:

Adjust the volume directly from your connected Bluetooth device.



Image: The KREAFUNK aGO Mini speaker in beige, placed on a concrete table next to a notebook, illustrating its use in an indoor

setting. A person is visible in the background, out of focus.

Stereo Pairing (TWS - True Wireless Stereo):

If you have two aGO Mini speakers, you can pair them together for a true wireless stereo experience. (Specific instructions for TWS pairing are not provided in the input, so a general statement is made).
Note: Refer to the official KREAFUNK website or support for detailed True Wireless Stereo pairing instructions if needed.



Image: Two KREAFUNK aGO Mini speakers in beige, positioned on a surface alongside travel accessories such as a straw hat, sunglasses, a passport, and currency, highlighting their portability and suitability for travel.

Maintenance

- **Cleaning:** Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The speaker is IPX5 water-resistant, meaning it can withstand splashes. Do not submerge the speaker in water. Ensure the charging port cover is securely closed when near water.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is drained.	Charge the speaker for at least 1 hour.
Cannot pair with Bluetooth device.	Bluetooth is off on device; speaker is not in pairing mode; device is out of range; previously paired device is connected.	Ensure Bluetooth is enabled on your device. Make sure the speaker is in pairing mode (blinking light). Move device closer to speaker (within 10 meters). Disconnect from other devices or turn off Bluetooth on them.
No sound or low volume.	Volume on speaker or device is too low; speaker is not connected; audio source issue.	Increase volume on both the speaker and your connected device. Ensure the speaker is successfully paired. Check if the audio is playing correctly on your source device.
Sound distortion.	Volume too high; device too far from speaker; interference.	Lower the volume. Move the device closer to the speaker. Avoid placing the speaker near other electronic devices that may cause interference.

Specifications

Model Name	aGO mini
Model Number	18888
Brand	KREAFUNK
Material	Plastic, Metal
Speaker Type	Outdoor and Indoor
Special Feature	Waterproof (IPX5), Lightweight
Product Dimensions	2"D x 2"W x 1.3"H
Item Weight	2.4 ounces
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters (32.8 Feet)
Battery Life	Up to 12 Hours
Charging Time	1 Hour
Power Source	Battery Powered
Audio Output Mode	Stereo
Speaker Maximum Output Power	3 Watts

Compatible Devices	Laptop, Television, Tablet, Smartphone
Included Components	Charging Cable
Country of Origin	China

Warranty & Support

Warranty Information:

The KREAFUNK aGO Mini Portable Bluetooth Speaker comes with a limited warranty. Please retain your proof of purchase for warranty claims. For specific terms and conditions of the warranty, refer to the documentation included with your product or visit the official KREAFUNK website.

Customer Support:

For further assistance, technical support, or warranty inquiries, please contact KREAFUNK customer service. You can find contact information on the official KREAFUNK website:

www.kreafunk.com

Please have your product model number (18888) and purchase details ready when contacting support.

© 2024 KREAFUNK. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question