Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iJoy IJHP21

iJoy Ultra Wireless Headphones User Manual

Model: IJHP21

Introduction

The iJoy Ultra Wireless Headphones are designed to provide a comfortable and immersive audio experience. Featuring Bluetooth connectivity, a built-in microphone, and versatile playback options, these headphones are suitable for various activities, from daily commutes to sports and exercise. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device.



Image: iJoy Ultra Wireless Headphones in black, showcasing the sleek design.

Package Contents

Ensure all items are present in your package:

- iJoy Ultra Wireless Headphones
- USB Type-C Charging Cable
- 3.5mm Audio Cable (AUX)
- User Manual (this document)



Image: The iJoy Ultra headphones along with the included USB-C charging cable and 3.5mm audio cable.

Product Overview

Familiarize yourself with the various components and controls of your iJoy Ultra headphones.

Controls and Ports:

Power Button (Center): Power On/Off, Play/Pause music, Answer/Reject/Hang up calls.

Volume Up / **Next Track Button (+)**: Press and hold to increase volume; single press to skip to the next song.

Volume Down / **Previous Track Button (-)**: Press and hold to decrease volume; single press to go back to the last song.

USB-C Charging Port: For charging the headphones.

AUX Port (3.5mm): For wired audio connection.

Micro SD Card Slot: For playing music directly from a Micro SD card.

Microphone: Built-in for calls.

LED Indicator: Shows power, pairing, and charging status.



Image: Close-up view of the headphone's side, highlighting the USB-C charging port, AUX port, and Micro SD card slot.



Image: Diagram illustrating the function of each control button on the headphone.

Setup

1. Charging the Headphones:

Before first use, fully charge your headphones. Connect the provided USB Type-C cable to the charging port on the headphone and the other end to a USB power source (e.g., computer, wall adapter). The LED indicator will show charging status and turn off when fully charged. A full charge provides approximately 10 hours of playtime.

2. Bluetooth Pairing:

1. Ensure the headphones are turned off.
2. Press and hold the **Power Button** until the LED indicator blinks red and blue, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for "iJoy Ultra" in the list of available

devices.

4. Select "iJoy Ultra" to connect. Once connected, the LED indicator will stop blinking and remain solid blue.

3. Wired Connection (AUX Mode):

If the battery is depleted or you prefer a wired connection, use the included 3.5mm audio cable. Plug one end into the AUX port on the headphones and the other end into your audio device's 3.5mm jack. The headphones will automatically switch to wired mode.

4. Micro SD Card Playback:

Insert a Micro SD card (with pre-loaded music files) into the Micro SD card slot until it clicks into place. The headphones will automatically detect the card and begin playing music. Use the control buttons to manage playback.

Your browser does not support the video tag.

Video: Official iJoy demonstration of the Ultra Bluetooth Over Ear Headphones, including setup and feature highlights.

Operating Instructions

Power On/Off:

To power on, press and hold the **Power Button** until the LED indicator lights up.

To power off, press and hold the **Power Button** until the LED indicator turns off.

Music Playback:

Play/Pause: Short press the **Power Button**.

Next Track: Short press the **+ Button**.

Previous Track: Short press the **- Button**.

Volume Up: Press and hold the **+ Button**.

Volume Down: Press and hold the **- Button**.

Call Management:

Answer Call: Short press the **Power Button** when a call comes in.

End Call: Short press the **Power Button** during a call.

Reject Call: Press and hold the **Power Button** when a call comes in.

FM Radio Mode:

The headphones feature a built-in FM radio. To activate, short press the **Power Button** twice rapidly. Use the **+** and **-** buttons to scan through radio stations. Note that FM reception may vary based on location.

Maintenance

To ensure the longevity and optimal performance of your iJoy Ultra headphones, follow these maintenance guidelines:

- **Cleaning**: Use a soft, dry cloth to wipe the headphones. Do not use abrasive cleaners or solvents.
- **Storage**: Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care**: Avoid fully discharging the battery frequently. Charge regularly to maintain battery health.
- **Avoid Moisture**: Do not expose the headphones to water or excessive moisture.

Troubleshooting

If you encounter issues with your iJoy Ultra headphones, refer to the following common problems and solutions:

Problem	Solution
Headphones do not power on.	Ensure the headphones are charged. Connect to a power source and try again.
Cannot pair via Bluetooth.	◦ Ensure headphones are in pairing mode (blinking red/blue LED). ◦ Turn off and on Bluetooth on your device. ◦ Move headphones closer to your device. ◦ Forget "iJoy Ultra" from your device's Bluetooth list and re-pair.
No sound or low volume.	◦ Adjust volume on both headphones and connected device. ◦ Ensure headphones are properly connected (Bluetooth or AUX). ◦ If using AUX, ensure the cable is fully inserted and not damaged.
Microphone quality is poor.	Ensure the microphone is not obstructed. Speak clearly and at a normal volume.
Micro SD card not recognized.	Ensure the card is inserted correctly and contains compatible audio files. Try re-inserting the card.

Specifications

Feature	Detail
Model Name	Ultra
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth
Headphones Jack	3.5 mm Jack
Battery Life	Up to 10 Hours Playtime
Bluetooth Range	10 Meters
Earpiece Shape	Over-Ear Cups
Control Type	Media Control
Item Weight	12.3 ounces
Product Dimensions	7 x 3 x 8 inches
Manufacturer	Quest USA Corp
Country of Origin	China

Warranty and Support

iJoy products are manufactured with high-quality standards. For any warranty claims, technical support, or inquiries, please contact iJoy customer service. Refer to the product packaging or the official iJoy website for the most current contact information.
For more information, visit the official iJoy Store on Amazon.

© 2024 iJoy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09YTFD4LS

More documents and user manuals: **https://manuals.plus/**