Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit Replacement Remote Control for Soundbars

ZdalaMit Replacement Remote Control Instruction Manual

For Norcent, MEGACRA, BYL, and Bestisan Soundbars

Introduction

This document provides instructions for the ZdalaMit Replacement Remote Control, designed for use with various Norcent, MEGACRA, BYL, and Bestisan soundbar models. This remote control requires no programming and is ready for use after battery installation.

Setup: Battery Installation

The remote control operates using two (2) AAA size alkaline batteries. Batteries are not included with the remote control and must be purchased separately.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

Once batteries are installed, the remote control is ready for immediate use with compatible soundbar models. No additional programming or pairing is required.



Image: An angled view of the ZdalaMit replacement remote control, showing its ergonomic design and button layout.

Operating Instructions

This section details the functions of the buttons on your replacement remote control.





Image: A top-down view of the ZdalaMit replacement remote control, clearly showing all buttons and their labels.

- **Power Button (Red Circle with Line)**: Turns the soundbar on or off.
- **MUTE Button**: Mutes or unmutes the sound.
- **AUDIO MODE Buttons (MOVIE, MUSIC, DIALOG)**: Selects different audio equalization modes for optimized sound experience.
- **BT Button**: Switches the soundbar to Bluetooth input mode.

- **USB Button**: Switches the soundbar to USB input mode.
- **AUX Button**: Switches the soundbar to Auxiliary input mode.
- **OPT Button**: Switches the soundbar to Optical input mode.
- **COAX Button**: Switches the soundbar to Coaxial input mode.
- **RESET Button**: Resets sound settings or the soundbar to default.
- **VOL+ / VOL- Buttons**: Increases or decreases the main volume level.
- **Play/Pause Button (►//)**: Plays or pauses media playback.
- **Skip Forward / Skip Backward Buttons (◄ / ►)**: Skips to the previous or next track/chapter.
- **TREB + / TREB - Buttons**: Increases or decreases the treble level.
- **BASS + / BASS - Buttons** Increases or decreases the bass level.
- **Speaker Mute Button ()**: Mutes or unmutes the speaker output.

Compatible Soundbar Models

This replacement remote control is compatible with the following soundbar models:

- Norcent Soundbar: MB-3220, MB-3221NS, MB-2521
- MEGACRA Soundbar: SE02, S8520, SE01, ST09, ST08, SQ03, SG08, SG02, SR01, SD08, S7021B, SR04, SR02, SR06, S7020P, S7020E, S6520, S7020, S9920
- BYL Soundbar (models listed under MEGACRA compatibility)
- Bestisan Soundbar (models listed under MEGACRA compatibility)

Maintenance

To ensure optimal performance and longevity of your remote control, follow these maintenance guidelines:

- **Cleaning**: Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners, aerosols, or harsh chemicals, as these can damage the surface or internal components.
- **Battery Replacement**: Replace batteries promptly when the remote control's responsiveness decreases. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries or different types of batteries.
- **Storage**: Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- **Handling**: Avoid dropping the remote control or subjecting it to strong impacts, which can damage internal circuitry.

Troubleshooting

If you experience issues with your remote control, consider the following common solutions:

- **Remote Not Responding**: Ensure the batteries are inserted correctly with the correct polarity (+/-). Replace the batteries with new AAA alkaline batteries.
- **Interference**: Ensure there are no obstructions between the remote control and the soundbar's infrared receiver. Move closer to the soundbar and point the remote directly at it.
- **Soundbar Not Responding**: Verify that the soundbar is powered on and functioning correctly. Test the

soundbar with its original remote control if available, or manually.

Specifications

Brand	ZdalaMit
Manufacturer	ZdalaMit Factory
Product Dimensions	6 x 2 x 0.5 inches (approximately)
Item Weight	1.41 ounces (approximately)
Batteries Required	2 x AAA size alkaline batteries (not included)
Special Feature	Ergonomic design
Color	Black
Max Number of Supported Devices	1 (one soundbar)
Compatible Devices	Home Theater Soundbars (specific models listed above)

Support

Should you have any questions or require further assistance regarding your ZdalaMit Replacement Remote Control, please do not hesitate to contact our customer support.

© 2023 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09YTQDHZM

More documents and user manuals: **https://manuals.plus/**