ALLIMITY CV-PROSCAN-N

ALLIMITY Replacement Remote Control Instruction Manual

Brand: ALLIMITY | **Model:** CV-PROSCAN-N

1. Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your ALLIMITY CV-PROSCAN-N Replacement Remote Control. This remote is designed as a direct replacement for various Proscan and Curtis television models, offering immediate functionality without complex programming.

2. Product Overview

2.1 Key Features

- Direct replacement functionality, no programming required.
- Compatible with a wide range of Proscan and Curtis TV models.
- Infrared (IR) connectivity.
- Ergonomic design for comfortable use.

2.2 Compatible TV Models

This remote control is compatible with the following Proscan and Curtis TV models:

- **Proscan TV Models:** PLC3708A, PLCD3271AB, PLED1526A-B, PLED2243A, PLCD3271A-C, PLCD3271A, PLCD3273A-B, PLCD3283A, PLCD3717A, PLCD3903A-B, PLCD4692A, PLCD5092A-B, PLDED3257A-B, PLCD5092AB, PLDED3257A-C, PLDED3273A, PLDED3992A-C, PLDED3996A-C, PLDED3996A-C2, PLDED4016A, PLDED5066AE, PLDED5066A-E, PLED1526AB, PLED2694A, PLED2845A, PLED3216A, PLED4011A, PLED4017A, PLED4274A, PLED4616A, LCD1908A, LCD1933, PLED5529A-C, LCD1933A, LCD2425A, LCD2443A, LCD3227A, LCD3235A, LCD3708A, LCD4077A, LCD4620A, LCD4686A, LCD4686A-W, LED1337A, LED1526A, LED2415A, RLC3209A, RLC3255A-B, RLC3273A-B, RLC3708A, RLC3708A-B, RLD5515A-C, RLDED3258A-C, RLDED3955A, RLDED2845A, RLDED4016A, RLDED4633A-C, RLDED5078A-D, RLED1526A-BLACK, RLED1530, RLED3216A, RLED3219A, RLED1530-WHITE, RLED2243A, RLED4010A, RLED4627A-B, RLED4633B, RLED4778A, 32LA25T, RLED5592A-B.
- **Curtis TV Models:** (Specific models not detailed in product information, but general compatibility is stated.)

2.3 Remote Control Layout


MUTE
INFO
SOURCE
1
2
3
PMODE
4
5
6
SMODE
7
8
9
SLEEP
0
VOL+
CH+
MENU
VOL−
CH−
CC
MTS
ENTER
EXIT
EPG
FAV
FAV+
FAV−



Image 1: Front view of the ALLIMITY CV-PROSCAN-N remote control. The remote is black with gray buttons, including a power button, number pad, volume and channel controls, menu navigation, and various function buttons like Mute, Info, Source, PMode, SMode, Sleep, CC, MTS, Enter, Exit, EPG, FAV, FAV+, and FAV-.

3. Setup

3.1 Battery Installation

The remote control requires two AAA batteries (1.5V each) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to remove it.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Image 2: Back view of the remote control with the battery cover open, illustrating the correct orientation for inserting two AAA batteries.

After battery installation, the remote is ready for use with compatible Proscan and Curtis TVs without any additional programming.

4. Operating Instructions

4.1 Basic Functions

Point the remote control directly at your television's infrared receiver. Ensure there are no obstructions between the remote and the TV.

4.2 Button Descriptions

Button	Function
Power (Red)	Turns the television on or off.
MUTE	Mutes or unmutes the television audio.
INFO	Displays current program information.
SOURCE	Cycles through available input sources (e.g., HDMI, AV).
PMODE	Adjusts picture modes (e.g., Standard, Dynamic, Movie).
SMODE	Adjusts sound modes (e.g., Standard, Music, Movie).
SLEEP	Sets a timer for the TV to automatically turn off.

Button	Function
Number Buttons (0-9)	Direct channel selection.
VOL+ / **VOL-**	Increases or decreases the volume level.
CH+ / **CH-**	Changes the television channel up or down.
MENU	Opens the television's main menu.
Navigation Arrows (Up, Down, Left, Right)	Navigates through menu options.
ENTER	Confirms a selection in the menu.
EXIT	Exits the current menu or on-screen display.
CC	Activates or deactivates Closed Captions.
MTS	Selects Multi-channel Television Sound (e.g., Stereo, SAP).
EPG	Displays the Electronic Program Guide.
FAV / **FAV+** / **FAV-**	Accesses or navigates through favorite channels.

5. Troubleshooting

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote Not Responding:**
  - Ensure batteries are inserted correctly with proper polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
- **Limited Range:**
  - Ensure the remote is pointed directly at the TV.
  - Verify that the batteries are not low.
  - Avoid strong light sources (e.g., direct sunlight, fluorescent lights) that might interfere with the IR signal.
- **Specific Buttons Not Working:**
  - This remote is a direct replacement; no programming is needed. If a button does not function, it may not be supported by your specific TV model or the TV's firmware.
  - Clean the remote's surface and buttons to ensure no debris is interfering with button presses.

6. Specifications

- **Model:** CV-PROSCAN-N
- **Dimensions:** 5 x 1.5 x 0.5 inches (approximately)
- **Item Weight:** 2.08 ounces (without batteries)
- **Battery Type:** 2 x AAA (1.5V) alkaline batteries
- **Connectivity:** Infrared (IR)
- **Max Number of Supported Devices:** 1 (designed for specific TV models)

7. Support and Warranty

7.1 Customer Support

If you have further questions or require assistance, please contact the seller or manufacturer through the platform where the product was purchased. Provide your product model number (CV-PROSCAN-N) and a detailed description of the issue for efficient support.

7.2 Warranty Information

Specific warranty details for this product are not provided in the available information. Please refer to the product listing or contact the seller directly for any warranty-related inquiries.