Fresh A15-60-SR

Fresh A15-60-SR 60cm Dishwasher User Manual

Model: A15-60-SR | Brand: Fresh

Introduction

Thank you for choosing the Fresh A15-60-SR 60cm Dishwasher. This manual provides essential information for the safe and efficient use of your appliance. Please read these instructions carefully before installation, operation, and maintenance. Keep this manual for future reference.

Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury to persons.

- Read all instructions before using the dishwasher.
- This appliance is intended for household use only.
- Do not operate the dishwasher if it is damaged or malfunctioning. Contact authorized service personnel.
- Keep children away from the dishwasher, especially when the door is open. Detergent residues can be harmful.
- Use only detergents and rinse aids specifically designed for automatic dishwashers.
- Never use abrasive cleaners or sharp objects to clean the dishwasher.
- Ensure the dishwasher is properly grounded according to local codes and ordinances.
- Do not overload the dishwasher or place items that are not dishwasher-safe.
- Sharp items should be loaded with handles up to prevent injury.

Setup and Installation

Proper installation is crucial for the performance and longevity of your dishwasher. It can be installed as a built-in unit or freestanding.

Unpacking

Carefully remove all packaging materials. Inspect the dishwasher for any damage during transit. Report any damage to your retailer immediately.

Placement and Dimensions

Position the dishwasher on a level, stable surface. Ensure adequate space for door opening and connections. The dimensions of the dishwasher are 45 cm (Depth) x 60 cm (Width) x 85 cm (Height).



Image: Dishwasher dimensions showing 45cm depth, 60cm width, and 85cm height. This helps in planning the installation space.



Image: Side view of the Fresh A15-60-SR dishwasher, providing a visual reference for its profile during installation.

Water and Electrical Connections

Connect the dishwasher to a cold water supply using new hoses. Ensure all connections are tight to prevent leaks. The dishwasher requires a 220 Volt electrical supply. Consult a qualified technician for electrical and plumbing connections if you are unsure.

Leveling

Adjust the leveling feet to ensure the dishwasher is perfectly level. This prevents vibrations and ensures proper door closure.

Operating Instructions

Follow these steps for optimal cleaning performance.

Control Panel Overview

The dishwasher features a push-button control panel for easy program selection and operation.



Image: Close-up view of the dishwasher's control panel, showing various program and function buttons.

Loading the Dishwasher

This dishwasher is designed to accommodate 12 place settings. The upper and lower racks are designed to hold a large quantity of tableware. Ensure items do not block the spray arms.



Image: Interior view of the dishwasher with both upper and lower racks, demonstrating loading capacity.



Image: Close-up of the cutlery basket, showing how to properly place forks, knives, and spoons.

Adding Detergent and Rinse Aid

Open the detergent dispenser and fill it with the recommended amount of dishwasher detergent. Fill the rinse aid dispenser as needed. Refer to the detergent and rinse aid manufacturer's instructions for dosage.



Image: Close-up of the detergent and rinse aid dispenser compartments, indicating where to add cleaning agents.

Selecting a Wash Program

The dishwasher offers 6 wash programs, including:

- **Normal:** For daily soiled dishes and glassware.
- **Delicate:** For lightly soiled or fragile items.
- **Rinse:** A quick rinse cycle for dishes to be washed later.
- **Energy Save:** An economical program for normally soiled dishes.
- **Heavily Soiled Program:** Specifically designed for heavily soiled and long-used dishes.

Select the appropriate program using the control panel buttons.

Starting a Cycle

Close the dishwasher door firmly. Press the Start/Pause button to begin the selected wash cycle. The dishwasher will automatically dry and sterilize at 72°C during the drying phase for enhanced hygiene.

Maintenance and Care

Regular maintenance ensures optimal performance and extends the life of your dishwasher.

Cleaning Filters

The filter system should be checked and cleaned regularly to prevent food particles from recirculating and affecting wash performance. Remove the filter assembly, rinse it under running water, and brush away any stubborn debris. Reassemble and replace correctly.

Cleaning Spray Arms

The dishwasher is equipped with two water spray arms (top and bottom) for optimal water distribution. Periodically check the spray arm nozzles for blockages. If necessary, remove the spray arms and clear any obstructions with a thin wire.

Exterior Cleaning

Wipe the exterior surfaces of the dishwasher with a soft, damp cloth. For stainless steel surfaces, use a specialized stainless steel cleaner. Avoid abrasive cleaners or scouring pads.

Interior Cleaning

Run a dishwasher cleaning cycle periodically using a dishwasher cleaner to remove grease and limescale buildup.

Troubleshooting

Before contacting service, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Dishwasher does not start	Power cord not plugged in; door not closed properly; fuse blown.	Check power connection; ensure door is latched; check household fuse/breaker.
Poor cleaning results	Improper loading; clogged spray arms; insufficient detergent; clogged filters.	Reload dishes correctly; clean spray arm nozzles; add more detergent; clean filters.
Water not draining	Clogged drain hose; clogged filter; drain pump malfunction.	Check and clear drain hose; clean filters; contact service if pump is faulty.
Excessive noise	Dishes rattling; foreign object in pump; improper installation.	Rearrange dishes; check for foreign objects; ensure dishwasher is level.

If the problem persists after attempting these solutions, please contact Fresh customer support.

Product Specifications

Feature	Detail
Brand Name	Fresh
Model Number	A15-60-SR
Product Type	Dishwasher
Installation Type	Built-in or Freestanding
Product Dimensions (DxWxH)	45 cm x 60 cm x 85 cm
Color	Silver

Feature	Detail
Control Type	Push Button
Materials	Stainless Steel (Interior, Basket, Rack)
Noise Level	12 Decibels
Included Components	Dishwasher
Finish Type	Glossy
Form Factor	Freestanding
Voltage	220 Volts
Cycle Options	Normal, Delicate, Rinse, Energy Save (6 programs total)
Number of Place Settings	12
Item Weight	42 Kilograms
Recommended Uses	Daily dishes, glassware, pots, pans, delicate china
Country of Origin	Egypt
Part Number	500013746

Warranty and Support

Your Fresh A15-60-SR Dishwasher comes with a two-year warranty from the date of purchase. For any technical support, service requests, or warranty claims, please contact the Fresh customer support hotline.
Fresh Hotline for Support: 19059
Please have your model number (A15-60-SR) and proof of purchase ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question