Survivor Filter W200

Survivor Filter Active All-Terrain Water Bottle

Model: W200 - Instruction Manual

1. Introduction

The Survivor Filter Active All-Terrain Water Bottle (Model W200) is designed to provide safe, clean drinking water from various sources, including tap water, rivers, lakes, and streams. This BPA-free bottle features an advanced filtration system that removes 99.99% of bacteria and parasites, meeting ANSI/NSF 42 & 53 standards. It is ideal for outdoor activities such as hiking, camping, and running, offering a reliable hydration solution.

2. Safety Information

- **Do not filter saltwater:** The filter is not designed to remove salt from water.
- **Avoid chemically contaminated water:** This filter is not intended for filtering industrial chemicals, heavy metals (beyond specified removal), or other chemical contaminants.
- **Use with caution:** While highly effective, always use the clearest water available. If water is visibly turbid, pre-filter with a cloth if possible.
- **Secure all parts:** Ensure the filter and lids are securely tightened to prevent leaks and maintain filtration integrity.
- **Keep out of reach of children:** Small parts could be a choking hazard.

3. Package Contents

Verify that all items are present in your package:

- 1x Active All-Terrain Bottle (1 Liter / 33.8 oz)
- 1x Filter (378-Liter Capacity)
- 1x Leakproof Lid (for use with filter)
- 1x Dome Lid (for use without filter)
- 1x Neoprene Carrying Case
- 1x 3ft Shoulder Strap
- 1x 7ft Shoulder Strap



Figure 3.1: All components included in the Survivor Filter Active All-Terrain Water Bottle package.

4. Setup and First Use

1. **Unpack Components:** Remove all items from the packaging.
2. **Initial Cleaning:** Wash the bottle and both lids with warm, soapy water. Rinse thoroughly. Do**not** wash the filter with soap; rinse it only with clean water.
3. **Assemble Filter:** Insert the filter into the leakproof lid (the black and blue lid). Ensure it is seated firmly.
4. **Attach Lid:** Screw the leakproof lid with the filter onto the bottle. Tighten securely to prevent leaks.
5. **Priming the Filter:** Fill the bottle with clean tap water. Squeeze the bottle to force water through the filter and out the mouthpiece. Discard the first bottle full of water. Repeat this process 2-3 times to ensure the filter is fully primed and any manufacturing residue is flushed out.
6. **Prepare Carrying Case:** If using, attach the desired shoulder strap (3ft or 7ft) to the neoprene carrying case.



Figure 4.1: Assembling the filter into the bottle lid.

5. Operating Instructions

5.1. Filtering Water

1. **Fill Bottle:** Unscrew the leakproof lid and fill the bottle with water from your desired source (river, lake, tap).
2. **Secure Lid:** Screw the leakproof lid with the filter firmly back onto the bottle.
3. **Drink:** Open the mouthpiece on the leakproof lid. Squeeze the bottle gently to force water through the filter and drink. The flow rate may vary depending on the water source and filter condition.



Figure 5.1: Filling the bottle from a natural water source.

5.2. Using Without Filter (Dome Lid)

For situations where filtration is not required, such as carrying pre-purified water, you can use the dome lid:

1. **Remove Filtered Lid:** Unscrew the leakproof lid with the filter.
2. **Attach Dome Lid:** Screw the dome lid onto the bottle.
3. **Drink:** Open the mouthpiece on the dome lid and drink as you would from a standard water bottle.



Figure 5.2: Bottle configurations: with dome lid (left) and with leakproof lid and filter (right).

5.3. Using the Neoprene Carrying Case

The included neoprene carrying case provides protection and portability:

- **Insert Bottle:** Place the bottle into the carrying case.
- **Attach Strap:** Connect either the 3ft or 7ft shoulder strap to the D-rings on the case for hands-free carrying.
- **Storage:** Utilize the front pocket of the case to store small items like a phone, keys, or wallet.



Figure 5.3: Neoprene carrying case with storage for essentials.



Figure 5.4: User wearing the bottle in its neoprene carrier system.

6. Maintenance

6.1. Cleaning the Bottle and Lids

After each use, especially when filtering from natural sources:

- Disassemble the bottle, filter, and lids.
- Wash the bottle and both lids with warm, soapy water. Use a bottle brush if necessary to reach all areas.
- Rinse thoroughly with clean water to remove all soap residue.
- Allow all parts to air dry completely before reassembling or storing.

6.2. Cleaning the Filter

The filter should be back-flushed regularly to maintain flow rate and extend its lifespan:

- Remove the filter from the lid.

- Using a clean water source (e.g., tap), force water through the filter in the opposite direction of normal flow (from the mouthpiece side towards the intake side). This helps dislodge trapped particles.
- Do **not** use soap or harsh chemicals on the filter.
- Allow the filter to air dry completely before storage.

6.3. Filter Replacement

The filter has a capacity of 378 liters (approximately 100 gallons) or should be replaced every 3 months of daily use, whichever comes first. Replace the filter sooner if you notice a significant decrease in flow rate that cannot be resolved by back-flushing, or if the water taste or odor changes.

7. Troubleshooting

Problem	Possible Cause	Solution
Slow water flow	Filter is clogged with sediment or airlocked.	Back-flush the filter (see Section 6.2). Ensure the bottle is squeezed firmly. If flow does not improve, replace the filter.
Water leaking from lid	Lid not tightened properly or O-ring is damaged/missing.	Ensure the lid is screwed on tightly and evenly. Check the O-ring inside the lid for proper placement and any damage.
Unpleasant taste/odor after filtering	Filter needs priming or replacement.	Ensure the filter was properly primed on first use. If the issue persists, replace the filter. Avoid filtering heavily contaminated water.

8. Specifications

Feature	Detail
Model Name	Active All-Terrain Bottle
Model Number	W200
Capacity	1 Liter (33.8 Ounces)
Bottle Material	Low Density Polyethylene (BPA Free)
Filter Capacity	378 Liters (approx. 100 Gallons)
Product Dimensions	3.5"W x 9.5"H
Item Weight	3.9 Ounces
Filtration Standard	ANSI/NSF 42 & 53
Care Instructions	Hand Wash Only
Reusability	Reusable

9. Product Video



Video 9.1: An overview of the Survivor Filter Active All-Terrain bottle, showcasing its features and use in various environments.

10. Warranty

The Survivor Filter Active All-Terrain Water Bottle comes with a **Lifetime Product Warranty**. This warranty covers all manufacturing defects and other defects that may arise during the product's lifespan. For any warranty claims or issues, please refer to the support section below.

11. Support

For further assistance, technical support, or warranty claims, please contact Survivor Filter customer service. Our knowledgeable team is available to help resolve any concerns you may have.
Please have your order details and any relevant photos ready to streamline the support process.
Visit the official Survivor Filter website for contact information and additional resources:Survivor Filter Store

© 2026 Survivor Filter. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question