**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## onerbl EPC-1013, EPC-607, EPC-1013OR, EPC-607R, EPC-607BL, EPC-808, EPC-808R

# onerbl AC Power Cord Instruction Manual

For Maxi-Matic Elite Platinum Pressure Cookers (Models EPC-1013, EPC-607, EPC-1013OR, EPC-607R, EPC-607BL, EPC-808, EPC-808R)

## 1. Setup and Installation

This section provides instructions for safely connecting your onerbl AC Power Cord to your Maxi-Matic Elite Platinum Pressure Cooker.

### 1.1 Unpacking and Inspection

- Carefully remove the AC power cord from its packaging.
- Inspect the power cord for any visible signs of damage, such as cuts, frayed wires, or bent prongs. Do not use the cord if any damage is observed.
- Ensure the power cord is the correct type for your Maxi-Matic Elite Platinum Pressure Cooker model (EPC-1013, EPC-607, EPC-1013OR, EPC-607R, EPC-607BL, EPC-808, EPC-808R).



**Figure 1:** The onerbl AC Power Cord, showing the standard Type B plug and the IEC C7 connector. This cord is designed for specific Maxi-Matic Elite Platinum Pressure Cooker models.

## 1.2 Connecting the Power Cord

1. Ensure your Maxi-Matic Elite Platinum Pressure Cooker is turned off and unplugged from any power source.
2. Locate the power input port on your pressure cooker. This port is typically a two-pin receptacle designed to accept an IEC C7 connector.
3. Align the IEC C7 connector end of the onerbl AC Power Cord with the power input port on the pressure cooker.
4. Gently push the connector firmly into the port until it is fully seated. Do not force the connection.
5. Once the cord is securely connected to the pressure cooker, insert the standard Type B plug end into a grounded electrical outlet.
6. Verify that the connection is snug at both ends to prevent intermittent power supply.



**Figure 2:** Detailed view of the power cord connectors, showing the robust construction for reliable power delivery.

## 2. Operation

The onerbl AC Power Cord is designed for straightforward operation. Once properly connected, it facilitates power delivery to your compatible Maxi-Matic Elite Platinum Pressure Cooker.

### 2.1 Powering Your Device

- After connecting the power cord as described in Section 1.2, ensure the pressure cooker's power switch (if applicable) is in the "Off" position before plugging into the wall outlet.
- Plug the Type B end of the power cord into a standard 120V AC wall outlet.
- Turn on your Maxi-Matic Elite Platinum Pressure Cooker using its integrated power controls.
- The power cord acts as a conduit for electrical current and does not require any user interaction beyond proper connection.

### 2.2 Important Safety Considerations

- Do not overload electrical outlets.
- Avoid running the power cord under carpets or in high-traffic areas where it could be damaged or create a tripping hazard.
- Always grasp the plug, not the cord, when disconnecting from the wall outlet.
- Ensure the power cord is not kinked, twisted, or subjected to excessive tension.

## 3. Maintenance and Care

Proper maintenance extends the lifespan of your onerbl AC Power Cord and ensures safe operation.

### 3.1 Cleaning

- Before cleaning, always unplug the power cord from both the wall outlet and the pressure cooker.
- Wipe the cord with a soft, dry, or slightly damp cloth. Do not use harsh chemicals, abrasive cleaners, or immerse the cord in water.
- Ensure the cord is completely dry before reconnecting it to any power source.

### 3.2 Storage

- When not in use, store the power cord in a cool, dry place, away from direct sunlight and extreme temperatures.
- Avoid tightly coiling or bending the cord, as this can damage the internal wires. A loose coil is preferable.
- Keep the cord away from sharp objects or surfaces that could cut or abrade the outer insulation.

## 4. Troubleshooting

If your Maxi-Matic Elite Platinum Pressure Cooker is not receiving power, follow these troubleshooting steps:

- **No Power to Device:**
  - Ensure the power cord is securely plugged into both the pressure cooker and the wall outlet.
  - Check the wall outlet by plugging in another known working appliance to confirm it is supplying power.
  - Inspect the power cord for any visible damage (cuts, kinks, exposed wires). If damaged, discontinue use and replace the cord.
  - Verify that the pressure cooker's power switch is in the "On" position.
- **Loose Connection:**
  - If the cord feels loose at either connection point, unplug it and re-insert it firmly.
  - If the connection remains loose after re-insertion, the cord or the device's port may be worn. Consider replacing the cord.

If these steps do not resolve the issue, consult the user manual for your Maxi-Matic Elite Platinum Pressure Cooker or contact the manufacturer for further assistance.

## 5. Specifications

| | |
|---|---|
| **Brand** | onerbl |
| **Compatible Models** | Maxi-Matic Elite Platinum Pressure Cooker EPC-1013, EPC-1013OR, EPC-607, EPC-607R, EPC-607BL, EPC-808, EPC-808R |
| **Voltage** | 120 Volts (AC) |
| **Plug Format** | Type B (US Standard) |
| **Connector Type** | IEC C7 (Figure 8) |
| **Material** | High-quality PVC jacket, Copper wire |

## 6. Warranty and Support

For specific warranty information regarding your onerbl AC Power Cord, please refer to the documentation provided at the time of purchase or contact the seller directly. As a replacement part, warranty terms may vary.

For technical support or inquiries, please reach out to the product seller or manufacturer. Contact details are typically available on the product packaging or the point of purchase.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B09Z65YXSD**

More documents and user manuals: **https://manuals.plus/**