Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl 6ft Flat Fig 8 Power Cord

onerbl 6ft Flat Fig 8 Power Cord Instruction Manual

For Technics 5-Disc CD Players: SL-PD627, SL-PD807, SL-PD647

1. Introduction

This manual provides essential information for the safe and effective use of your onerbl 6ft Flat Fig 8 Power Cord. Please read these instructions carefully before installation and retain for future reference.

2. Safety Guidelines

- Ensure the power cord is compatible with your device's power input requirements.
- Do not use the power cord if it is damaged, frayed, or has exposed wires.
- Avoid placing the cord in areas where it can be tripped over or pinched.
- Keep the cord away from water, excessive heat, and direct sunlight.
- Always grasp the plug, not the cord, when disconnecting from an outlet or device.

3. Product Overview

The onerbl 6ft Flat Fig 8 Power Cord is designed as a replacement or spare power cable for compatible audio equipment. It features a flat, two-prong (Figure 8) connector for the device end and a standard two-prong US plug for the wall outlet.



This image illustrates the durable construction of the power cord, featuring copper wire conductors and a protective PVC jacket, along with the standard two-prong plug design.

4. Compatibility

This power cord is specifically designed for use with the following Technics 5-Disc CD Player models:

- Technics SL-PD627
- Technics SL-PD807
- Technics SL-PD647

Ensure your device has a compatible Figure 8 (C7) power input receptacle.

5. Installation

1. Ensure your Technics CD player is powered off and unplugged from any existing power source.
2. Locate the Figure 8 (C7) power input receptacle on the back of your CD player.
3. Insert the Figure 8 connector end of the onerbl power cord firmly into the power input receptacle on the CD player.
4. Plug the standard two-prong end of the power cord into a functional wall outlet or surge protector.
5. You may now power on your Technics CD player.

6. Operation

Once properly connected, the power cord provides electrical power to your compatible Technics CD player. No further operational steps are required for the power cord itself. Ensure the CD player's power switch is in the 'ON' position for operation.

7. Care and Maintenance

- **Cleaning:** Disconnect the power cord from both the device and the wall outlet before cleaning. Wipe the cord and plugs with a dry, soft cloth. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, coil the cord loosely. Avoid tight coiling or bending, which can damage the internal wires. Store in a cool, dry place.
- **Inspection:** Periodically inspect the cord for any signs of wear, cuts, or damage. Replace the cord immediately if any damage is observed.

8. Troubleshooting

No Power to Device

- **Check Connections:** Ensure both ends of the power cord are securely plugged into the CD player and the wall outlet.
- **Test Outlet:** Plug another device into the wall outlet to confirm it is functional.
- **Inspect Cord:** Examine the power cord for any visible damage. If damaged, discontinue use and replace.
- **Device Power Switch:** Confirm the CD player's power switch is in the 'ON' position.

9. Specifications

Brand	onerbl
Connector Gender	Male-to-Female
Item Length	72 Inches (6 feet)
Manufacturer	Shenzhen Waweis Technology Co., Ltd
Connector Type	Figure 8 (C7) to NEMA 1-15P

10. Warranty and Support

For information regarding warranty coverage or technical support, please refer to the documentation provided with your original purchase or contact the retailer where the onerbl 6ft Flat Fig 8 Power Cord was acquired.

© 2023 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09Z6FGDL5

More documents and user manuals: **https://manuals.plus/**