De'Longhi EN560.S, EN560S, F521.SI

Delonghi Nespresso Lattissima Touch Milk Carafe Instruction Manual

Model: EN560.S, EN560S, F521.SI

Introduction

This manual provides comprehensive instructions for the proper use, maintenance, and troubleshooting of your De'Longhi Nespresso Lattissima Touch Milk Carafe. This is a genuine replacement part designed to ensure optimal performance with compatible De'Longhi Nespresso Lattissima Touch coffee machines.

Product Overview

The milk carafe is an essential component for preparing milk-based coffee beverages. It consists of a transparent milk container, a lid with an integrated frothing system, and a milk tube.



Figure 1: De'Longhi Nespresso Lattissima Touch Milk Carafe. This image shows the complete milk carafe assembly, including the clear milk container, the white top unit with control knob, and the internal milk tube.

- **Milk Container:** Transparent reservoir for milk.
- **Lid with Frothing System:** Houses the milk frothing mechanism and connects to the coffee machine.
- **Milk Tube:** Internal tube that draws milk from the container to the frothing system.
- **Regulation Knob:** (Visible on the lid) Used to adjust milk froth consistency.

Setup

1. **Unpacking:** Carefully remove the milk carafe from its packaging. Inspect for any damage.
2. **Initial Cleaning:** Before first use, wash all removable parts of the milk carafe (container, lid, milk tube) with warm water and a mild detergent. Rinse thoroughly and dry.
3. **Assembly:** Ensure the milk tube is correctly inserted into the base of the lid and extends into the milk container. Securely attach the lid to the milk container.
4. **Attachment to Machine:** Insert the assembled milk carafe into the designated slot on your De'Longhi Nespresso Lattissima Touch coffee machine until it clicks into place. Refer to your coffee machine's main instruction manual for specific attachment points.

Operating Instructions

Follow these steps to prepare milk-based beverages using the milk carafe:

1. **Fill Milk Container:** Open the lid and fill the milk container with fresh, cold milk. Do not exceed the MAX fill line.
2. **Close Lid:** Securely close the lid on the milk container.
3. **Adjust Froth:** Rotate the regulation knob on the lid to select your desired milk froth consistency (e.g., less froth for hot milk, more froth for cappuccino).
4. **Position Spout:** Position the milk spout over your coffee cup.
5. **Select Beverage:** On your coffee machine, select the desired milk-based beverage (e.g., Cappuccino, Latte

Macchiato). The machine will automatically draw milk from the carafe, froth it, and dispense it into your cup.

6. **After Use:** After dispensing milk, the machine may prompt you to clean the milk system. Always perform the quick clean cycle as instructed by your coffee machine to prevent milk residue buildup.

Cleaning and Maintenance

Regular cleaning is crucial for hygiene and optimal performance of the milk carafe.

Daily Cleaning:

- **Quick Clean Cycle:** After each milk preparation, perform the quick clean cycle on your coffee machine. This flushes hot water through the milk system.
- **Rinse Components:** Detach the milk carafe from the machine. Disassemble the lid and milk tube. Rinse all parts under running warm water.
- **Wipe Down:** Wipe the exterior of the carafe and the machine's milk connection point with a damp cloth.

Thorough Cleaning (Weekly or as needed):

- **Disassemble:** Fully disassemble the milk carafe, separating the container, lid, milk tube, and any removable frothing components.
- **Soak:** Soak all parts in warm water with a mild detergent or a specialized milk system cleaner.
- **Brush Cleaning:** Use a small brush (often supplied with coffee machines) to clean inside the milk tube and any narrow passages in the lid. Ensure no milk residue remains.
- **Rinse and Dry:** Rinse all components thoroughly under running water until no soap residue is visible. Allow them to air dry completely before reassembling.
- **Dishwasher Safe:** Refer to your coffee machine's manual; some milk carafe components may be dishwasher safe (top rack only).

Caution: Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the carafe's surfaces.

Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution
No milk dispensed or poor froth.	Milk tube clogged or improperly inserted. Milk carafe not properly attached. Milk too warm or too cold. Froth regulation knob set incorrectly.	Clean the milk tube and lid thoroughly. Ensure the tube is fully inserted. Re-attach the carafe firmly until it clicks. Use fresh, cold milk (refrigerated). Adjust the froth knob to a higher setting.
Milk leaks from carafe.	Lid not securely closed. Carafe not properly seated on machine. Damaged seal.	Ensure the lid is firmly closed. Re-seat the carafe on the machine. Inspect seals for damage; replace carafe if necessary.

Problem	Possible Cause	Solution
Machine prompts for milk system cleaning frequently.	Milk residue buildup.	Perform thorough cleaning of all milk carafe components as described in the "Cleaning and Maintenance" section.

If the problem persists after attempting these solutions, please refer to your coffee machine's main instruction manual or contact De'Longhi customer support.

Specifications

- **Product Type:** Replacement Milk Carafe
- **Compatibility:** De'Longhi Nespresso Lattissima Touch coffee machines (Models: EN560.S, EN560S, F521.SI)
- **Dimensions (L x W x H):** Approximately 8 x 6 x 16 cm (3.15 x 2.36 x 6.3 inches)
- **Weight:** Approximately 240 grams (0.53 lbs)
- **Material:** Food-grade plastic
- **Special Features:** Integrated milk frothing system, adjustable froth consistency.

Warranty and Support

As a genuine De'Longhi replacement part, this milk carafe is covered by the standard warranty terms applicable to De'Longhi accessories. Please retain your proof of purchase for warranty claims.
For technical assistance, spare parts, or warranty inquiries, please contact De'Longhi customer support or visit their official website. You can often find contact information and support resources via the following link:

De'Longhi Official Support

When contacting support, please have your coffee machine's model number and the milk carafe's part number (if available) ready.

© 2023 De'Longhi. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question