**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Acer A515-57G-735F

# Acer Aspire 5 A515-57G-735F Slim Laptop User Manual

Model: A515-57G-735F

## 1. Introduction

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Acer Aspire 5 A515-57G-735F Slim Laptop. Designed for productivity and performance, this laptop features a 12th Gen Intel Core i7 processor, NVIDIA GeForce RTX 2050 graphics, a 15.6-inch Full HD IPS display, and runs on Windows 11 Home. Please read this manual thoroughly to ensure optimal use and longevity of your device.




**Figure 1.1:** Front view of the Acer Aspire 5 A515-57G-735F Slim Laptop, showcasing its display and keyboard.

## 2. What's in the Box

Upon opening your Acer Aspire 5 A515-57G-735F package, verify that all the following items are included:

- Acer Aspire 5 A515-57G-735F Slim Laptop
- AC Adapter
- Power Cord

## 3. Setup

### 3.1 Initial Power-On and Charging

1. Connect the AC adapter to the laptop's power port and then to a power outlet.
2. Open the laptop lid and press the power button, typically located on the top-right of the keyboard or on the side.
3. Allow the battery to fully charge before initial use for optimal battery health.

### 3.2 Windows 11 Setup

Follow the on-screen prompts to complete the Windows 11 Home setup. This includes selecting your region, connecting to a Wi-Fi network, creating a user account, and setting up security features like the fingerprint reader.

### 3.3 Connecting Peripherals

Your laptop features various ports for connecting external devices:

- **USB Ports:** Connect USB devices such as mice, keyboards, or external storage. The laptop includes 3 USB 3.2 Gen 1 ports (one with Power-off Charging) and 1 Thunderbolt 4 (USB Type-C) port.
- **HDMI Port:** Connect an external monitor or TV using an HDMI cable. The laptop has 1 HDMI 2.1 Port with HDCP support.
- **Thunderbolt 4 Port:** This versatile USB Type-C port supports data transfer up to 10 Gbps, DisplayPort over USB Type-C, and USB charging. It can connect two 4K displays for multitasking.
- **Ethernet (RJ-45):** For wired network connections.
- **Headphone/Speaker/Line-Out Jack:** For audio output.




**Figure 3.1:** Left side of the laptop showing the power input, Ethernet, HDMI, USB-A, and Thunderbolt 4 (USB-C) ports.




**Figure 3.2:** Right side of the laptop showing two USB-A ports and the headphone jack.

# 4. Operating the Laptop

## 4.1 Keyboard and Touchpad

The laptop features a full-size backlit keyboard and a precision touchpad. The ergonomic hinge design slightly elevates the keyboard for comfortable typing. The touchpad supports multi-gesture commands for navigation.



**Figure 4.1:** Top-down view of the backlit keyboard and touchpad, including the fingerprint reader.

## 4.2 Display Features

The 15.6-inch Full HD IPS display offers sharp details and vibrant colors. Acer Color Intelligence technology enhances visual clarity and color accuracy. The narrow bezels provide an immersive viewing experience.




**Figure 4.2:** The laptop display highlighting Full HD (1920x1080) and IPS technology for clear visuals.

## 4.3 Audio and Communication

Acer's Purified.Voice technology, with dual microphones and beam-forming technology, enhances speech accuracy and cancels background noise, ensuring clear communication during calls and online meetings.



**Figure 4.3:** Individuals engaged in a video conference, demonstrating the laptop's communication capabilities.

### 4.4 Wireless Connectivity

The laptop supports 802.11ax Wi-Fi 6 Dual-Band (2.4GHz and 5GHz) with 2x2 MU-MIMO technology for high-speed internet access and Bluetooth 5.1 for connecting wireless peripherals.

## 5. Maintenance

### 5.1 Cleaning Instructions

- Use a soft, lint-free cloth to clean the screen. For stubborn marks, lightly dampen the cloth with water or a screen-specific cleaner.
- Wipe the keyboard and chassis with a soft, dry cloth. Avoid harsh chemicals.
- Use compressed air to clear dust from keyboard keys and ventilation grilles.

### 5.2 Battery Care

- Avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place if not used for extended periods.
- Use only the original AC adapter provided with your laptop.

### 5.3 Thermal Management

The laptop features dual fans and copper thermal pipes for efficient cooling. Ensure ventilation grilles are not obstructed. You can adjust cooling modes (Silent, Normal, Performance) using the Fn+F key combination.




**Figure 5.1:** Internal view illustrating the dual-fan cooling system and heat dissipation pathways.

## 6. Troubleshooting

This section addresses common issues you might encounter. For more complex problems, refer to Acer's official support resources.

### 6.1 Power Issues

- **Laptop does not turn on:** Ensure the AC adapter is securely connected and the power outlet is functional. Try a different outlet. If the battery is completely drained, it may take a few minutes to respond after connecting the charger.
- **Battery not charging:** Verify the AC adapter and power cord connections. Check for any damage to the adapter or laptop's power port.

### 6.2 Display Problems

- **Screen is blank:** Ensure the laptop is powered on. Try adjusting the display brightness using the function keys. If an external monitor is connected, ensure it is properly configured.
- **Distorted or incorrect colors:** Update your graphics drivers. If using an external display, check the cable connection.

### 6.3 Connectivity Issues

- **Wi-Fi not connecting:** Ensure Wi-Fi is enabled in Windows settings. Restart your router and modem. Check for updated wireless drivers.
- **Bluetooth device not pairing:** Ensure Bluetooth is enabled on both the laptop and the device. Place devices close to each other and ensure they are in pairing mode.

## 7. Specifications

Detailed technical specifications for the Acer Aspire 5 A515-57G-735F Slim Laptop:

| | |
|---|---|
| **Processor** | 12th Generation Intel Core i7-1260P (4.7 GHz) |
| **Graphics** | NVIDIA GeForce RTX 2050 (4 GB GDDR6 Dedicated) |
| **RAM** | 16 GB DDR4 |
| **Storage** | 512 GB NVMe SSD |
| **Display** | 15.6" Full HD (1920x1080) IPS |
| **Operating System** | Windows 11 Home |
| **Wireless Connectivity** | Wi-Fi 6 (802.11ax), Bluetooth 5.1 |
| **Ports** | 1x Thunderbolt 4 (USB Type-C), 3x USB 3.2 Gen 1 (one with Power-off Charging), 1x HDMI 2.1, 1x Ethernet (RJ-45), 1x Headphone/Speaker/Line-Out Jack |
| **Special Features** | Backlit Keyboard, Fingerprint Reader, Acer Purified.Voice |
| **Dimensions (LxWxH)** | 14.29 x 9.36 x 0.7 inches |
| **Weight** | 2.75 pounds |

## 8. Warranty and Support

For warranty information, technical support, driver downloads, and service inquiries, please visit the official Acer support website. Keep your purchase receipt and product serial number (located on the bottom of the laptop) handy when contacting support.
**Acer Support Website:** www.acer.com/support

© 2025 Acer Inc. All rights reserved. Acer and the Acer logo are registered trademarks of Acer Inc. Other trademarks, registered trademarks, and/or service marks, indicated or otherwise, are the property of their respective owners.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B09ZVFHPPV**

More documents and user manuals: **https://manuals.plus/**