EDISON ELECTRIC 6285360069926

Edison Electric 12 Liter Electric Pressure Cooker User Manual

Model: 6285360069926

Introduction

Thank you for choosing the Edison Electric 12 Liter Electric Pressure Cooker. This multi-functional appliance is designed to simplify your cooking experience with its ten versatile functions, replacing the need for several kitchen devices. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new pressure cooker. Please read it thoroughly before first use and keep it for future reference.



Image: The Edison Electric 12 Liter Electric Pressure Cooker, showcasing its sleek design.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.

- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance cooks under pressure. Improper use may result in scalding injury. Make certain unit is properly closed before operating.
- Never force open the pressure cooker. Ensure pressure is completely released before opening.
- Do not fill the unit over 2/3 full. When cooking foods that expand during cooking, such as rice or dried vegetables, do not fill the unit over 1/2 full.
- Always check the pressure release valve and float valve for clogging before use.

Product Components

Familiarize yourself with the parts of your Edison Electric Pressure Cooker:

- **Main Unit:** Houses the heating element and control panel.
- **Inner Pot:** Removable stainless steel cooking pot.
- **Lid:** With sealing gasket, pressure release valve, and float valve.
- **Condensation Collector:** Gathers excess moisture.
- **Measuring Cup:** For precise ingredient measurement.
- **Rice Paddle:** For serving cooked rice.

قدر إديسون سهلها عليك

أكثر من 10 برامج في قدر واحد



غطاء سهل الاستعمال مع قفل صمام لتحرير البخار بكل هدوء وآمان و آمن في غسالة الصحون

ستاند داخلي لطبخ المندي و الأطعمة المتنوعة والخضار على البخار للحفاظ على القيمة الغذائية بشكل صحي



وعاء من الستانليس ستيل المقاوم للصدأ بسطح غير لاصق يجعل تنظيفه أمرا سهل للغاية



Image: A diagram illustrating the components of the pressure cooker, including the lid, inner pot, and main unit.



Image: Included accessories: a clear plastic measuring cup and a white rice paddle.

Setup

1. **Unpacking:** Carefully remove all packaging materials and accessories from the box.
2. **Initial Cleaning:** Before first use, wash the inner pot, lid, and accessories (measuring cup, rice paddle) with warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the pressure cooker on a stable, level, heat-resistant surface, away from heat sources and flammable materials. Ensure there is adequate space around the unit for ventilation.
4. **Condensation Collector:** Attach the condensation collector to the back of the cooker.
5. **Inner Pot Insertion:** Place the clean inner pot into the main unit. Ensure it sits properly and makes full contact with the heating element.

Operating Instructions

Control Panel Overview



Image: The digital control panel of the Edison Electric Pressure Cooker, showing various cooking presets.

The control panel features a digital display and touch-sensitive buttons for various cooking functions and settings:

- **Digital Display:** Shows cooking time, pressure level, and status indicators.
- **Function Buttons:** Dedicated buttons for Rice, Fish, Chicken, Meat, Grape Leaves, Hashi, Soup, Mataziz, Cake, and Slow Cook.
- **Keep Warm/Cancel:** To keep food warm after cooking or to stop a cooking program.
- **Preset Timer:** To delay the start of cooking.
- **+/- Buttons:** To adjust cooking time or preset delay time.

General Cooking Steps

1. **Prepare Ingredients:** Measure and prepare your ingredients according to your recipe.
2. **Add Ingredients:** Place the prepared ingredients into the inner pot. Ensure the total volume does not exceed the MAX fill line (2/3 full for most foods, 1/2 full for expanding foods like rice).

3. **Close Lid:** Place the lid on the cooker, aligning the arrow on the lid with the arrow on the main unit. Rotate the lid clockwise until it locks into place. Ensure the steam release valve is in the "Sealing" position.
4. **Plug In:** Connect the power cord to a grounded electrical outlet. The display will light up.
5. **Select Function:** Press the desired cooking function button (e.g., "Rice", "Chicken", "Meat"). The default cooking time for that function will appear on the display.
6. **Adjust Time (Optional):** If needed, use the "+" or "-" buttons to adjust the cooking time.
7. **Start Cooking:** The cooker will automatically begin the preheating process. Once pressure is reached, the cooking timer will start counting down.
8. **Pressure Release:** Once cooking is complete, the cooker will beep and automatically switch to "Keep Warm" mode. To release pressure, carefully turn the steam release valve to the "Venting" position. **WARNING:** Hot steam will be released. Keep hands and face clear.
9. **Open Lid:** Once the float valve drops down, indicating all pressure has been released, rotate the lid counter-clockwise and lift it carefully away from you to avoid residual steam.
10. **Serve:** Your meal is ready to be served.

Using the Preset Timer

The Preset Timer allows you to delay the start of your cooking program:

1. Follow steps 1-3 from "General Cooking Steps".
2. Select your desired cooking function.
3. Press the "Preset Timer" button. The display will show a default delay time.
4. Use the "+" or "-" buttons to adjust the desired delay time.
5. The cooker will start counting down the delay time. Once the delay time expires, the cooking program will automatically begin.

Cleaning and Maintenance

Regular cleaning and maintenance ensure the longevity and safe operation of your pressure cooker.

- **Always unplug the appliance and allow it to cool completely before cleaning.**
- **Inner Pot:** The stainless steel inner pot is dishwasher safe for easy cleaning. Alternatively, wash with warm, soapy water and a non-abrasive sponge.
- **Lid:** Remove the sealing gasket and wash it, along with the lid, in warm, soapy water. Inspect the gasket for cracks or damage and replace if necessary. Clean the steam release valve and float valve to ensure they are free from food debris.
- **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
- **Condensation Collector:** Empty and clean the condensation collector after each use.
- **Storage:** Store the cleaned and dried pressure cooker in a dry place. You may invert the lid on the inner pot to prevent odors.

Troubleshooting

If you encounter issues with your pressure cooker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cooker not building pressure.	Lid not properly closed or steam release valve in "Venting" position. Sealing gasket is damaged or missing. Not enough liquid in the pot.	Ensure lid is fully locked and steam release valve is in "Sealing" position. Check sealing gasket for proper placement and condition. Add sufficient liquid as per recipe.
Steam leaking from lid.	Sealing gasket not properly seated or damaged. Food debris on the rim of the inner pot or lid.	Adjust gasket, clean lid and inner pot rim. Replace gasket if damaged.
Food is undercooked.	Insufficient cooking time. Not enough liquid.	Increase cooking time. Ensure adequate liquid for pressure buildup.
Display shows an error code.	Specific internal malfunction.	Unplug the cooker, wait a few minutes, then plug it back in. If the error persists, contact customer support.

For issues not covered here, please contact Edison Electric customer support.

Specifications

Feature	Detail
Brand	EDISON ELECTRIC
Model Number	6285360069926
Color	Black
Capacity	12 Liters
Material	Stainless Steel
Product Dimensions	35 x 35 x 35 cm
Item Weight	1.32 Kilograms
Control Method	Touch
Operation Mode	Automatic
Special Features	Dishwasher Safe (Inner Pot)

Warranty and Support

Your Edison Electric 12 Liter Electric Pressure Cooker comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. For technical support, service, or warranty claims, please contact Edison Electric customer service through their official website or the contact information provided with your purchase.
For further assistance, you may visit the Edison Electric Store on Amazon.

© 2024 EDISON ELECTRIC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question