Aquasonic AFPRO-White

AquaSonic Aqua Flosser PRO Instruction Manual

Model: AFPRO-White | Brand: Aquasonic

1. Product Overview

The AquaSonic Aqua Flosser PRO is a professional water flosser designed to provide a superior oral cleaning experience. It features a large capacity reservoir, multiple usage modes, and adjustable water pressure levels to effectively remove plaque, tartar, and food particles that traditional string floss may miss. This device is engineered for sleekness and compactness, making it a convenient addition to any bathroom.

Key features include:

- **Large Capacity Reservoir:** Holds 20 oz. (600ml) of water for extended flossing sessions without frequent refilling.
- **Two Usage Modes:** "Clean" mode for general flossing and "Massage" mode for gum stimulation.
- **Ten Water Pressure Levels:** Adjustable from soft to strong to suit individual comfort and cleaning needs.
- **Multiple Jet Tips:** Includes 2 micro jet-stream nozzles, 1 periodontal tip, and 1 tongue scraper for comprehensive oral care.
- **Compact Design:** Saves counter space while offering powerful performance.
- **Braces & Dental Work Friendly:** 360-degree rotary tips are ideal for cleaning around braces and other dental devices.



Figure 1: AquaSonic Aqua Flosser PRO and included accessories.

2. Components

The Aqua Flosser PRO package includes the following components:

- Aqua Flosser PRO Main Unit (with integrated handle and hose)
- Large Capacity Water Reservoir (600ml)
- 2 x Micro Jet-Stream Nozzles
- 1 x Periodontal Tip
- 1 x Tongue Scraper
- Power Adapter

- User Manual (this document)



Figure 2: Included Jet Tips and Tongue Scraper.

3. Setup Instructions

Follow these steps to set up your AquaSonic Aqua Flosser PRO for first use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean Parts:** Before initial use, clean the water reservoir and all jet tips with warm, soapy water. Rinse thoroughly.
3. **Fill Reservoir:** Detach the water reservoir from the main unit. Fill it with lukewarm water. You may also add

mouthwash as desired, but ensure it is non-abrasive and compatible with water flossers. Reattach the reservoir securely to the main unit.

4. **Attach Tip:** Select the desired jet tip (e.g., micro jet-stream nozzle) and insert it firmly into the handle until it clicks into place.
5. **Connect Power:** Plug the power adapter into a suitable electrical outlet.



Figure 3: The compact design of the Aqua Flosser PRO on a bathroom counter.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the Aqua Flosser PRO's features, including setup and usage. This video highlights the ease of use and various functions of the device.

4. Operating Instructions

To use your AquaSonic Aqua Flosser PRO:

1. **Select Mode:** On the main unit, choose your desired mode: "Clean" for standard flossing or "Massage" for gum stimulation. An indicator light will illuminate next to the selected mode.
2. **Adjust Pressure:** Rotate the knob on the side of the main unit to select one of the 10 water pressure levels, from soft (1) to strong (10). Start with a lower setting and gradually increase to a comfortable level.
3. **Position Tip:** Lean over the sink and place the tip in your mouth, directing the water stream at a 90-degree angle to your gumline.
4. **Activate:** Press the power button on the handle to start the water flow.
5. **Floss:** Guide the water stream along your gumline and between your teeth, pausing briefly between each tooth. Allow the water to flow into the sink.
6. **Complete Session:** Continue until you have cleaned all areas of your mouth or the reservoir is empty.
7. **Turn Off:** Press the power button on the handle to stop the water flow.



Figure 4: Key operational features of the Aqua Flosser PRO.



Figure 5: Demonstrating proper usage of the Aqua Flosser PRO.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your Aqua Flosser PRO:

- **After Each Use:**
    a. Empty any remaining water from the reservoir.
    b. Rinse the reservoir thoroughly with clean water.
    c. Run the unit for a few seconds with the tip removed to drain any water from the hose and handle.
    d. Wipe the exterior of the unit with a soft, damp cloth.

- **Weekly Cleaning:**
    a. For a deeper clean, fill the reservoir with warm water and 2 tablespoons of white vinegar.
    b. Run the solution through the unit until the reservoir is empty.
    c. Rinse by filling the reservoir with clean water and running it through the unit.
- **Tip Cleaning:** Remove tips and rinse them under running water. For stubborn deposits, soak them in a solution of 1 part white vinegar to 1 part water for 5-10 minutes, then rinse.
- **Storage:** Ensure the unit is dry before storing. Store in a cool, dry place away from direct sunlight.

6. Troubleshooting

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; power outlet issue; unit malfunction.	Ensure power cord is securely plugged into a working outlet. Test outlet with another device. If problem persists, contact customer support.
No water flow or weak water pressure.	Reservoir empty; tip clogged; air in pump; pressure setting too low.	Refill reservoir. Clean the jet tip. Run unit with tip removed to clear air. Increase pressure setting using the knob.
Water leaks from unit.	Reservoir not seated correctly; damaged hose/seal.	Ensure reservoir is firmly seated. Check for visible damage to hose or seals. Contact customer support if damage is found.
Excessive noise during operation.	Air in pump; unit not on a stable surface.	Run unit with tip removed to clear air. Place unit on a flat, stable surface.

7. Product Specifications

Model Number: AFPRO-White

Product Dimensions: 6 x 5 x 9 inches

Item Weight: 1.87 Pounds

Power Source: Corded Electric

Water Reservoir Capacity: 20 oz. (approx. 600ml)

Pressure Levels: 10 (Soft to Strong)

Modes: Clean, Massage

Included Tips: 2 Micro Jet-Stream Nozzles, 1 Periodontal Tip, 1 Tongue Scraper

Manufacturer: Aquasonic

Date First Available: May 12, 2022

8. Warranty Information

The AquaSonic Aqua Flosser PRO typically comes with a manufacturer's warranty. For specific details regarding your product's warranty period, coverage, and terms, please refer to the warranty card included in your product packaging or visit the official Aquasonic website. Retain your proof of purchase for warranty claims.

9. Customer Support

For further assistance, technical support, or to inquire about replacement parts, please contact Aquasonic customer service. You can find contact information on the official Aquasonic website or through the retailer where you purchased the product.

Visit the official Aquasonic Store: Aquasonic Store on Amazon

© 2024 Aquasonic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question