Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Zippo Z4A20

Zippo HeatBank 6 Rechargeable Hand Warmer User Manual

Model: Z4A20

Introduction

The Zippo HeatBank 6 Rechargeable Hand Warmer is a versatile device designed to provide warmth in cold conditions and serve as a portable power bank for charging USB-compatible devices. Featuring a 4400 mAh lithium-ion battery, it offers up to 6 hours of warmth and can reach temperatures of up to 120°F (50°C). This manual provides essential information for the safe and effective use of your HeatBank 6.

Safety Information

WARNING: To reduce the risk of injury, fire, or electric shock, always read and follow all instructions and warnings before using this product. Keep this manual for future reference.

- Do not expose the device to extreme temperatures (above 140°F / 60°C) or direct sunlight for prolonged periods.
- Do not immerse the device in water or other liquids.
- Do not attempt to disassemble, repair, or modify the device. This will void the warranty and may cause injury.
- Keep out of reach of children.
- Use only the provided USB cable or a certified equivalent for charging.
- If the device becomes excessively hot, emits smoke, or shows signs of damage, discontinue use immediately.
- Dispose of the device according to local regulations for lithium-ion batteries.

Package Contents

- Zippo HeatBank 6 Rechargeable Hand Warmer
- USB Charging Cable
- Lanyard with removable clip
- Instruction Sheet (this manual)



Image: Zippo HeatBank 6 Hand Warmer shown with its included USB charging cable and lanyard.

Product Overview

Familiarize yourself with the different parts of your Zippo HeatBank 6:

- **Power Button / Heat Activation Button:** Used to turn the device on/off and cycle through heat settings.
- **Heat Indicator Lights:** Indicate the current heat setting (low/high).
- **Battery Indicator Lights:** Show the remaining battery charge.
- **Micro-USB Input Port (IN):** For charging the HeatBank 6.
- **USB-A Output Port (OUT):** For charging external devices.



Image: Top view of the Zippo HeatBank 6, highlighting the input and output ports, power button, and indicator lights.



Image: Angled view of the Zippo HeatBank 6, showcasing its sleek black design.

Setup

Initial Charging

Before first use, fully charge your Zippo HeatBank 6. This ensures optimal battery performance and longevity.

1. Connect the smaller end of the provided USB charging cable to the Micro-USB input port (IN) on the HeatBank 6.
2. Connect the larger end of the USB cable to a USB power source (e.g., computer USB port, wall adapter, car charger).
3. The battery indicator lights will flash while charging and remain solid when fully charged.
4. Charging time for the 4400 mAh battery is typically several hours, depending on the power source.

Attaching the Lanyard

The included lanyard can be attached for convenient carrying or to prevent accidental drops.

1. Locate the small loop on the HeatBank 6, usually near the charging ports.
2. Thread the thin loop of the lanyard through this opening.
3. Pass the larger part of the lanyard through the thin loop and pull to secure.

Operating Instructions

Using as a Hand Warmer

The HeatBank 6 offers two heat settings: Low and High.

1. **To Turn On:** Press and hold the power button for approximately 3 seconds. The heat indicator lights will illuminate.
2. **To Change Heat Setting:** Briefly press the power button.
    - One light: Low heat setting (approx. 100°F / 38°C).
    - Two lights: High heat setting (up to 120°F / 50°C).
3. **To Turn Off:** Press and hold the power button for approximately 3 seconds until the heat indicator lights turn off.

The device will provide warmth for up to 6 hours on the low setting, depending on ambient temperature and usage.

Using as a Power Bank

The HeatBank 6 can charge most USB-compatible devices, such as mobile phones, MP3 players, and cameras.

1. Connect your device's charging cable to the USB-A output port (OUT) on the HeatBank 6.
2. Connect the other end of your device's charging cable to your device.
3. The HeatBank 6 will automatically begin charging your device. The battery indicator lights will show the remaining charge.
4. To stop charging, simply disconnect your device.

Note: Using the power bank function will reduce the available battery life for the hand warmer function.

Maintenance

Cleaning

- Ensure the device is turned off and disconnected from any power source before cleaning.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Do not submerge the device in water.

Storage

- Store the HeatBank 6 in a cool, dry place away from direct sunlight and extreme temperatures.
- For long-term storage, it is recommended to charge the device to approximately 50% every 3-6 months to maintain battery health.

Troubleshooting

Problem	Possible Cause	Solution
Device not turning on.	Battery is depleted.	Charge the device fully.
Device not heating up.	Hand warmer function not activated or low battery.	Ensure the hand warmer function is turned on (press and hold power button). Check battery level and recharge if necessary.
External device not charging.	HeatBank battery depleted; incorrect cable; device not compatible.	Charge the HeatBank 6. Ensure you are using the correct USB cable for your device. Some devices may require specific charging protocols.
Short battery life.	High heat setting used; frequent charging of external devices; cold ambient temperatures.	Use the low heat setting for extended warmth. Minimize external device charging if hand warmer function is prioritized. Battery performance can decrease in very cold environments.

Specifications

Model: Z4A20

Battery Type: Rechargeable Lithium-Ion

Battery Capacity: 4400 mAh

Input: 5V 2A (Micro-USB)

Output: 5V 2A (USB-A)

Operating Temperature: Up to 120°F (50°C)

Run Time: Up to 6 hours (on low heat setting)

Dimensions: Approximately 4.25 x 1.73 x 0.95 inches (10.8 x 4.4 x 2.4 cm)

Weight: Approximately 4.96 ounces (140.6 grams)

Material: Aluminum

Included Components: Hand warmer, USB charging cable, instruction sheet, lanyard.

Warranty and Support

The Zippo HeatBank 6 Rechargeable Hand Warmer comes with a**1-Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
The warranty does not cover:

- Damage caused by accident, abuse, misuse, flood, fire, or other external causes.
- Damage caused by operating the product outside the permitted or intended uses described by Zippo.
- Damage caused by service performed by anyone who is not an authorized representative of Zippo.
- Products or parts that have been modified to alter functionality or capability without the written permission of Zippo.

For warranty claims or technical support, please contact Zippo Customer Service through their official website or the

contact information provided with your product packaging. Please have your proof of purchase and product model number (Z4A20) ready when contacting support.
For more information, visit the official Zippo website:www.zippo.com

© 2025 Zippo Manufacturing Company. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B198NPBG

More documents and user manuals: **https://manuals.plus/**