Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CalExotics 14691

CalExotics Her Royal Harness Me2 Remote Rumbler Instruction Manual

Model: 14691

Introduction

Thank you for choosing the CalExotics Her Royal Harness Me2 Remote Rumbler. This device is designed to provide enhanced pleasure through its powerful dual motors and remote-controlled functions. This manual provides essential information for the safe and effective use, care, and maintenance of your product. Please read it thoroughly before first use.

Safety Information

- This product is intended for adult use only.
- Discontinue use immediately if you experience any discomfort or pain.
- Consult a healthcare professional if you have any pre-existing medical conditions or concerns.
- Keep out of reach of children.
- Do not use if the product appears damaged or defective.

Package Contents

Your CalExotics Her Royal Harness Me2 Remote Rumbler package should include:

- Her Royal Harness Me2 Remote Rumbler device
- Remote control
- Adjustable silicone waist and thigh straps
- USB charging cord



Image: The product packaging, illustrating the device, remote, harness, and key features.

Setup

Charging the Device

Before first use, fully charge the device. The Her Royal Harness Me2 Remote Rumbler is USB rechargeable.

1. Locate the charging port on the device.
2. Connect the included USB charging cord to the device and a compatible USB power source (e.g., computer, USB wall adapter).
3. Allow approximately 2.5 hours for a complete charge. The indicator light will show charging status (refer to product specific light indicators if available).



Image: The device shown with its dual USB charging cable connected, ready for charging.

Attaching the Harness

The silicone waist and thigh straps are fully adjustable and removable, allowing for a customized and secure fit.

1. Thread the straps through the designated loops on the device.
2. Adjust the straps to achieve a comfortable and secure fit around the waist and thighs.
3. Ensure the device is positioned as desired for use.





Image: The device with its remote control and the adjustable harness straps laid out, demonstrating the components.

Operating Instructions

Power On/Off and Travel Lock

The device features a security travel lock to prevent accidental activation.

- To turn the device ON or OFF, press and hold both buttons on the probe for 3 seconds.
- This action also engages or disengages the travel lock.

Using the Remote Control

The remote control allows for easy adjustment of the device's functions.

- Once the device is powered on, use the remote control to activate and cycle through the 10 independent functions of rumbling vibration, pulsation, and escalation.
- The memory chip feature will resume on the last function used when the device is powered on again.

Independent Probe Use

The waterproof probe may be used independently of the harness and remote control for versatile pleasure.

Video: An instructional video demonstrating how to lock/unlock the probe and turn on shaft vibration using the remote control.

Maintenance and Care

Cleaning

The device is made of silicone and is waterproof, making it easy to clean.

1. Clean the device thoroughly before and after each use with warm water and a mild soap or a specialized toy cleaner.
2. Rinse thoroughly and pat dry with a lint-free cloth.
3. Ensure the charging port is dry before recharging.

Storage

Store the device in a clean, dry place away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent potential damage or reactions.

Troubleshooting

Device Not Turning On or Responding

- **Check Battery Level:** Ensure the device is fully charged. Connect it to the USB charging cord and allow 2.5 hours for a complete charge.
- **Disable Travel Lock:** Press and hold both buttons on the probe for 3 seconds to ensure the travel lock is disengaged.
- **Remote Control Battery:** If the remote is not responding, ensure its battery is functional.
- **Reset:** Try connecting the device to the charger for a few minutes, then disconnect and attempt to power on again.

If the issue persists after trying these steps, please refer to the Customer Support section.

Specifications

Model Number	14691
Material	Silicone
Dimensions (L x W x H)	3 x 5.4 x 11.25 inches
Weight	1.17 pounds
Battery Type	1 Lithium Polymer (included)
Charge Time	Approximately 2.5 hours
Run Time (High Speed)	Approximately 45 minutes
Run Time (Low Speed)	Approximately 150 minutes
Functions	10 independent functions (vibration, pulsation, escalation)
Motors	Dual motors
Waterproof	Yes

Warranty Information

This CalExotics product is backed by a **1-year manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.
The warranty does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear.

Customer Support

For further assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact CalExotics customer support directly. Refer to the product packaging or the official CalExotics website for the most current contact information.

© 2023 CalExotics. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B1DFLN76

More documents and user manuals: **https://manuals.plus/**