Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DEWENWILS TW16

DEWENWILS WiFi Smart Yard Stake Timer Instruction Manual

Model: TW16

Introduction

This manual provides detailed instructions for the DEWENWILS WiFi Smart Yard Stake Plug. This outdoor power stake features 6 grounded outlets, a 6-foot cord, and is compatible with Amazon Alexa and Google Assistant for remote and voice control. It is designed for outdoor use with a waterproof cover and built-in timer functions, making it ideal for various outdoor lighting and appliance needs.

Safety Information

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the product is properly grounded.
- Do not immerse the unit in water.
- Keep the waterproof cover securely closed when in use.
- Do not exceed the maximum load capacity of 1875W/15A.
- Always unplug the unit from the power source before performing any maintenance or cleaning.
- Keep out of reach of children.
- Only use with outdoor-rated extension cords if additional length is required.

Product Overview

Familiarize yourself with the components of your Smart Yard Stake Timer.



Figure 1: Key components of the DEWENWILS WiFi Smart Yard Stake Timer, including the WiFi & Power Indicator, ON/OFF & Program Button, Overload Protection, 15A Outlets, Waterproof Cover, and 6Ft Cord with Stake.

- **Waterproof Cover:** Protects internal components from dust and water.
- **WiFi & Power Indicator:** Shows connection status and power status.
- **ON/OFF & Program Button:** Manual control and programming access.
- **Overload Protection:** Safety feature to prevent damage from excessive current.
- **15A Outlets:** Six grounded outlets for connecting devices.
- **6Ft Cord:** Provides flexible placement options.
- **Stake:** For secure ground installation.

Setup

1. Physical Installation

1. Attach the stake to the bottom of the yard stake timer by screwing it in securely.

2. Choose a suitable outdoor location with access to a 2.4 GHz Wi-Fi network.
3. Firmly push the stake into the ground. Ensure the unit is stable and upright.
4. Plug the yard stake timer into a grounded outdoor power outlet.



Figure 2: Step-by-step guide for assembling and installing the yard stake timer.

2. App Connection (Smart Life App)

1. Download the "Smart Life" app from your smartphone's app store (iOS or Android).
2. Register or log in to your Smart Life account.
3. Ensure your smartphone is connected to a 2.4 GHz Wi-Fi network.
4. Open the app and tap "Add Device" or the "+" icon.
5. Select "Electrical Outlet" or "Power Strip (Wi-Fi)" from the device list.
6. Follow the in-app instructions to put the device into pairing mode (usually by pressing and holding the ON/OFF button until the indicator light blinks rapidly).
7. Confirm the indicator light is blinking rapidly in the app and enter your Wi-Fi password.
8. The app will connect to the device. Once connected, you can rename the device for easy identification.

Operating Instructions

1. Remote Control via App

Once connected to the Smart Life app, you can control your yard stake from anywhere with an internet connection.

- Open the Smart Life app and select your DEWENWILS Smart Yard Stake.
- Tap the large power button on the app's main screen to turn all 6 outlets ON or OFF simultaneously.
- Use the "Timer" function within the app to set schedules for automatic ON/OFF operations.



Figure 3: Remote control interface on the smartphone app.

2. Voice Control (Alexa/Google Assistant)

Integrate your Smart Yard Stake with voice assistants for hands-free control.

1. Link your Smart Life account to Amazon Alexa or Google Assistant through their respective apps.
2. Once linked, use voice commands such as:
    3. "Alexa, turn on [Device Name]"
    4. "Hey Google, turn off [Device Name]"



Figure 4: Voice control in action with smart speakers.

3. Manual Control

The physical button on the unit allows for direct control.

- Press the ON/OFF button located under the waterproof cover to manually toggle power to all connected devices.

Maintenance

Proper maintenance ensures the longevity and safe operation of your Smart Yard Stake Timer.

- **Cleaning:** Periodically wipe the unit with a damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the unit is unplugged before cleaning.
- **Waterproof Seal:** Regularly inspect the waterproof cover and seals for any signs of wear or damage. Ensure it closes tightly to prevent water ingress.
- **Cord Inspection:** Check the 6-foot cord for any cuts, fraying, or damage. Replace the unit if the cord is damaged.
- **Storage:** If storing the unit for an extended period, clean it thoroughly and store it in a dry, cool place away from

direct sunlight.



Figure 5: The weatherproof design allows for use in various outdoor conditions.

Troubleshooting

Problem	Possible Cause	Solution
Device not connecting to Wi-Fi.	Incorrect Wi-Fi password; Not on 2.4 GHz network; Device too far from router.	Verify password; Connect to 2.4 GHz Wi-Fi; Move device closer to router.
Outlets not powering on.	Overload protection tripped; Unit not plugged in; Timer schedule not active.	Check and reset overload switch; Ensure unit is plugged in; Verify app schedule.
Voice control not working.	Smart Life account not linked; Incorrect device name; Internet connectivity issue.	Link accounts in Alexa/Google Home app; Check device name in Smart Life app; Verify internet connection.

Specifications

Feature	Detail
Model Number	TW16
Product Dimensions	8.55 x 4.25 x 6.15 inches
Item Weight	1.55 pounds
Total Power Outlets	6

Feature	Detail
Voltage	125 Volts
Max Load	1875W/15A Resistive, 8A/1000W Tungsten, 1/2Hp
Cord Length	6 feet (14AWG SJTW)
Special Features	Waterproof, Remote & Voice Control
Certifications	FCC Listed

Warranty and Support

DEWENWILS products typically come with a 1-year limited warranty from the date of purchase. For warranty claims, technical support, or any inquiries, please contact DEWENWILS customer service.
Visit the official DEWENWILS Store for more information:DEWENWILS Amazon Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B1PJY9S7

More documents and user manuals: **https://manuals.plus/**