HAUSHOF HH22050JP

HAUSHOF Portable Carpet Spot and Upholstery Cleaner User Manual

Model: HH22050JP

Product Overview

The HAUSHOF Portable Carpet Spot and Upholstery Cleaner is a lightweight and powerful machine designed for deep cleaning and stain removal on various surfaces. Its compact design and versatile tools make it ideal for tackling pet stains, dirt, and odors on carpets, rugs, upholstery, and even car interiors.



Figure 1: HAUSHOF Portable Carpet Spot and Upholstery Cleaner with accessories.

Setup and Assembly

1. **Unpack the Cleaner:** Carefully remove all components from the packaging. Ensure all parts listed in the packing list are present.
2. **Identify Tanks:** The cleaner features a dual-tank design. Identify the clean water tank (larger, 37 oz capacity) and the dirty water/sewage tank (smaller, 17 oz capacity).



Figure 2: Illustration of the dual tank design for clean and dirty water.

3. **Fill Clean Water Tank:** Remove the clean water tank by pulling back the lever and lifting it up. Fill it with clean water (and appropriate cleaning solution if desired, ensuring it's safe for the machine and surface). Do not exceed the MAX fill line. Securely reattach the tank.
4. **Attach Hose and Tool:** Connect the flexible hose to the main unit. Select the appropriate cleaning tool (water sucker with brush for deep cleaning or right-angled water sucker for crevices). Attach the chosen tool securely to the end of the hose.



Figure 3: The water sucker with brush attachment for deep cleaning.



Figure 4: The right-angled water sucker for hard-to-reach areas.

5. **Power Connection:** Unwind the 10 ft power cord and plug the unit into a standard electrical outlet.

Operating Instructions

1. **Pre-test:** Before cleaning, always test the cleaner on an inconspicuous area of the carpet or upholstery for colorfastness.
2. **Power On:** Press the power button located on the top of the unit to turn on the cleaner. The 400W motor will activate.
3. **Spray Solution:** Hold the cleaning tool over the stained area. Press the trigger on the handle to spray cleaning solution onto the stain. Ensure the area is adequately saturated.
4. **Scrub the Stain:** Use the brush on the cleaning tool to gently scrub the stained area. Work the solution into the fibers to loosen dirt and stains.
5. **Extract Dirty Water:** Release the spray trigger and firmly press the cleaning tool against the surface. Pull the tool slowly over the treated area to suction up the dirty water. Repeat this step until no more dirty water is being extracted and the area is as dry as possible.



Figure 5: User operating the cleaner on a carpet to remove stains.

6. **Monitor Dirty Water Tank:** The dirty water tank is transparent, allowing you to see the extracted liquid. Empty the tank when it reaches the MAX fill line to prevent overflow.

Maintenance

Regular maintenance ensures optimal performance and longevity of your HAUSHOF cleaner.

1. **Empty and Rinse Tanks:** After each use, remove both the clean and dirty water tanks. Empty any remaining liquid. Rinse both tanks thoroughly with clean water. The dirty water tank can be fully disassembled for easy cleaning.



Figure 6: Emptying the dirty water tank after use.

2. **Clean Cleaning Tools:** Detach the cleaning tools from the hose. Rinse them under running water to remove any debris or residue. Ensure the spray nozzle and suction path are clear.
3. **Wipe Down Unit:** Use a soft, damp cloth to wipe down the exterior of the main unit. Do not immerse the main unit in water.

4. **Store Properly:** Once all components are clean and dry, store the cleaner in a cool, dry place. The hose can be wrapped around the base for compact storage.



Figure 7: The compact design allows for easy storage.

Troubleshooting

Problem	Possible Cause	Solution
No Power	Unit not plugged in; Power outlet not working.	Ensure power cord is securely plugged into a working outlet. Check circuit breaker.
No Spray	Clean water tank empty; Spray nozzle clogged; Tank not seated correctly.	Refill clean water tank. Clean spray nozzle. Re-seat clean water tank firmly.  Figure 8: Common issues and solutions for water leakage or no spray.
Poor Suction	Dirty water tank full; Suction nozzle clogged; Tank not seated correctly.	Empty dirty water tank. Clean suction nozzle. Re-seat dirty water tank firmly.
Water Leakage	Tank caps not tightened; Missing seal ring; Tank not seated correctly.	Ensure all tank caps are tightly secured. Check for missing or damaged seal rings. Re-seat tanks firmly.

Specifications

- **Model:** HH22050JP
- **Brand:** HAUSHOF
- **Power:** 400W Motor
- **Clean Water Tank Capacity:** 37 oz
- **Dirty Water Tank Capacity:** 17 oz
- **Item Weight:** 7.5 lbs
- **Hose Length:** 4 ft
- **Power Cord Length:** 10 ft
- **Color:** White & Light Grey
- **UPC:** 820909679370

Warranty and Support

For warranty information or technical support, please refer to the official HAUSHOF website or contact their customer service directly. Keep your purchase receipt for warranty claims.

Official User Guide (PDF): Download PDF

HAUSHOF Store: Visit Store

© 2023 HAUSHOF. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question